

Operating Instructions
for
Handheld Pressure Measuring Devices
with External Pressure Sensors

Model: HND-P105



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Electrical Connection	4
6.1 Mains Operation With Power Supply	4
7. Operation / Configuration / Adjustments	5
7.1 Safety Requirements	5
7.2 Connections.....	6
7.3 Display.....	6
7.4 Basic Operation	6
7.5 Configuration	7
7.6 Measuring Of Water Level – Display Unit [m]	8
7.7 Calibration Services.....	9
7.8 Pressure Connection To The Sensors.....	9
7.9 Error And System Messages	10
7.10 The Serial Interface	11
8. Maintenance	11
8.1 Battery Operation.....	11
9. Technical Information.....	12
10. Order Codes	13
10.1 Pressure sensors for HND-P105	13
10.2 Accessories	14
11. Declaration of Conformance	15

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Handheld Pressure Measuring Devices with External Pressure Sensors
model: HND-P105
- Operating Instructions

4. Regulation Use

Any use of the Manual Pressure Measuring Devices with External and Integrated Pressure Sensors, model: HND-P105, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The KOBOLD manual pressure measuring devices HND-P105 are highly precise, compact pressure measuring devices that can be used universally. In conjunction with the appropriate external pressure sensors, precise measurement results over the entire measuring range can be achieved.

Various pressure sensors are available for a multitude of measuring tasks and special applications. The respective measurement task determines which combination is selected. Naturally, these first-rate KOBOLD-measuring units can display more than just pressure. All devices in this series allow for minimum/maximum value memory, hold function, automatic self-shut-off, or zero point offset entry for all connected pressure sensors.

6. Electrical Connection

6.1 Mains Operation With Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}.

Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage.

We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002.

Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

6.1.1 Connecting/Changing Sensors

Do not use unsuitable sensors. Connecting other devices/sensors as specified may cause a damage to the instrument and device/sensor! Switch off device before changing the sensor.

Connect sensor before switching on the device, otherwise the sensor may not be detected correctly. When connecting the sensor the connector may not lock correctly. In such case take the plug not at the casing but at the buckling protection at the end of the plug. If plug is entered correctly, it will slide in smoothly. To disconnect sensor do not pull at the cable but at the plug (to open locking mechanism).

7. Operation / Configuration / Adjustments

7.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices.

However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under *9 Technical Information*.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.




Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be a risk if:
 - there is visible damage to the device
 - the device is not working as specified
 - the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.

7.2 Connections



1. **Interface:** Connect to optically isolated interface adapter (accessory: GRS 3100, GRS 3105, USB 3100 or USB 3100N)
2. **Connections for pressure sensors** of the HND-PS-family
3. The **mains socket** is located at the left side of the instrument

7.3 Display

Units: an arrow points to the chosen measuring unit

SL: appears if sea-level-correction is activated

Tara: appears if tara-function is activated

main display: shows measuring value

secondary display: shows min-, max- or hold value

Logg: not used

7.4 Basic Operation

When switching on the device displayed “Corr”, if a sensor with activated offset or scale correction is connected.

On-/Off-Switch

1 ON/OFF

2 max

3 Tara

4 Set/Menu

5 min

6 Store/Quit

Tara: Calling of tara function

min/max: Showing the min- resp. max-memory

Store/Quit: Calling of hold function

Set/Menu: Calling of configuration

Tare Function: By pressing `Tara` (key 3) the displays will be set to 0. All measuring from then on will be displayed relatively to the set tare values. When the tare function is activated, the arrow “Tara” appears in the display. To deactivate tare function press `Tara` for >2 seconds. **Please note: Activating/deactivating tara clears the max-&min-memories.**

Max Memory: Pressing `max` (key 2) shows the maximum of the measured values. Pressing it again hides it. To clear the max memory press key `max` for >2 seconds.

Min Memory: Pressing `min` (key 5) shows the minimum of the measured values. Pressing it again hides it. To clear the min memory press key `min` for >2 seconds.

Hold Function: By pressing `Store/Quit` (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it.

Zero-Point Adjustment: If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press key 3 for approx. 5 seconds. (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu). Please note: A zero-point adjustment can only be carried out if the difference between the value on display is less than 500 digits!

To recall the manufacturer`s calibration press button 3 for approx. 15 seconds.

Note: If a zero-point adjustment was carried out, this will be signalled by the short displaying of “Corr” when switching on the device.

7.5 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu.

Pressing key **Menu** jumps between the parameters.

The parameters can be changed with \blacktriangle (key 2) or \blacktriangledown (key 5).

Quit (key 6) finishes the configuration and returns to standard measuring operation.

7.5.1 Unit: Choice Of The Display Unit



Choose the desired display unit, the referring unit is displayed by means of a functional arrow in the display. The selection is permanently stored in the sensor, therefore after reconnecting the sensor the unit will instantly reappear. The choice depends on the used sensor.

7.5.2 Sea Level Correction For Absolute Pressure Sensors

The device displays the absolute pressure measured at the sensor. This is not necessarily the same like the values given by weather stations! The weather stations' values are pressure at sea level. Usually the sensor is placed above sea level and therefore, if the value at sea level (zero) is to be measured, the pressure loss resulting from the actual level above zero has to be considered!



- To correct activate the „Sea-Level-Function“:
Select „on“ in the menu „SL“ with \blacktriangle (key 2) or \blacktriangledown (key 5).



- Jump to the next parameter „Alti“ by pressing **Menu** (key 4).
Then enter the altitude above sea level of the sensor's location in meters and leave the configuration by pressing **Quit** (key 6)

If the sea level correction is active this will be shown by the functional arrow „SL“ in the display, the device now displays the absolute pressure at sea level (zero).

7.5.3 P.oFF: Auto Power Off Time



The device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power off time. The power off time can be set to values between 1 and 120 min. It can be completely deactivated by setting the parameter to ,P.oFF = oFF“.

7.5.4 Adr: Base Address of Interface



Up to 10 devices of the HND- handheld-family can be connected to a serial interface at once (depending on interface converter, e.g. HND-P...: 5 devices). To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on.

7.5.5 OFFS: Adjusting Sensor Zero Displacement

A zero displacement can be carried out for the measured value:

$$\text{value displayed} = \text{value measured} - \text{offset}$$

Standard setting: 'off' = 0.0, i.e. no zero displacement will be carried out. Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations. Input is in the display unit.

7.5.6 SCAL: Adjusting Sensor Scale

The scale of the measuring can be influenced by this setting (factor is in %):

$$\text{displayed value} = \text{measured value} * (1 + \text{Scal}/100)$$

Standard setting: 'off' = 0.000, i.e. value is not corrected. Together with the zero displacement (see above) this factor is mainly used to compensate for sensor deviations.

7.6 Measuring Of Water Level – Display Unit [m]

(only for devices with ,m' printed below the display)

When using a suitable waterproof pressure sensor the unit [m] for meters of water can be set in the menu "Unit". 10 m of water are roughly 1 bar over pressure. Measurements can be made e.g. like described below :

- With abs. pressure sensor (SL oFF!): Press ,Tara' when sensor is at ambient air and then bring sensor to the depth to be measured. The display shows now the depth in [m].
- With rel pressure sensor: bring tube connection for lower press. in contact to ambient air by means of a tube (no water contact!) and bring the sensor with its open press. connection for higher pressure to water depth to be measured (display and is compensated for pressure changes in ambient air).

7.7 Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certified for its accuracy, it is the best solution to return it with the referring sensors to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

7.8 Pressure Connection To The Sensors

The device is designed to be connected to the sensors of the HND-PS...-series without a new calibration being necessary. Therefore a great variety of replaceable sensors of e.g. –1.999...2.500 mbar relative up to 0...400.0 bar absolute pressure can be connected to the device (*p.r.t. chapter 10.1 Pressure sensors*)

7.8.1 Relative Pressure Sensors

- **For measurements of over- or under pressure:**

Connect plastic tube with internal dia of 4 mm to pressure port "B". Port "A" will not be used!

Pressure sensors HND-PS01, -PS02 and –P03 allow for measurements of under pressure up to the entire over pressure measuring range by re-plugging the tube to pressure port "A". Please note that all values are displayed as positive values. No minus sign will be shown. (Example for HND-PS02: For tube connection "B" the measuring range covers -19.99 to 25.00 mbar. If you replug to port "A" under pressure measurements down to -25.00 mbar could be carried out with the display showing the value 25.00 (no minus sign).

- **For measurements of pressure differences:**

Connect both plastic tubes with an internal dia of 4 mm to pressure port "B" and "A"; make sure to apply higher pressure to port "B".




7.8.2 Absolute pressure sensors:

Connect plastic tube with an internal dia of 4 mm to pressure port "A". (Port "B" is not used.)

7.8.3 Stainless steel pressure sensors:

For measurements of over-, under- or absolute pressure screw sensor to G1/4" pressure terminal or plug plastic tube to a suitable adapter.

7.9 Error And System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
 or Err.9	No sensor connected	Switch off device and connect sensor
	Connected sensor or device defective	If second sensor available, check if device is ok. Return defective device/sensor to manufacturer for repair
	Measured value far out of allowable range	Check: pressure not within sensor range?
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
Err.1	Measured value above allowable range	Check: pressure not within sensor range? -> measuring value to high!
	Sensor defective	Return to manufacturer for repair
Err.2	Measured value below allowable range	Check: pressure not within sensor range? -> measuring value to low!
	Sensor defective	Return to manufacturer for repair
Err.3	Display range overflow	Check: value above 19999->to high to be displayed
Err.4	Display range underflow	Check: display below -19999 (Tara?)-> to low!
Err.11	Value could not be calculated	Choose different unit
	Calculation overflow happened	Choose different unit
Err.7	System error	Return to manufacturer for repair
----	Sensor not present/recognised	Connect suitable sensor
	Could not calculate value	

7.10 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031 or HND-Z032) the device can be connected to a computer for data transfer. To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

- **BUS-EBS9M:** 9-channel software to display the measuring values




Note: The measuring display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Code	Name/Function	Code	Name/Function
0	Read measurement value	200	Read min display range
3	Read system state	201	Read max display range
6	Read min value	202	Read display range - unit
7	Read max value	204	Read display range – decimal point
12	Read ID number	208	Read # of channels
176	Read min measuring range	214	Read Scale adjustment
177	Read max measuring range	216	Read Offset adjustment
178	Read measuring range unit	222	Read power off time (Conf.-P.oFF)
179	Read measuring range decimal point	223	Set power off time (Conf.-P.oFF)
180	Read kind of measuring of sensor	240	Reset
199	Read kind of measuring of display	254	Program version

8. Maintenance

8.1 Battery Operation

If  and 'bAt' are shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up. The battery has to be taken out, when storing device above 50 °C.



Please note: We recommend to take out battery if device is not used for a longer period of time!

9. Technical Information

Measuring ranges:

Display range:	-19999 ... +19999 digit, depending on connected sensor
Resolution:	depending on connected sensor
Pressure units:	mbar, bar, kPa, MPa, mmHg, PSI, mH ₂ O
Accuracy: (typ.)	± 0,1 % F.S. (at nominal temperature)
Measuring rate:	4 meas./sec
Nominal temperature:	25 °C

Sensor:

All sensors of the HND-PS-series without calibration can be connected.

Connection:

Mini-DIN-Socket with locking mechanism
The sensor will automatically be detected, the measurement range settings are set referring to sensor data

Additional Functions:

Power-Off-Function:

Device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power-off delay. The power-off delay can be set to values between 1 and 120 min.; it can be completely deactivated.

Display:

2 four-digit LCDs (12.4mm high and 7mm high) for measuring values, and for min/max memories, hold function, etc. As well as additional functional arrows.

Pushbuttons:

6 membrane keys

Interface:

Serial interface (3.5 mm jack) can be connected to HND-Z031 or HND-Z032 to RS232 or USB interface of a PC via electrically isolated interface adapter.

Power supply:

9 V-battery, type: IEC 6F22
(included in the scope of delivery)
As well as additional d.c. connector (diameter of internal pin 1.9 mm) for external 10.5-12V direct voltage supply. (suitable power supply: GNG10/3000)

Power consumption:

<1.6 mA

Low battery warning:

`bAt`

Housing:

impact-resistant ABS, membrane keyboard, transparent panel, Front side IP65

Dimensions:

142 x 71 x 26 mm (LxWxD)

Weight:

approx. 150 g

Working temperature:

-25...+50 °C

Allowable rel. humidity:

0...95%RH (not condensing)




Storage temperature:

-25...+70 °C

10. Order Codes

Order-no.	Housing design
HND-P105	1 x pressure sensor input, standard

10.1 Pressure sensors for HND-P105

Measuring range	Accuracy	Resolution	Overload	Working-Temperature	Connection	Order-no.
1.999...2.500 mbar	± 0.2 % f.s. / ± 1.0 % f.s.*	0.001 mbar	max. 200 mbar	0...+50 °C	Nylon spigot for hose 6 x1 mm 	HND-PS01**
19.99...25 mbar	± 0.2 % f.s. / ± 0.5 % f.s.*	0.01 mbar	max. 300 mbar			HND-PS02**
199.9...350.0 mbar	± 0.2 % f.s. / ± 0.4 % f.s.*	0.1 mbar	max. 1 bar			HND-PS03**
1000...2000 mbar		1 mbar	max. 4 bar			HND-PS04**
-1...10 bar		10 mbar	max. 10.34 bar			HND-PS05**
0...1300 mbar abs.		1 mbar	max. 4 bar abs.			HND-PS06**
0...2000 mbar abs.		10 mbar	max. 10 bar abs.			HND-PS07**
0...7.00 bar abs.		0.1 mbar	max. 1.4 bar			HND-PS08**
0...350.0 mbar rel.	± 0.2 % f.s. / ± 0.4 % f.s.*	1 mbar	max. 4 bar abs.	0...+70 °C	G ¼ male, stainless steel 	HND-PS09
0...1000 mbar abs.			max. 14 bar abs.			HND-PS10
0...3500 mbar abs.			max. 14 bar rel.			HND-PS11
0...3500 mbar rel.			max. 28 bar abs.			HND-PS12
0...7000 mbar abs.		10 mbar	max. 140 bar abs.			HND-PS13
0...35.00 bar abs.			max. 280 bar abs.			HND-PS14
0...70.00 bar abs.		0.1 bar	max. 600 bar abs.			HND-PS15
0...160.0 bar abs.						HND-PS16
0...250.0 bar abs.						HND-PS17
0...400.0 bar abs.						HND-PS18
0...1000 mbar abs	$\pm 0,2\%$ ME / $\pm 0,4\%$ ME*	1 mbar	max. 5 bar abs	0...+70°C	G ½ male 	HND-PA20
0...2500 mbar abs			max. 10 bar abs			HND-PA21
0...4000 mbar abs			max. 17 bar abs			HND-PA22
0...6000 mbar abs			max. 35 bar abs			HND-PA23

* in the range from 0 to +50 °C

** Pressure sensors HND-PS01 up to HND-PS08 are only suitable for air and non corrosive/non ionizing gases and liquid.

10.2 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10.5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose 6.4 on hose 6.4
HND-Z082	Hose clamp for hose 6.4
HND-Z088	Adapter made of brass for G ½ internal threads on hose 6.4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

* Please pay attention to instrument dimensions

More accessories on request

11. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

**Handheld Pressure Measuring Devices with External Pressure Sensors
Model: HND-P105**

to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and laboratory use. EMC requirements

Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline


Hofheim, 8. Mai 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Hand-held Pressure Measuring Devices
with Integrated Pressure Sensors

Model: HND-P121



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. General	4
6.1 Safety Requirements	4
6.2 Maintenance	5
6.3 Connections.....	5
6.4 Display	6
7. Operation	6
8. Configuration of the Device	7
8.1 Unit: Coice Of The Display Unit	7
8.2 P.oFF: Auto Power Off Time	7
8.3 Adr: Base Address of Interface	7
8.4 OFFS: Adjusting Sensor zero Displacement.....	8
8.5 SCAL: Adjusting Sensor Scale	8
9. Error and System Messages.....	8
10. Pressure Connection to the Sensors.....	9
11. Calibration Services	9
12. The Serial Interface.....	10
13. Technical Information.....	11
14. Order Codes	12
14.1 Accessories for HND-P	12
15. Declaration of Conformance	13

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Hand-held Pressure Measuring Devices with Integrated Pressure Sensors
model: HND-P121
- Operating Instructions

4. Regulation Use

Any use of the hand--held Pressure Measuring Devices with Integrated Pressure Sensors, model: HND-P121, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The highly precise KOBOLD manual pressure measuring devices HND-P121 are measuring devices with integrated pressure sensors. They have two pressure measurement inputs on the top of the housing, which are connected to the measuring points by means of stable metal connections and plastic hoses that are available as accessories. Numerous measuring ranges in the overpressure and underpressure range are available for various measurement tasks, such as differential pressure measurement. In addition to pressure display, these first-rate, compact, universally applicable measuring units offer additional functions such as minimum/maximum value memory, a hold function, tare function, automatic self-shut-off, or zero point offset. The devices with an expanded spectrum of functions also have a logger function, a peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

6. General

6.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices.

However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under chapter 13. *Technical Information*.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.



Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting.


Operator safety may be a risk if:

- there is visible damage to the device
- the device is not working as specified
- the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.

6.2 Maintenance

• Battery Operation

If  and 'bAt' are shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.



Note: We recommend to take out the battery if device is not used for a longer period of time!


• Mains Operation With Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002.

Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

6.3 Connections



Connection for pressure tubes:

„+“ = higher pressure, „-“ = lower pressure

Interface: Connection for el. isolated interface adapter (p.r.t. chapter 12 *The Serial Interface*)

The mains adapter socket is located at the left side of the device.

6.4 Display

Units: an arrow points to the chosen measuring unit
SL: no function

Tara: appears if tara-function is activated




main display: shows measuring value
secondary display: shows min-, max- or hold value

Logg: not used

7. Operation

When **switching on** the device and a zero point adjustment was carried out it shows shortly „nuLL Corr“.



Max Memory: Pressing 'max' (key 2) shows the maximum of the measured values. Pressing it again hides it. To clear the max memory press key 'max' for >2 seconds.

Min Memory: Pressing 'min' (key 5) shows the minimum of the measured values. Pressing it again hides it. To clear the min memory press key 'min' for >2 seconds.

Hold Function: By pressing 'Store/Quit' (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it.

Tare Function: By pressing 'Tara' (key 3) the display will be set to 0. All measurements from then on will be displayed relatively to the set tare value. When tara function is activated, the arrow "Tara" appears in the display. To deactivate tare function press 'Tara' for >2 seconds.



Please Note: Activating/deactivating tara clears the max- & min-memories.

Zero-Point Adjustment: If there is no pressure applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press key 3 for approx. 5 seconds (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu).

Please note: A zero-point adjustment can only be carried out if the difference between the value on display is less than 500 digits! To recall the manufacturer's calibration press button 3 for approx. 15 seconds. Note: If a zero-point adjustment was carried out, this will be signalled by the short displaying of "Corr" when switching on the device.

8. Configuration of the Device

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu.

Pressing key **Menu** jumps between the parameters.

The parameters can be changed with \blacktriangle (key 2) or \blacktriangledown (key 5).

Quit (key 6) finishes the configuration and returns to standard measuring operation.

8.1 Unit: Coice Of The Display Unit



Choose the desired display unit, the referring unit is displayed by means of a functional arrow in the display. The selection is permanently stored in the device, therefore after power on the unit will instantly reappear. The choice depends on the used sensor.

The unit [m] =mH₂O is just supported by devices with [m] printed below the display!

8.2 P.oFF: Auto Power Off Time



The device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power off time. The power off time can be set to values between 1 and 120 min. It can be completely deactivated by setting the parameter to ,P.oFF = oFF“.

8.3 Adr: Base Address of Interface



Up to 10 devices of the HND-P... handheld-family can be connected to a serial interface at once. To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on.

8.4 OFFS: Adjusting Sensor zero Displacement

A zero displacement can be carried out for the measured value:

$$\text{value displayed} = \text{value measured} - \text{offset}$$

Standard setting: 'off' = 0.0°, i.e. no zero displacement will be carried out. Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations. Input is in the display unit.



8.5 SCAL: Adjusting Sensor Scale

The scale of the measuring can be influenced by this setting (factor is in %):

$$\text{displayed value} = \text{measured value} * (1 + \text{Scal}/100)$$

Standard setting: 'off' = 0.000, i.e. value is not corrected. Together with the zero displacement (see above) this factor is mainly used to compensate for sensor deviations.

9. Error and System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
Err.1	Measured value above allowable range	Check: pressure above 25 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.2	Measured value below allowable range	Check: pressure below -1mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.4	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
Err.9	Measured value far out of allowable range	Check: pressure not within sensor range?
Err.7	System error	Return to manufacturer for repair

10. Pressure Connection to the Sensors

- **For measurements of over pressure (-1.00 mbar...25.00 mbar):**
Connect plastic tube with internal diameter of 4 mm to pressure port "+". Port "-" will not be used!
- **For measurements of under pressure (-25.00 mbar...0.00 mbar):**
Plug the tube to pressure port "-". The measuring range covers then -25.00 to 0.00 mbar.



Note: All values are displayed now as positive values. No minus sign will be shown.

Example: it is possible to measure under pressure down to -25.00 mbar, the display shows then the value 25.00 (no minus sign).

- **For measurements of pressure differences:**
Connect both plastic tubes with an internal diameter of 4 mm to pressure port "+" and "-"; make sure to apply higher pressure to port "+".

11. Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certified for its accuracy, it is the best solution to return it with the referring sensors to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

12. The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031) the device can be connected to a computer for data transfer. To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

- **BUS-SW9M:** 9-channel software to display the measuring values



Note: The measuring and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Code	Name/Function	Code	Name/Function
0	Read measurement value	200	Read min display range
3	Read system state	201	Read max display range
6	Read min memory	202	Read display range - unit
7	Read max memory	204	Read display range – decimal point
12	Read ID number	208	Read # of channels
174	Clear min memory	214	Read scale adjustment [%]
175	Clear max memory	216	Read offset adjustment
176	Read min measuring range	222	Read power off time (Conf-P.oFF)
177	Read max measuring range	223	Set power off time (Conf-P.oFF)
178	Read measuring range – measuring unit	240	Reset
179	Read measuring range – decimal point	254	Program version
180	Read kind of measuring of sensor		
199	Read kind of measuring of display		

13. Technical Information

Measuring range:	-1.00 to 25.00 mbar rel.
Accuracy:	±0.3 % f.s. (Hysteresis and linearity) ±0.4 % f.s. (in the range of 0-50 °C)
Resolution:	0.01 mbar (1Pa)
Units:	mbar, bar, Pa, kPa, mmHg, PSI, mH ₂ O (display "m") (switchable)
Overload:	max. 10000 Pa (max. 100 mbar)
Measurement input:	by means of two metal hose stems
Sensor:	piezo-resistive relative pressure sensor, for air or non-corrosive and non-ionising gases and liquids, not for water!
Display:	2 x 4- digit LCDs
Operating temp.:	0 to +50 °C
Storage temp.:	-20 to +70 °C
Storage humidity:	0 to 95 % r.H. (non-condensing)
Output:	serial interface (via 3,5mm jack, to RS232, or USB optional)
Power supply:	9 V-monobloc battery (included in the scope of delivery), external 10.5-12 V _{DC} via jack
Power consumption:	approx. 0,6 mA (HND-P121...)
Material:	housing made of impact-resistant ABS plastic
Degree of protection:	IP65, front side
Dimensions:	142 x 71 x 26 mm (L x W x D)
Weight:	approx. 165 g

Scope of functions:**Minimum/maximum value memory****Hold function:** »freezing« of the current value**Automatic-off function:** 1...120 min (can be deactivated)**Zero point adjustment** via keyboard possible**Tare function:** display, minimum/maximum values are set to zero**Battery change notification**

14. Order Codes

Order-no.	Housing design
HND-P121	2 measuring inputs, standard

14.1 Accessories for HND-P

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10.5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose 6/4 on hose 6/4
HND-Z082	Hose clamp for hose 6/4
HND-Z088	Adapter made of brass for G 1/2 internal threads on hose 6/4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

Additional accessories on request.

*Observe instrument dimensions.

15. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Pressure Measuring Devices with Integrated Pressure Sensors
model: HND-P121

to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and
laboratory use. EMC requirements

Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline


Hofheim, 8. May 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions

for

Hand held Pressure Measuring Devices with Integrated Pressure Sensors

Model:

HND-P121

HND-P123

HND-P126

HND-P127

HND-P129



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Electrical Connection	4
6.1 Mains Operation with Power Supply	4
7. Operation / Configuration / Adjustments	5
7.1 General.....	5
7.2 Pop-up clip.....	7
7.3 Calibration Services	8
7.4 Configuration	8
7.5 The Serial Interface	9
7.6 Zero Displacement Sensor ('OFFS')	10
7.7 Scale Correction Sensor ('SCAL')	10
7.8 Pressure Connection	10
7.9 Error and System Messages.....	12
8. Maintenance	12
8.1 Battery Operation.....	12
9. Technical Information.....	13
10. Order Codes	15
10.1 Accessories	16
11. Declaration of Conformance	17

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EC-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Hand held Pressure Measuring Devices with Integrated Pressure Sensors
Model: HND-P121/-P123/-P126/-P127/-P129
- Operating Instructions

4. Regulation Use

Any use of the device which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

Nearly all measuring tasks for the determination of pressure can be performed with the HND-P series KOBOLD hand-held pressure measuring devices. Various housing designs make it possible to find the right housing with the appropriate characteristic for every application. In addition to the large selection of external pressure sensors up to max. 400 bar absolute, measuring devices with integrated sensors in the millibar range are also available.

6. Electrical Connection

6.1 Mains Operation with Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002.

Prior to connecting the power supply to the mains makes sure that the operating voltage stated at the power supply is identical to the mains voltage.

7. Operation / Configuration / Adjustments

7.1 General

7.1.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices.

However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under *9 Technical Information*.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.




Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be a risk if:
 - there is visible damage to the device
 - the device is not working as specified
 - the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.

7.1.2 Display



- 1 **Main display:** shows actual value

- 2 Arrow points to the chosen measuring **unit**

- 3 **Secondary display:** shows min./max. or hold value

- 4 **SL:** appears if sea-level-correction is activated
(only HND-P129)

- 5 **Tara:** appears if tara-function is activated

- 6 *Not used*

7.1.3 Basic Operation



- ON / Off**
press short: shows the min./max. value

- min/max when taking measurement:**
press short: shows the min./max. value
press again: hides min./max. value
press 2 sec.: clears particular value

- Tara, zero-point adjustment:**
press short: display will be set to 0
The following measuring will be relatively displayed to the set tara value
press 2 sec.: deactivates tara-function
press 5 sec.: Zero-Point Adjustment¹⁾

- Set/Menu:**
press short: invokes configuration menu


- Store/Quit:**
press short: hold-function, the last measuring value will be held in the secondary display.
press again: hides the value



Please Note: Activating/deactivating tara clears the max- & min-memories.

¹⁾ Zero-Point Adjustment: If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press button 3 for approx. 5 seconds (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu). To recall the manufacturer's calibration press button 3 for approx. 15 seconds.

7.1.4 Connections



Connection for pressure tube


Interface: Connection for el. isolated interface adapter (p.r.t. chapter 7.5 *The Serial Interface*)

The mains adapter socket is located at the left side of the device.

7.2 Pop-up clip

Handling:

- Pull at label “open” in order to swing open the pop-up clip.



Pop-up clip closed


Pop-up clip at position 90°

Pop-up clip at position 180°

- Pull at label “open” again to swing open the pop-up clip further.

Function:

- The device with a closed pop-up clip can be plainly laid onto a table or attached to a belt, etc.
- The device with pop-up clip at position 90° can be set up on a table, etc.
- The device with pop-up clip at position 180° can be suspended from a screw or the magnetic holder.



Device attached to a belt

Device set up on a table

Device suspended from magnetic holder

7.3 Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certificated for its accuracy, it is the best solution to return it with the referring sensors to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!






7.4 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu.

Pressing key **Menu** jumps between the parameters.

The parameters can be changed with ▲ (key 2) or ▼ (key 5).

Quit (key 6) finishes the configuration and returns to standard measuring operation.

Parameter	Value	Description
,Menu'	▲ or ▼	
	mbar, bar, ...	Unit: Unit of display
	oFF/on	Sea-Level: Sea level correction: on or off (only available at HND-P129)
	-2000 ... 9999	Altitude: Input of altitude above sea level [m], only if SL=on (only available at HND-P129)
	1...120	Auto Power-Off time in minutes
	oFF	Auto Power-Off deactivated
	0,1, 11...91	Base adress of interface
OFFS	refer to list below	The offset of sensor will be displaced by this value to compensate for deviations in the probe or in the measuring device.
	oFF	Zero displacement inactive (=0.00)
SCAL	-2.000 ... 2.000	The measuring scale of sensor will be changed by this factor [%] to compensate deviations of temperature probe or measuring device.
	oFF	Scale correction factor inactive (=0.000)

Device type	adjustable offset
HND-P121	-5.00...5.00 mbar
HND-P123	-50.0...50.0 mbar
HND-P127	-50.0...50.0 mbar
HND-P126	-500...500 mbar
HND-P129	-500...500 mbar

7.4.1 Sea Level Correction for Absolute Pressure Sensors (HND-P129)

The device displays the absolute pressure measured at the sensor. This is not necessarily the same like the values given by weather stations! The weather stations' values are pressure at sea level. Usually the sensor is placed above sea level and therefore, if the value at sea level (zero) is to be measured, the pressure loss resulting from the actual level above zero has to be considered! To correct the measuring display activate the "Sea-Level-Function" (SL, p.r.t. chapter 7.4).

If the sea level correction is active this will be shown by the functional arrow „SL“ in the display, the device now displays the absolute pressure at sea level (zero).

7.4.2 Power off Time

The device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power off time. It can be completely deactivated by setting the parameter to „P.oFF = oFF“.

7.5 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter HND-Z031, HND-Z032 (accessories) the device can be connected to a computer for data transfer.

To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

BUS-S20M: 20-channel software to display the measuring values



Note: The measuring and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Code	Name/Function	Code	Name/Function
0	Read measurement value	200	Read min display range
3	Read system state	201	Read max display range
6	Read min memory	202	Read display range - unit
7	Read max memory	204	Read display range – decimal point
12	Read ID number	208	Read # of channels
32	Read configuration flag BitCorrectToSealevel:32	214	Read scale adjustment [%]
		216	Read offset adjustment
160	Set configuration flag (see above)	220	Read altitude (only abs. press sensors)
174	Clear min memory	221	Set altitude (only abs. press sensors)
175	Clear max memory	222	Read power off time (Conf-P.oFF)
176	Read min measuring range	223	Set power off time (Conf-P.oFF)
177	Read max measuring range	240	Reset
178	Read measuring range – measuring unit	254	Program version
179	Read measuring range – decimal point		
180	Read kind of measuring of sensor		
199	Read kind of measuring of display		

7.6 Zero Displacement Sensor ('OFFS')

A zero displacement can be carried out for the measured value:

$$\text{value displayed} = \text{value measured} - \text{offset}$$

Standard setting: 'off' = 0.0°, i.e. no zero displacement will be carried out. Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations. Input is in the display unit.

7.7 Scale Correction Sensor ('SCAL')

The scale of the measuring can be influenced by this setting (factor is in %):

$$\text{displayed value} = \text{measured value} * (1 + \text{Scal}/100)$$

Standard setting: 'off' = 0.000, i.e. value is not corrected. Together with the zero displacement (see above) this factor is mainly used to compensate for sensor deviations.

7.8 Pressure Connection

2 (or 1) universal pressure connector for 6 x 1 mm (4 mm tube inner diameter) or 8 x 1 mm (6 mm tube inner diameter) plastic tubes.

7.8.1 Device type with absolute pressure (HND-P129)

Connect plastic tube to pressure port.

7.8.2 Device type with relative pressure

- For measurements of overpressure (refer to summary):
Connect plastic tube to pressure port "+". Port "-" will not be used!
- For measurements of underpressure (refer to summary):
Plug the tube to pressure port "-". The measuring range covers then up to max. overpressure range





Note: All values are displayed now as positive values. No minus sign will be shown. Example: it is possible to measure under pressure down to -25.00 mbar, the display shows then the value 25.00 (no minus sign).

- For measurements of pressure differences:
Connect both plastic tubes to pressure port "+" and "-"; make sure to apply higher pressure to port "+".

Measure ranges:

Device type	Over- or underpressure	underpressure
HND-P121	-1.00...25.00 mbar	-25.00...0.00 mbar
HND-P123	-10.0...350.0 mbar	-350.0...0.0 mbar
HND-P127	-10.0...420.0 mbar	-420.0...0.0 mbar
HND-P126	-100...2000 mbar	-2000...0 mbar

7.9 Error and System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
Err.1	Measured value above allowable range	Check: pressure above 1300 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.2	Measured value below allowable range	-> measuring value to low
	Sensor defective	Return to manufacturer for repair
Err.4	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
Err.9	Measured value far out of allowable range	Check: pressure not within sensor range?
Err.7	System error	Return to manufacturer for repair

8. Maintenance

8.1 Battery Operation

If 'bAt' is shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.



Please note: We recommend taking out battery if device is not used for a longer period of time!

9. Technical Information

HND-P121:

Measuring range: -1.00...25.00 mbar
Accuracy: ± 0.3 % F.S.
(hysteresis and linearity)
 ± 0.4 % F.S.
(temperature dependency 0...50 °C)
Resolution: 1 Pa (0.01 mbar)
Pressure units: mbar, bar, Pa, kPa, MPa, mmHg, PSI, m H₂O
(display "m")
Overload: max. 100 mbar

HND-P123:

Measuring range: -10.0...350.0 mbar
Accuracy: ± 0.2 % F.S.
(hysteresis and linearity)
 ± 0.4 % F.S.
(temperature dependency 0...50 °C)
Resolution: 0.01 mbar
Pressure units: mbar, bar, kPa, MPa, mmHg, PSI, m H₂O
(display "m")
Overload: max. 1 bar

HND-P127:

Measuring range: -10.0...420.0 mbar
Accuracy: ± 0.1 % F.S.
(hysteresis and linearity)
 ± 0.4 % F.S.
(temperature dependency 0...50 °C)
Resolution: 0.1 mbar
Pressure units: mbar, bar, kPa, MPa, mmHg, PSI, m H₂O
(display "m")
Overload: max. 1 bar

HND-P126:

Measuring range: -100...2000 mbar
Accuracy: ± 0.2 % F.S.
(hysteresis and linearity)
 ± 0.4 % F.S.
(temperature dependency 0...50 °C)
Resolution: 0.1 mbar
Pressure units: mbar, bar, kPa, MPa, mmHg, PSI, m H₂O
(display "m")
Overload: max. 4 bar

HND-P129:

Measuring range:	0...1300 mbar abs.
Accuracy:	±0.2 % F.S. (hysteresis and linearity) ±0.4 % F.S. (temperature dependency 0...50 °C)
Resolution:	1 Pa (0.01 mbar)
Pressure units:	mbar, bar, Pa, kPa, MPa, mmHg, PSI, m H ₂ O (display "m")
Overload:	max. 4 bar abs.
Measuring input:	by means of a metal-hose stems
Sensor:	piezo-resistive absolute pressure sensor, for air or non-corrosive and non-ionising gases and liquids, not for water!
Display:	2 x 4 ½ digit LC-displays
Operating temperature:	0...+50 °C
Storage temperature:	-20...+70 °C
Relative humidity:	0...95 % r.H. (non-condensing)
Output:	serial interface (via 3.5 mm jack, transformer on RS232 or USB optional)
Power supply:	9V-monobloc battery (included in the scope of delivery), extern 10.5...12 V _{DC} via jack
Current consumption:	~0.6 mA
Materials:	housing made of impact-resistant ABS plastic
Protection:	IP 65, front side
Dimensions:	142 x 71 x 26 mm (L x W x D)
Weight:	approx. 165g

Scope of functions:

- **Min-/Max-value memory**
- **Hold function:** »freezing« of the current value
- **Automatic-off function:** 1...120 min (can be deactivated)
- **Zero point adjustment** via keyboard possible
- **Tare function:** Display, minimum/maximum values are set to zero
- **Battery change notification**

10. Order Codes

Order-No.	Housing design
HND-P121	2 measuring inputs, standard
HND-P123	2 measuring inputs, standard
HND-P126	2 measuring inputs, standard
HND-P127	2 measuring inputs, greater sensor accuracy, standard
HND-P129	1x pressure sensor input, standard

10.1 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10.5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
BUS-S20M	Software for recording measuring data on a PC for 20 modules, for devices of the HND-series without logging function
HND-Z081	Double nozzle for hose 6/4 on hose 6/4
HND-Z082	Hose clamp for hose 6/4
HND-Z083	Adapter made of brass for G 1/4 internal threads on hose 6/4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

* observe instrument dimensions

Additional accessories on request

11. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

**Hand held Pressure Measuring Devices with Integrated Pressure Sensors
Model: HND-P121/-P123/-P126/P127/-P129**

to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and
laboratory use. EMC requirements

Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline


Hofheim, 22. Juli 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Hand-held Measuring Devices with
Integrated Pressure Sensors

Model: HND-P123



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Electrical Connection	4
6.1 Mains Operation with Power Supply	4
7. Operation / Configuration / Adjustments	5
7.1 General	5
7.2 Configuration	7
7.3 Error And System Messages	8
7.4 Pressure Connection To The Sensors	8
7.5 Calibration Services	9
7.6 The Serial Interface	9
8. Maintenance	10
8.1 Battery Operation.....	10
9. Technical Information.....	10
10. Order Codes	11
10.1 Accessories	12
11. Declaration of Conformance	13

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Hand-held Measuring Devices with Integrated Pressure Sensors
model: HND-P123
- Operating Instructions

4. Regulation Use

Any use of the Hand-held Measuring Devices with Integrated Pressure Sensors, model: HND-P123, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The highly precise KOBOLD manual pressure measuring devices HND-P123 are measuring devices with integrated pressure sensors. They have two pressure measurement inputs on the top of the housing, which are connected to the measuring points by means of stable metal connections and plastic hoses that are available as accessories. Numerous measuring ranges in the overpressure and underpressure range are available for various measurement tasks, such as differential pressure measurement. In addition to pressure display, these first-rate, compact, universally applicable measuring units offer additional functions such as minimum/maximum value memory, a hold function, tare function, automatic self-shut-off, or zero point offset. The devices with an expanded spectrum of functions also have a logger function, a peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

6. Electrical Connection

6.1 Mains Operation with Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002.

Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

7. Operation / Configuration / Adjustments

7.1 General

7.1.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices.

However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under *9 Technical Information*.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.



Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).


5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting.

Operator safety may be a risk if:

- there is visible damage to the device
- the device is not working as specified
- the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.

7.1.2 Connections



Connection for pressure tubes: „+“ = higher pressure, „-“ = lower pressure

Interface: Connection for el. isolated interface adapter (see. chapter *7.6 The Serial Interface*)


The mains adapter socket is located at the left side of the device.

7.1.3 Display

Units: an arrow points to the chosen measuring unit

Tara: appears if tara-function is activated.

SL: no function



main display: shows measuring value.


!: indicates weak battery or other warnings

secondary display: min-, max- or hold value

Logg: no function

AL: no function

When switching on the device and a zero point adjustment was carried out it shows shortly „nuLL Corr“.



On-/Off-Switch

Tara: Calling of tara function, zero point adjustment

min/max: Showing the min- resp. max-memory in sec. display

Store/Quit: Calling of hold function

Set/Menu: Calling of configuration

Max Memory: Pressing 'max' (key 2) shows the maximum of the measured values. Pressing it again hides it. To clear the max memory press key 'max' for >2 seconds.

Min Memory: Pressing 'min' (key 5) shows the minimum of the measured values. Pressing it again hides it. To clear the min memory press key 'min' for >2 seconds.

Hold Function: By pressing 'Store/Quit' (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it.

Tare Function: By pressing 'Tara' (key 3) the display will be set to 0. All measurements from then on will be displayed relatively to the set tare value. When tara function is activated, the arrow "Tara" appears in the display. To deactivate tare function press 'Tara' for >2 seconds.



Please Note: Activating/deactivating tara clears the max- & min-memories.

Zero-Point Adjustment: If there is no pressure applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press key 3 for 5 seconds. (Please note: A zero-point adjustment can only be carried out if the difference between the value on display and the value calibrated on site is less than 2%! E.g. for the measuring range of $-10.0 \dots +350.0$ mbar, =>zero-point adjustment up to 7.0 mbar possible). To recall the manufacturer's calibration press button 3 for approx. 7 seconds.



Note: If a zero-point adjustment was carried out, this will be signalled by the short displaying of „NuLL Corr“ when switching on the device.

7.2 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu.

Pressing key **Menu** jumps between the parameters.

The parameters can be changed with \blacktriangle (key 2) or \blacktriangledown (key 5).

Quit (key 6) finishes the configuration and returns to standard measuring operation.

7.2.1 Unit: Coice Of The Display Unit



Choose the desired display unit, the referring unit is displayed by means of a functional arrow in the display. The selection is permanently stored in the device, therefore after power on the unit will instantly reappear. The choice depends on the used sensor.

The unit [m] =mH₂O is just supported by devices with [m] printed below the display

7.2.2 P.oFF: Auto Power Off Time



The device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power off time.



The power off time can be set to values between 1 and 120 min. It can be completely deactivated by setting the paramter to ‚P.oFF = oFF“.

7.2.3 Adr: Base Address of Interface



Up to 10 devices of the HND- handheld-family can be connected to a serial interface at once. To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on.

7.3 Error And System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
<i>Err.1</i>	Measured value above allowable range	Check: pressure above 350 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
<i>Err.2</i>	Measured value below allowable range	Check: pressure below -10 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
<i>Err.4</i>	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
<i>Err.9</i>	Measured value far out of allowable range	Check: pressure not within sensor range?
<i>Err.7</i>	System error	Return to manufacturer for repair

7.4 Pressure Connection To The Sensors

- **For measurements of over pressure (-10.0 mbar...350.0 mbar):**

Connect plastic tube with internal dia of 4 mm to pressure port "+". Port "-" will not be used!

- **For measurements of under pressure (-350.0 mbar...0.0 mbar):**

Plug the tube to pressure port "-". The measuring range covers then -350.0 to 0.0 mbar.



Note: All values are displayed now as positive values. No minus sign will be shown.

Example: it is possible to measure under pressure down to -350.0 mbar, the display shows then the value 350.0 (no minus sign).

- **For measurements of pressure differences:**

Connect both plastic tubes with an internal dia of 4 mm to pressure port "+" and "-"; make sure to apply higher pressure to port "+".

7.5 Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certified for its accuracy, it is the best solution to return it with the referring sensors to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

7.6 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031 or HND-Z032) the device can be connected to a computer for data transfer. With the HND-Z032 up to 5 devices of the HND- series can be connected to one interface (see also manual of HND-Z031 or HND-Z032)

To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

BUS-SW9M: 9-channel software to display the measuring values




Note: The measuring and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Code	Name/Function	Code	Name/Function
0	Read measurement value	194	Set display unit
3	Read system state	199	Read kind of measuring of display
6	Read min memory	200	Read min display range
7	Read max memory	201	Read max display range
12	Read ID number	202	Read display range - unit
174	Clear min memory	204	Read display range – decimal point
175	Clear max memory	208	Read # of channels
176	Read min measuring range	222	Read power off time (Conf-P.oFF)
177	Read max measuring range	223	Set power off time (Conf-P.oFF)
178	Read measuring range – measuring unit	240	Reset
179	Read measuring range – decimal point	254	Program version
180	Read kind of measuring of sensor		

8. Maintenance

8.1 Battery Operation

If  and 'bAt' are shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.



Please note: We recommend to take out battery if device is not used for a longer period of time!

9. Technical Information

Measuring range:	-10.0 to 350.0 mbar (-350.0...+350.0 mbar)
Accuracy:	±0.2 % F.S. (Hysteresis and Linearity) ±0.4 % F.S. (in the range of 0-50 °C)
Resolution:	0.1 mbar
Units:	mbar, bar, kPa, MPa, PSI, mmHg, m (switchable)
Overload:	max. 1 bar
Measurement input:	by means of two metal hose stems
Sensor:	piezo-resistive relative pressure sensor, for air or non-corrosive and non-ionising gases and liquids, not for water!
Display:	2 x 4- digit LC-displays
Operating temp.:	0 to +50 °C
Storage temp.:	-20 to +70 °C
Storage humidity:	0 to 95 % r.H. (non-condensing)
Output:	serial interface (via 3-pin jack, transformer on RS232 or USB optional)
Power supply:	9 V-monobloc battery (included in the scope of delivery), extern 10,5-12 V _{DC} via jack

Current consumpt.: < 1 mA (HND-P121...),
max. 3 mA (HND-P231...)
Material: housing made of impact-resistant
ABS plastic
Degree of protect.: IP65, front
Dimensions: 142 x 71 x 26 mm (HxWxD)
Weight: approx. 160 g

Scope of functions:

Minimum/maximum value memory

Hold function: »freezing« of the current value

Automatic-off function: 1...120 min (can be deactivated)

Zero point adjustment via keyboard possible

Tare function:

display, minimum/maximum values are set to zero

Battery change notification

10. Order Codes

Order-no.	Housing design
HND-P123	2 measuring inputs, standard

10.1 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10,5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021	Case with recess (275 x 229 x 83 mm)
HND-Z022	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose 6/4 on hose 6/4
HND-Z082	Hose clamp for hose 6/4
HND-Z083	Adapter made of brass for G ¼ internal threads on hose 6/4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

Additional accessories on request

11. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Hand-held Measuring Devices with Integrated Pressure Sensors
model: HND-P123

to which this declaration relates is in conformity with the standards noted below:

EN 61326+A1+A2 Electromagnetic Compatibility Directive

Also the following EEC guidelines are fulfilled:

93/68/EWG, 2004/108/EG Electromagnetic Compatibility Directive

73/23/EWG, 93/68/EWG Low Voltage Directive


Hofheim, 01. April 2006



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Hand-held Pressure Measuring Devices
with Integrated Pressure Sensors

Model: HND-P126



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Electrical Connection	4
6.1 Mains Operation With Power Supply	4
7. Operation / Configuration / Adjustments	5
7.1 Safety Requirements	5
7.2 Connections.....	5
7.3 Display.....	6
7.4 Basic Operation	6
7.5 Configuration	7
7.6 Error And System Messages	8
7.7 Pressure Connection To The Sensors	8
7.8 Calibration Services	9
7.9 The Serial Interface	9
8. Maintenance	9
8.1 Battery Operation.....	9
9. Technical Information.....	10
10. Order Codes	11
11. Declaration of Conformance	12

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Hand-held Pressure Measuring Devices with Integrated Pressure Sensors
Model: HND-P126
- Operating Instructions

4. Regulation Use

Any use of the Hand-held Pressure Measuring Devices with Integrated Pressure Sensors, model: HND-P126, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The highly precise KOBOLD manual pressure measuring devices HND-P126 are measuring devices with integrated pressure sensors. They have two pressure measurement inputs on the top of the housing, which are connected to the measuring points by means of stable metal connections and plastic hoses that are available as accessories. Numerous measuring ranges in the overpressure and underpressure range are available for various measurement tasks, such as differential pressure measurement. In addition to pressure display, these first-rate, compact, universally applicable measuring units offer additional functions such as minimum/maximum value memory, a hold function, tare function, automatic self-shut-off, or zero point offset. The devices with an expanded spectrum of functions also have a logger function, a peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

6. Electrical Connection

6.1 Mains Operation With Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002.

Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

7. Operation / Configuration / Adjustments

7.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices. However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under Technical Information.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.




Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be a risk if:
 - there is visible damage to the device
 - the device is not working as specified
 - the device has been stored under unsuitable conditions for a longer period of time.


In case of doubt, please return device to manufacturer for repair or maintenance.

7.2 Connections



Connection for pressure tubes: „+“ = higher pressure, „-“ = lower pressure
 Interface:
 Connection for el. isolated interface adapter (p.r.t. chapter 7.9 *The Serial Interface*) The mains adapter socket is located at the left side of the device.

7.3 Display



Units: an arrow points to the chosen measuring unit

SL: no function

Tara: appears if tara-function is activated


main display: shows measuring value

secondary display: shows min-, max- or hold value

Logg: not used

7.4 Basic Operation

When switching on the device and a zero point adjustment was carried out it shows shortly „nuLL Corr“.



On-/Off-Switch

Tara: Calling of tara function, zero point adjustment

min/max: Showing the min- resp. max-memory in sec. display

Store/Quit: Calling of hold function

Set/Menu: Calling of configuration

- Max Memory:** Pressing 'max' (key 2) shows the maximum of the measured values. Pressing it again hides it. To clear the max memory press key 'max' for >2 seconds.
- Min Memory:** Pressing 'min' (key 5) shows the minimum of the measured values. Pressing it again hides it. To clear the min memory press key 'min' for >2 seconds.
- Hold Function:** By pressing 'Store/Quit' (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it.
- Tare Function:** By pressing 'Tara' (key 3) the display will be set to 0. All measurements from then on will be displayed relatively to the set tare value. When tara function is activated, the arrow "Tara" appears in the display. To deactivate tare function press 'Tara' for >2 seconds.



Please Note: Activating/deactivating tara clears the max- & min-memories.

Zero-Point Adjustment: If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press key 3 for approx. 5 seconds. (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu). Please note: A zero-point adjustment can only be carried out if the difference between the value on display is less than 500 digits! To recall the manufacturer's calibration press button 3 for approx. 15 seconds. Note: If a zero-point adjustment was carried out, this will be signaled by the short displaying of "Corr" when switching on the device.

7.5 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu. Pressing key **Menu** jumps between the parameters.

The parameters can be changed with \blacktriangle (key 2) or \blacktriangledown (key 5). **Quit** (key 6) finishes the configuration and returns to standard measuring operation.

7.5.1 Unit: Coice Of The Display Unit



Choose the desired display unit, the referring unit is displayed by means of a functional arrow in the display. The selection is permanently stored in the device, therefore after power on the unit will instantly reappear. The choice depends on the used sensor.

The unit [m] =mH₂O is just supported by devices with [m] printed below the display!

7.5.2 P.oFF: Auto Power Off Time



The device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power off time.

The power off time can be set to values between 1 and 120 min. It can be completely deactivated by setting the paramter to ‚P.oFF = oFF“.

7.5.3 ADr: Base Address of Interface



Up to 10 devices of the HND-P handheld-family can be connected to a serial interface at once (depending on interface converter). To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on.

7.5.4 OFFS: Adjusting Sensor Zero Displacement

A zero displacement can be carried out of the measured value:

$$\text{value displayed} = \text{value measured} - \text{offset}$$

Standard setting: 'off' = 0.0°, i.e. no zero displacement will be carried out. Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations. Input is in the display unit.



7.5.5 SCAL: Adjusting Sensor Scale

The scale of the measuring can be influenced by this setting (factor is in %):

$$\text{displayed value} = \text{measured value} * (1 + \text{Scal}/100)$$

Standard setting: 'off'=0.000, i.e. value is not corrected. Together with the zero displacement (see above) this factor is mainly used to compensate for sensor deviations.

7.6 Error And System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
No display or confused characters, device does not react on keypress	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
Err.1	Device defective	Return to manufacturer for repair
	Measured value above allowable range	Check: pressure above 2000 mbar? -> measuring value to high
Err.2	Sensor defective	Return to manufacturer for repair
	Measured value below allowable range	Check: pressure below -100 mbar? -> measuring value to high
Err.4	Sensor defective	Return to manufacturer for repair
Err.4	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
Err.9	Measured value far out of allowable range	Check: pressure not within sensor range?
Err.7	System error	Return to manufacturer for repair

7.7 Pressure Connection To The Sensors

- **For measurements of over pressure (-100 mbar...2000 mbar):**

Connect plastic tube with internal dia of 4 mm to pressure port "+". Port "-" will not be used!

- **For measurements of under pressure (-2000 mbar...0 mbar):**

Plug the tube to pressure port "-". The measuring range covers then -2000 to 0 mbar.



Note: All values are displayed now as positive values. No minus sign will be shown.

Example: it is possible to measure under pressure down to -2000 mbar, the display shows then the value 2000 (no minus sign).

- **For measurements of pressure differences:**

Connect both plastic tubes with an internal dia of 4 mm to pressure port "+" and "-"; make sure to apply higher pressure to port "+".

7.8 Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certified for its accuracy, it is the best solution to return it with the referring sensors to the manufacturer. Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

7.9 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031) the device can be connected to a computer for data transfer. To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

BUS-SW9M: 9-channel software to display the measuring values




Note: The measuring and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Code	Name/Function	Code	Name/Function
0	Read measurement value	200	Read min display range
3	Read system state	201	Read max display range
6	Read min memory	202	Read display range - unit
7	Read max memory	204	Read display range – decimal point
12	Read ID number	208	Read # of channels
174	Clear min memory	214	Read scale adjustment [%]
175	Clear max memory	216	Read offset adjustment
176	Read min measuring range	222	Read power off time (Conf-P.oFF)
177	Read max measuring range	223	Set power off time (Conf-P.oFF)
178	Read measuring range – measuring unit	240	Reset
179	Read measuring range – decimal point	254	Program version
180	Read kind of measuring of sensor		
199	Read kind of measuring of display		

8. Maintenance

8.1 Battery Operation

If  and 'bAt' are shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.



Please note: We recommend to take out battery if device is not used for a longer period of time!

9. Technical Information

Measuring range:	-100 to 2000 mbar
Accuracy:	±0.2 % F.S. (Hysteresis and linearity) ±0.4 % F.S. (in the range of 0-50 °C)
Resolution:	1 mbar
Units:	mbar, bar, kPa, MPa, PSI, mmHg, mH ₂ O (display "m") (switchable)
Overload:	max. 4 bar rel.
Connection:	2 metal pressure ports for connection to 6x1mm tubes at the top of device (4mm inner tube ø)
Sensor:	piezo-resistive relative pressure sensor, for air or non-corrosive and non-ionising gases and liquids, not for water!
Display:	2 x 4- digit LCDs
Operating temp.:	0 to +50 °C
Storage temp.:	-20 to +70 °C
Storage humidity:	0 to 95 % r.H. (non-condensing)
Output:	serial interface (via 3,5mm jack, to RS232 or USB optional)
Power supply:	9 V-monobloc battery (included in the scope of delivery), extern 10.5-12 V _{DC} via jack
Power consumpt.:	approx. 0,6 mA
Material:	housing made of impact-resistant ABS plastic
Degree of protect.:	IP65, front side
Dimensions:	142 x 71 x 26 mm (LxWxD)
Weight:	approx. 165 g
Scope of functions:	
	Minimum/maximum value memory
	Hold function: »freezing« of the current value
	Automatic-off function: 1...120 min (can be deactivated)
	Zero point adjustment via keyboard possible
	Tare function:
	display, minimum/maximum values are set to zero
	Battery change notification

10. Order Codes

Order-no.	Housing design
HND-P126	2 measuring inputs, standard

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10.5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose 6/4 on hose 6/4
HND-Z082	Hose clamp for hose 6/4
HND-Z088	Adapter made of brass for G 1/2 internal threads on hose 6/4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

*observe instrument dimensions

Additional accessories on request.

11. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Manual Pressure Measuring Devices with External and Integrated Pressure Sensors Model:HND-P126

to which this declaration relates is in conformity with the standards noted below:

EN61326-1:2006 Electrical equipment for measurement, control and laboratory use. EMC requirements

Also the following EC guidelines are fulfilled:


2004/108/EG Electromagnetic Compatibility Directive

2006/95/EC Low Voltage Directive


Hofheim, 8. May 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Hand-held Pressure Measuring Devices
with Integrated Pressure Sensors

Model: HND-P127



1. Contents

1. Contents	2
2. Note	3
3. Instrument Inspection	3
4. Regulation Use	3
5. Operating Principle	4
6. Electrical Connection	4
6.1 Mains Operation with Power Supply	4
7. Operation	4
7.1 General	4
7.2 Configuration	6
7.3 Error and System Messages	8
7.4 Pressure Connection to the Sensors	9
7.5 Calibration Services	9
7.6 The Serial Interface	9
8. Maintenance	10
8.1 Battery Operation	10
9. Technical Information	11
10. Order Codes	12
10.1 Accessories	12
11. Declaration of Conformance	13

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Hand-held Pressure Measuring Devices with integrated Pressure Sensors
model: HND-P-127
- Operating Instructions

4. Regulation Use

Any use of the Hand-held Pressure Measuring Devices with integrated Pressure Sensors, model: HND-P127, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The highly precise KOBOLD hand-held pressure measuring devices HND-P127 are measuring devices with integrated pressure sensors. They have two pressure measurement inputs on the top of the housing, which are connected to the measuring points by means of stable metal connections and plastic hoses that are available as accessories. Numerous measuring ranges in the overpressure and underpressure range are available for various measurement tasks, such as differential pressure measurement. In addition to pressure display, these first-rate, compact, universally applicable measuring units offer additional functions such as minimum/maximum value memory, a hold function, tare function, automatic self-shut-off, or zero point offset. The devices with an expanded spectrum of functions also have a logger function, a peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

6. Electrical Connection

6.1 Mains Operation with Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply over-voltage !! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002. Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage

7. Operation

7.1 General

7.1.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices. However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under 9. Technical Information.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.



Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).


5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting.

Operator safety may be a risk if:

- there is visible damage to the device
- the device is not working as specified
- the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.

7.1.2 Connections



Connection for pressure tubes: „+“ = higher pressure, „-“ = lower pressure

Interface: Connection for el. isolated interface adapter (p.r.t. chapter 7.6 *The Serial Interface*)

The mains adapter socket is located at the left side of the device

7.1.3 Display

Units: an arrow points to the chosen measuring unit

SL: no function

Tara: appears if tara-function is activated



main display:

shows measuring value


secondary display:

shows min-, max- or hold value

Logg: not used

7.1.4 Operating

When **switching on** the device and a zero point adjustment was carried out it shows shortly „nuLL Corr“.



On-/Off-Switch

Tara: Calling of tara function, zero point adjustment

min/max: Showing the min- resp. max-memory in sec. display

Store/Quit: Calling of hold function

Set/Menu: Calling of configuration

Max Memory: Pressing ‘max’ (key 2) shows the maximum of the measured values. Pressing it again hides it. To clear the max-memory press key ‘max’ for >2 seconds.

Min Memory: Pressing ‘min’ (key 5) shows the minimum of the measured values. Pressing it again hides it. To clear the min-memory press key ‘min’ for >2 seconds.

Hold Function: By pressing ‘Store/Quit’ (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it.

Tare Function: By pressing ‘Tara’ (key 3) the display will be set to 0. All measurements from then on will be displayed relatively to the set tare value. When tara function is activated, the arrow "Tara" appears in the display. To deactivate tare function press ‘Tara’ for >2 seconds.



Note: Activating/deactivating tara clears the max- & min-memories.

Zero-Point Adjustment: If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press button 3 for approx. 5 seconds (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration-menu).

Please note: A zero-point adjustment can only be carried out if the difference between the value on display is less than 500 digits!

To recall the manufacturer’s calibration press button 3 for approx. 15 seconds.

Note: If a zero-point adjustment was carried out, this will be signalled by the short displaying of “Corr” when switching the device.

7.2 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu.

Pressing key **Menu** jumps between the parameters.

The parameters can be changed with ▲ (key 2) or ▼ (key 5).

Quit (key 6) finishes the configuration and returns to standard measuring operation.

7.2.1 Unit: Choice Of The Display Unit



Choose the desired display unit, the referring unit is displayed by means of a functional arrow in the display. The selection is permanently stored in the device, therefore after power on the unit will instantly reappear. The choice depends on the used sensor.

The unit [m] =mH₂O is just supported by devices with [m] printed below the display!

7.2.2 P.oFF: Auto Power Off Time

The
The



device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power off time.

power off time can be set to values between 1 and 120 min. It can be completely deactivated by setting the parameter to ,P.oFF = oFF“.

7.2.3 Adr: Base Address of Interface



Up to 10 devices of the HND- handheld-family can be connected to a serial interface at once (depending on interface converter, e.g. HND-Z031: 5 devices). To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on.

7.2.4 OFFS: Adjusting Sensor Zero Displacement

A zero displacement can be carried out for the measured value:

$$\text{value displayed} = \text{value measured} - \text{offset}$$

Standard setting: 'off' = 0.0°, i.e. no zero displacement will be carried out. Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations. Input is in the display unit.



7.2.5 SCAL: Adjusting Sensor Scale

The scale of the measuring can be influenced by this setting (factor is in %):

$$\text{displayed value} = \text{measured value} * (1 + \text{Scal}/100)$$

Standard setting: 'off' = 0.000, i.e. value is not corrected. Together with the zero displacement (see above) this factor is mainly used to compensate for sensor deviations.

7.3 Error and System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
Err.1	Measured value above allowable range	Check: pressure above 420 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.2	Measured value below allowable range	Check: pressure below -10 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.4	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
Err.9	Measured value far out of allowable range	Check: pressure not within sensor range?
Err.7	System error	Return to manufacturer for repair

7.4 Pressure Connection to the Sensors

- **For measurements of over pressure (-10.0 mbar...420.0 mbar):**
Connect plastic tube with internal diameter of 4 mm to pressure port "+".
Port "-" will not be used!
- **For measurements of under pressure (-420.0 mbar...0.0 mbar):**
Plug the tube to pressure port "-". The measuring range covers then -420.0 to 0.0 mbar.



Note: All values are displayed now as positive values. No minus sign will be shown.

Example: It is possible to measure under pressure down to -420.0 mbar, the display shows then the value 420.0 (no minus sign).

- **For measurements of pressure differences:**
Connect both plastic tubes with an internal diameter of 4 mm to pressure port "+" and "-"; make sure to apply higher pressure to port "+".

7.5 Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certified for its accuracy, it is the best solution to return it with the referring sensors to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

7.6 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031) the device can be connected to a computer for data transfer. To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

- **BUS-SW9M:** 9-channel software to display the measuring values




Note: The measuring and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Code	Name/Function	Code	Name/Function
0	Read measurement value	199	Read kind of measuring of display
3	Read system state	200	Read min display range
6	Read min memory	201	Read max display range
7	Read max memory	202	Read display range - unit
12	Read ID number	204	Read display range – decimal point
174	Clear min memory	208	Read # of channels
175	Clear max memory	214	Read scale adjustment [%]
176	Read min measuring range	216	Read offset adjustment
177	Read max measuring range	222	Read power off time (Conf-P.oFF)
178	Read measuring range – measuring unit	223	Set power off time (Conf-P.oFF)
179	Read measuring range – decimal point	240	Reset
180	Read kind of measuring of sensor	254	Program version
194	Set display unit		

8. Maintenance

8.1 Battery Operation

If  and 'bAt' are shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.



Note: We recommend to take out the battery if device is not used for a longer period of time!

9. Technical Information

Measuring ranges:

Display range: -10.0 to 420.0 mbar rel.
 Overload: max. 1 bar
 Resolution: 0.1 mbar
 Pressure units: mbar, bar, kPa, MPa, PSI, mmHg,
 mH₂O (display "m")
 (switchable)

Accuracy: ±0.1 % f.s.
 (Hysteresis and linearity)
 ±0.4 % f.s.
 (in the range of 0-50 °C)

Measuring rate: 4 meas./sec

Nominal temperature: 25°C

Sensor: **piezo-resistive relative pressure sensor, for air or non-corrosive and non-ionising gases and liquids, not for water!**


Connection: 2 metal pressure ports for connection to 6x1mm tubes at the top of device (4mm inner tube ø)

Power-Off-Function: Device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power-off delay. The power-off delay can be set to values between 1 and 120 min.; it can be completely deactivated.

Display: 2 four digit LCDs

Pushbuttons: 6 membrane keys

Interface: Serial interface (3,5mm jack) can be connected to RS232 or USB interface of a PC via electrically isolated interface adapter (see accessories).

Power supply: 9 V battery
 (included in the scope of delivery),
 external 10.5-12 V_{DC} via jack 

Power consumption: approx. 0,6mA

Low battery warning: 'bAt'

Housing: impact-resistant ABS, membrane keyboard, transparent panel, Front side IP65

Weight: approx. 165g

Working temperature: -20...+50 °C

Allowable rel. humidity: 0...95% RH (not condensing)

Storage temperature: -20...+70°C

Scope of functions:

Minimum/maximum value memory

Hold function: »memorising« of the current value

Tare function:

display, minimum/maximum values are set to zero

Battery change notification

10. Order Codes

Order-no.	Housing design
HND-P127	2 measuring inputs, greater sensor accuracy, standard

10.1 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10.5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose 6/4 on hose 6/4
HND-Z082	Hose clamp for hose 6/4
HND-Z088	Adapter made of brass for G 1/2 internal threads on hose 6/4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

*Observe instrument dimensions

11. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Manual Pressure Measuring Devices with External and Integrated Pressure Sensors Model: HND.P127

to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and laboratory use. EMC requirements

Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline


Hofheim, 8. May 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Hand-held Pressure Measuring Devices
for External Pressure Sensors

Model: HND-P210



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Electrical Connection	4
7. Operation	5
7.1 Safety Requirements	5
8. Start of Operation.....	6
8.1 Connections.....	6
8.2 Display.....	6
8.3 Basic Operation	6
8.4 Configuration	7
8.5 Measuring Of Water Level – Display Unit [m]	11
8.6 Operation Of Logger	11
8.7 The Serial Interface	14
8.8 Pressure Connection To The Sensors.....	15
8.9 Error And System Messages	16
8.10 Calibration Services.....	16
9. Maintenance	17
9.1 Battery Operation.....	17
10. Technical Information.....	17
11. Order Codes	19
11.1 Pressure sensors.....	19
11.2 Accessories	20
12. Declaration of Conformance	21

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Hand-held Pressure Measuring Devices for External Pressure Sensors
Model: HND-P210
- Operating Instructions

4. Regulation Use

Any use of the Manual Pressure Measuring Devices with External Pressure Sensors, model: HND-P210, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The KOBOLD manual pressure measuring devices HND-P210 are highly precise, compact pressure measuring devices that can be used universally. In conjunction with the appropriate external pressure sensors, precise measurement results over the entire measuring range can be achieved.

Various pressure sensors are available for a multitude of measuring tasks and special applications. The respective measurement task determines which combination is selected. Naturally, these first-rate KOBOLD-measuring units can display more than just pressure. All devices in this series allow for minimum/maximum value memory, hold function, automatic self-shut-off, or zero point offset entry for all connected pressure sensors, for example. The HND-P210 types also have a logger function, a peak value memory, or a minimum/maximum alarm.

6. Electrical Connection

Mains Operation With Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002.

Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

Connecting/Changing Sensors

Do not use insuitable sensors. Connecting other devices/sensors as specified may cause a damage to the instrument and device/sensor! Switch off device before changing the sensor. Connect sensor before switching on the device, otherwise the sensor may not be detected correctly. When connecting the sensor the connector may not lock correctly. In such case take the plug not at the casing but at the buckling protection at the end of the plug. If plug is entered correctly, it will slide in smoothly. To disconnect sensor do not pull at the cable but at the plug (to open locking mechanism).

7. Operation

7.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices. However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated see chapter 10 *Technical Information*.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.




Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be a risk if:
 - there is visible damage to the device
 - the device is not working as specified
 - the device has been stored under unsuitable conditions for a longer period of time.


In case of doubt, please return device to manufacturer for repair or maintenance.

8. Start of Operation

8.1 Connections




8.2 Display



8.3 Basic Operation

When switching on the device and the logger function is not off the time of the integrated clock will shortly be displayed. Furthermore the kind of measuring is displayed (Slc/Fast/P.det, p.r.t 2.1) and "Corr", if a Sensor with activated offset or scale correction is connected.

After changing the battery the clock-setting menu is activated automatically (,CLOC'). Check the clock and adjust, if necessary (see chapter 8.4 Configuration).



Tare Function: By pressing 'Tara' (key 3) the display will be set to 0. All measurements from then on will be displayed relatively to the set tare value. When tara function is activated, the arrow "Tara" appears in the display. To deactivate tare function press 'Tara' for >2 seconds.



Please Note: Activating/deactivating tara clears the max- & min-memories.

- Max Memory:** Pressing 'max' (key 2) shows the maximum of the measured values. Pressing it again hides them. To clear the max memory press key 'max' for >2 seconds.
- Min Memory:** Pressing 'min' (key 5) shows the minimum of the measured values. Pressing it again hides them. To clear the min memory press key 'min' for >2 seconds.
- Hold Function:** By pressing 'Store/Quit' (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it. (only when logger = ,off').
- Zero-Point Adjustment:** If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out.
To carry out the adjustment press button 3 for approx. 5 seconds. (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu).
Note: A zero-point adjustment can only be carried out if the difference between the value on display is less than 500 digits!
To recall the manufacturer's calibration press button 3 for approx. 15 seconds.



Note: If a zero-point adjustment was carried out, this will be signalled by the short displaying of „Corr“ when switching on the device.

8.4 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu (main display: „SEt“).

Pressing key **Menu** changes between the menus, pressing **▶** (key 3) jumps to the referring parameters, which can be selected with key **▶** (key 3).

The parameters can be changed with **▲** (key 2) or **▼** (key 5).

Pressing **Menu** again jumps back to the main configuration menu and saves the settings.

Quit (key 6) finishes the configuration and returns to standard measuring operation.

HND-P210

Menu	Param.	Values	Meaning	
,Menu'	▶	▲ or ▼		
SEt ConF	Set Configuration: Generic Configurations			
	Unit	mbar, bar..	Unit: Unit of display	*
	SL	oFF/on	Sea level correction: on or off	*
	Alti	-2000..9999	Altitude: Input of altitude above sea level [m] (only if SL on)	*
	rAtE		Rate: Measuring rate (p.r.t. chapter 8.4.1)	*
		Slo	Slow measuring rate (4 Hz filtered, low power consumption)	*
		FASt	Fast measuring rate, filtered (>1000 Hz)	*
	t.AVG	P.dEt	Peak detection: fast measuring rate, unfiltered (>1000 Hz)	*
		1-120	Averaging period in seconds, used by the averaging function	
	P.oFF	oFF	Averaging function deactivated	
		1-120	Auto Power Off time in minutes	
	Out	oFF	Auto Power Off deactivated	
		oFF	Function of the output: No output function, lowest power consumption	
		Ser	Output is serial interface	
	dAC	Output is analogue output 0..1 V		
Adr.	01, 11..91	Base address of interface (if Out = SEr)		
dAC.0	eg. -5.00.. 5.00 mbar	Enter desired value which the analogue output potential should be 0 V (if Out = dAC)		
dAC.1	eg. -5.00.. 5.00 mbar	Enter desired value at which the analogue output potential should be 1 V (if Out = dAC)		
Set CAL	Set Calibration: Adjustment of Sensor			
	OFFS	Sensordep., e.g. - 5.00..5.00 mbar	The offset of sensor will be displaced by this value to compensate for deviations in the probe or in the measuring device.	
		oFF	Zero	
	SCAL	-2.000... 2.000	The measuring scale of sensor will be changed by this factor [%] to compensate deviations of temperature probe or measuring device.	
oFF		Scale correction factor inactive (=0.000)		
SEt AL.	Set Alarm: Settings Of Alarm Function			
	AL.	On	Alarm on, with horn-sound	
		no.So	Alarm on, without horn-sound	
		oFF	no alarm function	
	AL.Lo	Sensor-Min ... AL.Hi	Min alarm rail (not when AL. oFF, Sensor-Min is the lower display range of connected sensor)	
AL.Hi	AL.Lo ... Sensor-Max	Max alarm rail (not when AL. oFF, Sensor-Max is the upper display range of connected sensor)		
SEt LoGG	Set Logger: Configuration Of Logger Function			
	Func	CYCL	Cyclic: logger function ,cyclic logger'	*
		Stor	Store: logger function ,individual value logger'	*
		oFF	no logger function	*
	CYCL	1..3600	Cycle time of cyclic logger [seconds]	*
Lo.Po	on/oFF	Low-power logger with very low power consumption only for cyclic logger and slow measuring rate)	*	
SEt	Set Clock: Setting Of Real Time Clock			

CLOC	CLOC	HH:MM	Clock: Setting of time hours:minutes	
	dAtE	TT.MM	Date: day.month	
	YEAr	YYYY	Year	



Note: If the logger memory contains data already, the menus/parameters marked with (*) can not be invoked! If these should be altered the logger memory has to be cleared before! (key 6, see chapter 8.6 Operation Of Logger)

8.4.1 Different Kinds of Measuring: “rAtE-Slo, -P.dEt, -FASt”

Three different kinds of measuring pressure are supported. Two of them (P.dEt and FASt) are working with high measuring frequency of more than 1000 measurings per second.

8.4.1.1 rAtE-Slo: Standard Measuring

Measuring rate 4Hz, averaging and filter functions are active.

Application: Measuring of slowly changing or static pressures, eg. measuring of leakproofness, atmospheric pressure...

Highest accuracy, high noise immunity (EMI and unstable measuring signals), low power consumption.

8.4.1.2 rAtE-P.dEt: Peak detection

Measuring rate >1000Hz, the value is displayed unfiltered.

Application with logger function: Measuring of short pressure peaks or fast changing pressures with a resolution of <1ms. The cyclic logger function records the arithmetic mean value, the highest and the lowest peak of the referring time interval.

Attention: higher power consumption, measuring is sensitive to noise (EMI,..)

8.4.1.3 rAtE-FASt: Fast filtered measuring

Measuring rate >1000Hz, the value is filtered slightly (higher noise immunity than P.dEt., small peaks will be filtered out), apart from that identical behaviour like P.dEt.

8.4.2 Averaging Function

The averaging function concerns the display values (LCD and interface). It is completely independent from the averaging of the logger function, please don't mix them up!

The averaging integrates the measuring values during a selectable period of time and then calculates the average display value. It is independent from the selected kind of measuring (slow, fast, peak detect). As long as not enough values are collected (selected averaging time) to calculate a average value, the upper display shows “----“, the lower display a ‘countdown‘.

During an active low-power-logging procedure the averring is always deactivated
Function of min/max-value memory during averaging:

- If averaging is activated and slow measuring is selected (rAtE-Slo), the min-/max-value memory refers to the average display value.

- If averaging is activated and fast measuring is selected (rAtE-FASt or P.dEt) , the min-/max-value memory refers to the internal measured values (fast peaks can be detected).

8.4.3 Power Off Time

If there won't be pressed any key and no interface communication takes place for the time of the power off time setting (P.Off), the device will be switched off automatically to save battery power.

If P.oFF = oFF then the automatic switch off is deactivated.

8.4.4 Address

Up to 10 devices of the HND-P- handheld-family can be connected to a serial interface at once (depending on interface converter). To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on. See also chapter 8.7 *The Serial Interface*.

8.4.5 Alarm

There are three possible settings: Alarm off (AL. oFF), on with horn sound (AL. on), on without sound (AL. no.So).

Following conditions will display an alarm, when the function is activated (on or no.So):

- Value is below lower (AL. Lo) or above upper alarm rail (AL.Hi).
- Sensor error (Sens Erro)
- Low battery (bAt)
- Fe 7: System error (always with sound)

In case of an alarm and when polling the interface the prio-flag is set in the returned interface message.

8.4.6 Real Time Clock

The real time clock is used for the logger function: Recorded values are also containing the point of time, when they were measured. Please check the settings when necessary.

If the battery was replaced the referring menu ,CLOC' will automatically be started.

8.5 Measuring Of Water Level – Display Unit [m]

(only for devices with ,m' printed below the display)

When using a suitable waterproof pressure sensor the unit [m] for meters of water can be set in the menu "Unit". 10 m of water are roughly 1 bar over pressure. Measurements can be made e.g. like described below :

- With abs. pressure sensor (SL OFF!): Press ,Tara' when sensor is at ambient air and then bring sensor to the depth to be measured. The display shows now the depth in [m].
- With rel pressure sensor: bring tube connection for lower press. in contact to ambient air by means of a tube (no water contact!) and bring the sensor with its open press. connection for higher pressure to water depth to be measured (display and is compensated for pressure changes in ambient air).

8.6 Operation Of Logger

The device supports two different logger functions:

„**Func-Stor**“: each time when „store“ (key 6) is pressed a measurement will be recorded.

„**Func-CYCL**“: measurements will automatically be recorded each interval, which was set in the logger menu ,CYCL' until the logger will be stopped or the logger memory is full. The recording is started by pressing „Store“ 2 seconds.

The logger records 3 measurement results each time:

current or mean value (depending on logger setting, see below), min peak and max peak of sensor

Min and max peak are the minimum resp. the maximum of the measured values since the last recording. Using them allows f.e. analysis of fluctuating pressures. For the evaluation of the data the software HND-Z034 has to be used. The software also allows easy configuration and starting of the logger. When the logger is activated (Func Stor or Func CYCL) the hold function is no more available, the key 6 is solely used for the operation of the logger functions.

8.6.1 „Func-Stor“: Storing Single Measurements

Each time when „store“ (key 6) is pressed a measurement and its time stamp will be recorded.

The recorded data can be viewed either in the display (when calling the configuration an additional menu „REAd LoGG“ is displayed, see below) or by means of the interface and a PC with HND-Z034-software.

Please note: For the Func-Stor-logging function it is not allowed to change the pressure sensor after values are stored, otherwise invalid data could be read out. For the read out of the logger the sensor has to be kept connected!

Max. number of measurements: 99

A measuring contains:

- current measuring value at the time of recording
- min peak, max peak since the last recording
- max peak since the last recording

- time and date of the recording

After each recording „St. XX“ will be displayed for a short time. XX represents the number of the recording.

If logger memory contains recordings already:

When „Store“ is pressed for 2 seconds, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording



Clear nothing (cancel menu)

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.



If the logger memory is full, the display will show:

Viewing Recorded Measurements

Within the „LoGG Stor“ function the measurements can be viewed directly in the display not only by means of a computer (like at „Func CYCL“): press 2 seconds „Set“ (key 4): The first menu displayed now is „rEAd LoGG“ (read logger data). After pressing ▶ (key 3) the measurement recorded last will be displayed, changing between the different values referring to the measurement also is done by pressing ▶.

Changing the measurement is done by pressing the keys ▲ or ▼.

8.6.2 „Func-CYCL“: Automatic Recording With Selectable Logger-Cycle-Time

The Logger-Cycle-Time is settable (p.r.t. Configuration). For example „CYCL“ = 60: A measuring is recorded after each 60 seconds.

When the slow measurement "rAtE-Slo" is chosen, additionally a low power function is available: „Lo.Po“.

If „Lo.Po“ is on, the device only will take a measurement at the point of time of the recording. In between the recordings the measuring shut's down. This decreases the power consumption enormously and therefore is recommended e.g. for long time recordings where no mains adapter is available.

Max. number of measurements: 10000

Cycle time: 1...3600 seconds (=1h), selectable in the configuration


A measuring contains:

- rAtE SLo: - current measuring value at the time of recording
 - min peak, max peak since the last recording
- rAtE FASt,P.dEt - arithmetic mean value since the last recording
 - min peak, max peak since the last recording

Starting a recording:

By pressing "Store" (key 6) for 2 seconds the recording will be initiated. After that the display shows 'St.XXXX' for a short time whenever a measuring is recorded. XXXX is the number of the measuring 1..10000.



If the logger memory is full, the display will show:  The recording automatically will be stopped.

If Low-Power-Logger-Function „Lo.Po = on“ the device switches itself off as soon as the memory gets filled.

Stopping the recording manually:

By pressing "Store" (key 6) the recording can be stopped manually. Then the following choice appears:



Stop the recording



Do not stop the recording


The selection can be made by \blacktriangle (key 2) and \blacktriangledown (key 5). "Quit" (key 6) enters the choice.



Note: If you try to switch off the instrument in the cyclic recording operation You will be asked once again if the recording is to be stopped. The device can only be switched off after the recording has been stopped! The Auto-Power-Off-function is deactivated during recording!

Clear Recordings:

By pressing „Store“ (key 6) for 2 seconds the logger operation will be called.

The display will show  By pressing the keys \blacktriangle (key 2) or \blacktriangledown (key 5)

the display will change to



When "Store" is pressed, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording sequence



Clear nothing (cancel menu)

The selection can be made by \blacktriangle (key 2) and \blacktriangledown (key 5). "Quit" (key 6) enters the choice.

8.7 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031/-032) the device can be connected to a computer for data transfer. To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

- **HND-Z034:** Operation and read out of logger function, data display in diagrams and tables
- **BUS-SW9M:** 9-channel software to display the measuring values

The device has 3 channels:

- 1: current measuring value (base address)
- 2: min peak (see chapter 8.6 *Operation Of Logger*)
- 3: max peak (see chapter 8.6 *Operation Of Logger*)



Note: The measuring-/ alarm- and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Channel	Code	Name/Function	Channel	Code	Name/Function	
1	2, 3		1	2, 3		
x	x	0	x	208	Read # of channels	
x	x	3	x	222	Read power off time (Conf-P.oFF)	
x		12	x	223	Set power off time (Conf-P.oFF)	
x		22	x	x	224	Logger: Read data of CYCL- Logger
x		23	x		225	Logger: Read cycle time (LoGG - CYCL)
x		32	x		226	Logger: set cycle time (LoGG - CYCL)
x		160	x		227	Logger: start recording
x	x	176	x		228	Logger: Read # of recordings made
x	x	177	x		229	Logger: Read state
x	x	178	x		231	Logger: Read stop time
x	x	179	x		233	Read real time clock (CLOC)
x	x	180	x		234	Set real time clock (CLOC)
			x		236	Read logger memory size
x	x	199	x		237	Read logger filecount
x	x	200	x		238	Read logger filepointer
x	x	201	x		239	Read logger file info
x	x	202	x		240	Reset
x	x	204	x		254	Program version
			x		260	Logger: read data of STOR Logger
			x	x	263	Read logger channel info

8.8 Pressure Connection To The Sensors

The device is designed to be connected to the sensors of the HND-PS...-series without a new calibration being necessary. Therefore a great variety of replaceable sensors of e.g. -1.999...2.500 mbar relative up to 0...400.0 bar absolute pressure can be connected to the device (p.r.t. chapter 11 order codes)

Relative Pressure Sensors

- **For measurements of over- or under pressure:**

Connect plastic tube with internal dia of 4 mm to pressure port "B". Port "A" will not be used! Pressure sensors HND-PS01/-PS02/-PS03 allow for measurements of under pressure up to the entire over pressure measuring range by re-plugging the tube to pressure port "A". Please note that all values are displayed as positive values. No minus sign will be shown. (Example for HND-PS02: For tube connection "B" the measuring range covers -19.99 to 25.00 mbar. If you replug to port "A" under pressure measurements down to -25.00 mbar could be carried out with the display showing the value 25.00 (no minus sign).

- **For measurements of pressure differences:**

Connect both plastic tubes with an internal dia of 4 mm to pressure port "B" and "A"; make sure to apply higher pressure to port "B".




Absolute pressure sensors:

Connect plastic tube with an internal dia of 4 mm to pressure port "A". (Port "B" is not used.)

Stainless steel pressure sensors:

For measurements of over-, under- or absolute pressure screw sensor to G1/4" pressure terminal or plug plastic tube to a suitable adapter.

8.9 Error And System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
 or <i>Err.9</i>	No sensor connected	Switch off device and connect sensor
	Connected sensor or device defective	If second sensor available, check if device is ok. Return defective device/sensor to manufacturer for repair
	Value extremely out of measuring range	Check: pressure not within sensor range?
No display or confused characters, device does not react on keypress	Battery empty	
	Mains operation: wrong	
<i>Err.1</i>	Measured value above allowable range	Check: pressure not within sensor range? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
<i>Err.2</i>	Measured value below allowable range	Check: pressure not within sensor range? -> measuring value to low
	Sensor defective	Return to manufacturer for repair
<i>Err.3</i>	Display range overflow	Check: value above 19999->to high to be displayed
<i>Err.4</i>	Display range underflow	Check: value below -19999 (Tara?) ->to low!
<i>Err.11</i>	Value could not be calculated	Choose different unit
	Calculation overflow happened	Choose different unit
<i>Err.7</i>	System error	Return to manufacturer for repair
----	Sensor not present/recognised	Reconnect sensor, during logging: stop the logger and restart it
	Could not calculate value	Suitable sensor/unit combination necessary

8.10 Calibration Services


Calibration certificates – DKD-certificates – other certificates:

If device should be certificated for its accuracy, it is the best solution to return it with the referring sensors to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

9. Maintenance

9.1 Battery Operation

If  and 'bAt' are shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.

The battery has to be taken out, when storing device above 50 °C.



Please note: We recommend to take out battery if device is not used for a longer period of time!

10. Technical Information

Measuring ranges:

Display range:	max. -19999...19999 digit, depending on connected sensor
Resolution:	depending on connected sensor
Pressure units:	mbar, bar, kPa, MPa, mmHg, PSI, mH ₂ O Selectable depending on connected sensor
Accuracy: (typ.)	± 0.1 % F.S. (at nominal temperature) (FASt and P.dET: ±0,5%FS)
Measuring rate:	slow: 4 meas./sec (ConF-Rate=slow) fast: >1000 meas./sec (ConF-Rate=FASt and P.dEt)
Nominal temperature:	25 °C

Sensor:

Connection:	All sensors of the HND-Ps...-series without recalibration can be connected Mini-DIN-Socket with locking mechanism The sensor will automatically be detected, the measurement range settings are set referring to sensor data
-------------	--

Additional functions:

Power-Off-Function:	Device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power-off delay. The power-off delay can be set to values between 1 and 120 min.; it can be completely deactivated.
Min/Max-Alarm:	The measuring values can be monitored constantly for the min. and max. rails set Alarming is done by integrated horn, display and interface
Real time clock:	Integrated clock with date and year
Logger:	2 Functions: individual value logger ("Func-Stor")

HND-P210

Memory:	and cyclic logger ("Func-CYCL")
Cycle time CYCL:	Stor: 99 data sets; CYCL: 10000 data sets 1...3600 seconds (=1h)
Display:	2 four digit LCDs (12.4mm high and 7mm high) for measuring values, and for min/max memories, hold function, etc. as well as additional functional arrows.
Pushbuttons:	6 membrane keys
Interface:	Serial interface (3.5mm jack) can be connected to RS232 or USB interface of a PC via electrically isolated interface adapter HND-Z031, or HND- Z032 (see accessories)
Power supply:	9V battery, type: IEC 6F22 (included in scope of supply) as well as additional d.c. connector (diameter of internal pin 1.9mm) for external 10.5-12V direct voltage supply.
Power consumption:	Slow measuring rate: <1.6mA Fast measuring rate: <7.0mA Low-Power-Logger: <0.3mA (for cycle time >30s, without interface communication active and no alarm horn sounding) up to 0.8mA (at cycle time 1s)
Housing:	impact-resistant ABS, membrane keyboard, transparent panel, Front side IP 65
Dimensions:	142x71x26mm (LxWxD)
Working conditions:	-25...+50°C, 0...95%RH (non-condensing)
Storage temperature:	-25...+70°C
EMC:	The device corresponds to the essential protection ratings established in the Regulations of the Council for the Approximation of Legislation for the member countries regarding electromagnetic compatibility (2004/108/EG) Additional fault: <1%

Scope of functions

Minimum/maximum value memory

Hold function: »freezing« of the current value

Automatic-off function: 1...120 min (can be deactivated)

Zero point adjustment for connected sensor



Tare function:

display-, minimum/maximum values are set to zero

11. Order Codes

Order-no.	Housing design
HND-P210	1 x pressure sensor input with additional functions

11.1 Pressure sensors

Measuring range	Accuracy	Resolution	Overload	Working temperature	Connection	Order-no.
-1,999...2,500 mbar	$\pm 0,2\%$ ME / $\pm 1,0\%$ ME*	0,001 mbar	max. 200 mbar	0...+50 °C	Nylon-spigot for hose 6 x 1 mm 	HND-PS01**
-19,99...25 mbar	$\pm 0,2\%$ ME/ $\pm 0,5\%$ ME*	0,01 mbar	max. 300 mbar			HND-PS02**
-199,9...350,0 mbar	$\pm 0,2\%$ ME/ $\pm 0,4\%$ ME*	0,1 mbar	max. 1 bar			HND-PS03**
-1000...2000 mbar		1 mbar	max. 4 bar			HND-PS04**
-1...10 bar		10 mbar	max. 10,34 bar			HND-PS05**
0...1300 mbar abs.		1 mbar	max. 4 bar abs.			HND-PS06**
0...2000 mbar abs.		10 mbar	max. 10 bar abs.			HND-PS07**
0...7,00 bar abs.		0,1 mbar	max. 2 bar rel.			0...+70 °C
0...400,0 mbar rel.	1 mbar	max. 5 bar rel.	HND-PS20			
0...1000 mbar rel.		max. 10 bar rel.	HND-PS21			
0...2500 mbar rel.		max. 17 bar rel.	HND-PS22			
0...4000 mbar rel.	10 mbar	max. 35 bar rel.	HND-PS23			
0...6000 mbar rel..		max. 50 bar rel.	HND-PS24			
0...10 bar rel.		max. 80 bar rel.	HND-PS25			
0...25 bar rel.	0,1 bar	max. 120 bar rel.	HND-PS26			
0...40,0 bar rel.		max. 200 bar rel.	HND-PS27			
0...60 bar rel.		max. 320 bar rel.	HND-PS28			
0...100 bar rel.	10 mbar	max. 500 bar rel.	HND-PS29			
0...160 bar rel.		max. 800 bar rel.	HND-PS30			
0...250 bar rel.		max. 1200 bar rel.	HND-PS31			
0...400 bar rel.	0,1 bar	max. 800 bar rel.	HND-PS32			
0...600 bar rel.	1 bar	max. 1500 bar rel.	HND-PS33			
0...1000 mbar abs	$\pm 0,2\%$ ME / $\pm 0,4\%$ ME*	1 mbar	max. 5 bar abs	0...+70°C	External threads G 1/2 	HND-PA20
0...2500 mbar abs			max. 10 bar abs			HND-PA21
0...4000 mbar abs			max. 17 bar abs			HND-PA22
0...6000 mbar abs			max. 35 bar abs			HND-PA23

* in the range from 0 to +50 °C

** Pressure sensors HND-PS01 up to HND-PS08 are only suitable for air and non-corrosive/non-ionizing gases and liquids.

11.2 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10.5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose 6.4 on hose 6.4
HND-Z082	Hose clamp for hose 6.4
HND-Z088	Adapter made of brass for G 1.4 internal threads on hose 6.4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

*Pay attention to instrument dimensions

Additional accessories on request

12. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Hand-held Pressure Measuring Devices with External Pressure Sensors
Model: HND-P210

to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and laboratory use. EMC requirements

Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline


Hofheim, 8. Mai 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Manual Pressure Measuring Devices with
External and Integrated Pressure
Sensors

Model: HND-P215



1. Contents

1. Contents	2
2. Note	3
3. Instrument Inspection	3
4. Regulation Use	3
5. Operating Principle	4
6. Electrical Connection	4
6.1 Mains Operation with Power Supply	4
7. Operation / Configuration / Adjustments	5
7.1 General	5
7.2 Connections	5
7.3 Pop-up clip	6
7.4 Display	7
7.5 Basic Operation	7
7.6 Operation	8
7.7 Configuration	8
7.8 Operation Of Logger	12
8. Output	15
8.1 The Serial Interface	15
8.2 Analogue Output – Scaling with DAC.0 and DAC.1	17
8.3 Instrument Adjustment	17
8.4 Pressure Connection to the Sensors	18
8.5 Relative Pressure Sensors (Types: HND-PS01...-PS05, HND-PS09)	18
8.6 Error and System Messages	19
8.7 Calibration Services	20
9. Maintenance	20
9.1 Battery Operation	20
10. Technical Information	21
11. Order Codes	22
11.1 Pressure sensors	22
11.2 Accessories	23
12. Declaration of Conformance	24

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfill the EG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Manual Pressure Measuring Devices with External and Integrated Pressure Sensors model: HND-P215
- Operating Instructions

4. Regulation Use

Any use of the Manual Pressure Measuring Devices with External and Integrated Pressure Sensors, model: HND-P215, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The KOBOLD manual pressure measuring devices HND-P215 are highly precise, compact pressure measuring devices that can be used universally. In conjunction with the appropriate external pressure sensors, precise measurement results over the entire measuring range can be achieved.

Various pressure sensors are available for a multitude of measuring tasks and special applications. The respective measurement task determines which combination is selected. Naturally, these first-rate KOBOLD-measuring units can display more than just pressure. All devices in this series allow for minimum/maximum value memory, hold function, automatic self-shut-off, or zero point offset entry for all connected pressure sensors, for example. The HND-P215 type also has a logger function, a peak value memory, or a minimum/maximum alarm. A special characteristic of the type HND-P215 is the possibility of connecting two external pressure sensors.

6. Electrical Connection

6.1 Mains Operation with Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002. Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

7. Operation / Configuration / Adjustments

7.1 General

7.1.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices. However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under *10 Technical Information*.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. When connecting the device to other devices the connection has to be designed most thoroughly as internal connections in third-party devices (e.g. connection GND with protective earth) may lead to undesired voltage potentials that can lead to malfunctions or destroying of the device and the connected devices.



Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).


5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting.

Operator safety may be a risk if:

- there is visible damage to the device
- the device is not working as specified
- the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.

7.2 Connections




The mains adapter socket is located at the left side of the device.

7.3 Pop-up clip


Handling:

- Pull at label “open” in order to swing open the pop-up clip.
- Pull at label “open” again to swing open the pop-up clip further.




Function:

- The device with a closed pop-up clip can be plainly laid onto a table or attached to a belt, etc.
- The device with pop-up clip at position 90° can be set up on a table, etc.
- The device with pop-up clip at position 180° can be suspended from a screw or the magnetic holder.



7.4 Display



- 1 **Main display:** measuring value of sensor 1
- 2 Arrow points to the chosen measuring unit
- 3 **Secondary display:** measuring value of sensor 2 or difference sensor 1 – sensor 2
- 4 **SL:** appears if sea-level-correction is activated
- 5 **Tara:** appears if tara-function is activated
- 6 **Logg:** appears if logger function is chosen, flashes while logger is running

7.5 Basic Operation



On / Off



min/max bei Messung:

+

press short: shows the min./max. value



press again: hides min./max. value

press 2 sec.: clears particular value

Tara, zero-point adjustment:

press short: display will be set to 0



The following measuring will be relatively displayed to the set tara value

press 2 sec.: deactivates tara-function

press 5 sec.: Zero-Point Adjustment¹⁾

Set/Menu:



press short: Choose secondary display: **Sensor 2** or **difference sensor 1 – sensor 2** or calling of configuration

Store/Quit:



press short: hold-function, the last measuring value will be held in the secondary display.

press again: hides the value


at active logger: invokes logger functions

Please Note: Activating/deactivating tara clears the max- & min-memories.

¹⁾ **Zero-Point Adjustment:** If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press button 3 for approx. 5 seconds (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu).

To recall the manufacturer's calibration press button 3 for approx. 15 seconds.
Please note: - A zero-point adjustment can only be carried out if the difference between the values on display is less than 500 digits!
 - If a zero point adjustment was carried out the display shows "Corr" after a restart .

7.6 Operation

Connect sensor, turn on device via  key.



After segment test the device displays some configuration:
 If the logger function is not off the time of the integrated clock will shortly be displayed.

If a zero point adjustment was carried out the display shows shortly „nuLL Corr“.
 After changing the battery the clock-setting menu is activated automatically (,CLOC‘). Check the clock and adjust, if necessary (p.r.t. chapter 7.7). After that the device is ready for measuring.

7.7 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will activate the configuration menu (main display: „SEt“).

Pressing key **Menu** changes between the menus, pressing **▶** (key 3) jumps to the referring parameters, which can be selected with key **▶** (key 3).

The parameters can be changed with **▲** (key 2) or **▼** (key 5).

Pressing **Menu** again jumps back to the main configuration menu and saves the settings.

Quit (key 6) finishes the configuration and returns to standard measuring operation.

Menu	Parameter	Values	Meaning	
KEY Menu	KEY ▶	KEY ▲ or ▼		
SEt ConF	Set Configuration: Generic Configurations			
	Unit	mbar, bar..	Unit: Unit of display (given by sensor 1 when using 2 sensors)	*, **
	SL	oFF/on	Sea level correction: on or off (only for Sensor 1)	*, **
	Alti	-2000..9999	Altitude above sea level [m] (only for Sensor1 and if SL)	*, **
	rAtE		Rate: Measuring rate (p.r.t. chapter 7.7.1)	*
		Slo	Slow measuring rate (4 Hz filtered, low power consumption)	*
		FASt	Fast measuring rate, filtered (>1000Hz)	*
	t.AVG	1-120	Peak detection: fast measuring rate, unfiltered (>1000Hz)	*
		oFF	Averaging period in seconds, used by the averaging function	
	P.oFF	1-120	Averaging function deactivated	
		oFF	Auto Power Off time in minutes	
	Out	oFF	Auto Power Off deactivated	
		oFF	Function of the output: No output function, lowest power consumption	
Ser		Output is serial interface		
	dAC	Output is analogue output 0...1 V		

Menu	Parameter	Values	Meaning	
KEY Menu	KEY	KEY ▲ or ▼		
SEt ConF	Set Configuration: Generic Configurations			
	Adr .	01,11..91	Base address of interface (if Out=Ser)	
	dAC .	CH1, CH2, or CH DIF	Choice of the input to be the source for the analogue output (if Out=dAC)	
	dAC.0	eg. -5.00..5.00 mbar	Enter desired value at which the analogue output potential should be 0 V (if Out=dAC)	
	dAC.1	eg. -5.00...5.00 mbar	Enter desired value at which the analogue output potential should be 1 V (if Out=dAC)	
SEt CAL	Set Calibration: Adjustment of Sensors			
	OFS.1	Sensordep., e.g. -5.00...5.00 mbar	The offset of sensor 1 will be displaced by this value to compensate for deviations in the probe or in the measuring device.	
		OFF	Zero displacement is inactive (=0.0°)	
	SCL.1	-2.000...2.000	The measuring scale of sensor 1 will be changed by this factor [%] to compensate deviations of temperature probe or measuring device.	
		OFF	Scale correction factor inactive (=0.000)	
	OFS.2	Sensordep., e.g. -5.00...5.00 mbar	The offset of sensor 2 will be displaced by this value to compensate for deviations in the probe or in the measuring device.	
		OFF	Zero displacement inactive (=0.0°)	
	SCL.2	-2.000...2.000	The measuring scale of sensor 2 will be changed by this factor [%] to compensate deviations of temperature probe or measuring device.	
		OFF	Scale correction factor inactive (=0.000)	
SEt AL.	Set Alarm: Settings Of Alarm Function			
	AL. 1	On	Alarm sensor 1 on, with buzzer sound	
		no.S0	Alarm sensor 1 on, without buzzer sound	
		OFF	no alarm function for sensor 1	
	AL.Lo/AL.1	Sensor1-Min... AL.1-Hi	Min alarm rail Sensor 1 (not when AL.1 OFF) Sensor1-Min is the lower display range of sensor 1	
	AL.Hi/AL.1	AL.1-Lo... Sensor1-Max	Max alarm rail Sensor 1 (not when AL.1 OFF) Sensor1-Max is the upper display range of sensor 1	
	AL. 2	On	Alarm sensor 2 on, with buzzer sound	
		no.S0	Alarm sensor 2 on, without buzzer sound	
		OFF	no alarm function for sensor 2	
	AL.Lo/AL.2	Sensor2- Min...AL.2-Hi	Min alarm rail Sensor 2 (not when AL.2 OFF) Sensor2-Min is the lower display range of sensor 2	
	AL.Hi/AL.2	AL.2-Lo... Sensor2-Max	Max alarm rail Sensor 2 (not when AL.2 OFF) Sensor2-Max is the upper display range of sensor 2	
	AL.DIF	On	Alarm sensor difference on, with buzzer sound	
		no.S0	Alarm sensor difference on, without buzzer sound	
		OFF	no alarm function for sensor difference	
	AL.Lo DIF	-19999..AL.DIF- Hi	Min alarm rail of difference (not when AL.DIF OFF)	
	AL.Hi DIF	AL.DIF-Lo..19999	Max alarm rail of difference (not when AL.DIF OFF)	
SEt LoGG	Set Logger: Configuration Of Logger Function			*
	Func	CYCL	Cyclic: logger function ,cyclic logger'	*
		Stor	Store: logger function ,individual value logger'	*
		OFF	no logger function	*
	CYCL	1..3600	Cycle time of cyclic logger [seconds]	*
	Lo.Po	on/OFF	Low-power logger with very low power consumption (only for cyclic logger and slow measuring rate)	*
SEt CLOC	Set Clock: Setting Of Real Time Clock			
	CLOC	HH:MM	Clock: Setting of time	hours:minutes
	dAtE	TT.MM	Date:	day.month
	YEAr	YYYY	Year	

(* This menu can only be invoked if the logger memory contains no data! If parameter should be changed the logger memory has to be cleared before! (key 6, p.r.t. 7.8 Operation Of Logger)

() This menu can only be invoked if a referring sensor is connected to connection 1. When using a second referring sensor at connection 2 then changes are taken over.**

Note: When using the logger function some settings in the menu may not be accessible (). If this settings should be changed, the logger has to be stopped before, eventually the logger data has to be cleared. (p.r.t. chapter 7.8)*

7.7.1 Different Kinds Of Measuring: „rAtE-Slo, -P.dEt, -FASt“

Three different kinds of measuring pressure are supported. Two of them (P.dEt and FASt) are working with high measuring frequency of more than 1000 measurings per second.

7.7.1.1 rAtE-Slo: Standard Measuring

Measuring rate 4 Hz, averaging and filter functions are active.

Application: Measuring of slowly changing or static pressures, e.g. measuring of leakproofness, atmospheric pressure... Highest accuracy, high noise immunity (EMI and unstable measuring signals), low power consumption.

7.7.1.2 rAtE-P.dEt: Peak detection

Measuring rate >1000 Hz, the value is displayed unfiltered.

Application with logger function: Measuring of short pressure peaks or fast changing pressures with a resolution of < 1 ms. The cyclic logger function records the arithmetic mean value, the highest and the lowest peak of the referring time interval. Attention: higher power consumption, measuring is sensitive to noise (EMI,..).

7.7.1.3 rAtE-FASt: Fast filtered measuring

Measuring rate >1000 Hz, the value is filtered slightly (higher noise immunity than P.dEt, small peaks will be filtered out), apart from that identical behaviour like P.dEt.

7.7.2 Measuring Of Water Level – Display Unit [m]

When using suitable waterproof pressure sensors the unit [m] for meters of water can be set in the menu “Unit“. 10 m of water are roughly 1 bar over pressure. Measurements can be made e.g. like described below :

- With one abs. pressure sensor (SL oFF!): Press ‚Tara‘ when sensor is at ambient air and then bring sensor to the depth to be measured. The display shows now the depth in [m].
- With two abs. pressure sensors (SL oFF!): Sensor 2 at ambient air (does not have to be waterproof), waterproof sensor 1 at water depth to be measured. Don't press ‚Tara‘, the depth can already read from the DIF-display and is compensated for pressure changes in ambient air.
- With one rel pressure sensor: bring tube connection for lower press. in contact to ambient air by means of a tube (no water contact!) and bring the sensor with its open press. connection for higher pressure to water depth to be measured (display and is compensated for pressure changes in ambient air).

7.7.3 Sea Level Correction For Absolute Pressure Sensors

The device displays the absolute pressure. This is not necessarily the same like the values given by weather stations! The weather stations' values are giving the pressure at sea level. Usually the sensor is placed above sea level and therefore, if the value at sea level (zero) is to be measured, the pressure loss resulting from the actual level above sea level has to be considered! To correct the measuring display activate the „Sea-Level-Function“ (SL, p.r.t. chapter 7.7 *Configuration*, setting is only possible, if the abs. pressure sensor is connected to sensor socket 1). Then enter the altitude above sea level of the sensor's location in meters (Alti, p.r.t. chapter 7.7 *Configuration*). When activated, the display shows the SL-arrow and the device displays the pressure value at sea level.



Please note: When two absolute pressure sensors are connected, the sea level function for both is corresponding to the setting of sensor 1

7.7.4 Averaging Function

The averaging function concerns the display values (LCD and interface). It is completely independent from the averaging of the logger function, please don't mix them up!

The averaging integrates the measuring values during a selectable period of time and then calculates the average display value. It is independent from the selected kind of measuring (slow, fast, peak detect).

As long as not enough values are collected (selected averaging time) to calculate a average value, the upper display shows "----", the lower display a 'countdown'.

During an active low-power-logging procedure the averaging is always deactivated
Function of min/max-value memory during averaging:

- If averaging is activated and slow measuring is selected (rAtE-Slo), the min-/max-value memory refers to the average display value.
- If averaging is activated and fast measuring is selected (rAtE-FASt or P.dEt) , the min-/max-value memory refers to the internal measured values (fast peaks can be detected). (>1000 Hz)

7.7.5 Power Off Time

If there won't be pressed any key and no interface communication takes place for the time of the power off time setting (P.Off), the device will be switched off automatically to save battery power. If P.oFF = oFF then the automatic switch off is deactivated.

7.7.6 Alarm

3 possible settings per channel: Alarm off (AL.oFF), on with horn sound (AL.on), on without horn (AL.no.So). Following conditions will display an alarm, when the function is activated (on or no.So):

- Value is below lower (AL. Lo) or above upper alarm rail (AL.Hi).
- Sensor error (Sens Erro)
- Low battery (bAt)
- Fe 7: System error (always with sound)

In case of an alarm and when polling the interface the prio-flag is set in the returned interface message.

If the horn sound of one channel will be switched on/off (on or no.So), then this horn sound setting will automatically be copied to the other activated channels.

7.7.7 Real Time Clock

The real time clock is used for the logger function: Recorded values are also containing the point of time, when they were measured. Please check the settings when necessary.

If the battery was replaced the referring menu ,CLOC' will automatically be started.

7.8 Operation Of Logger

The device supports two different logger functions:

„Func-Stor“: each time when „store“ (key 6) is pressed a measurement will be recorded.

„Func-CYCL“: measurements will automatically be recorded each interval, which was set in the logger menu ,CYCL' until the logger will be stopped or the logger memory is full. The recording is started by pressing „Store“ 2 seconds.

The logger records 3 measurement results each time:

current or mean value (depending on logger setting, see below), min peak and max peak of sensor 1

current or mean value (depending on logger setting, see below), min peak and max peak of sensor 2

current or mean value (dep. on logger setting), min peak and max peak of sensor 1 - sensor 2

Min and max peak are the minimum resp. the maximum of the measured values since the last recording. Using them allows f.e. analysis of fluctuating pressures. For the evaluation of the data the software HND-Z034 has to be used. The software also allows easy configuration and starting of the logger. When the logger is activated (Func Stor or Func CYCL) the hold function is no more available, the key 6 is solely used for the operation of the logger functions.



Please note: When reading out loggerdata either the sensor connected during logging or no sensor should be connected. Otherwise the measuring unit of the data may be corrupted.

7.8.1 „Func-Stor“: Storing Single Measurements

Each time when „store“ (key 6) is pressed a measurement and its time stamp will be recorded. The recorded data can be viewed either in the display (when calling the configuration an additional menu „REAd LoGG“ is displayed, see below) or by means of the interface and a PC with HND-Z034-software.

Max. number of measurings: 99

A measuring contains:

- sensor 1, current measuring value at the time of recording
- sensor 1, min peak since the last recording
- sensor 1, max peak since the last recording
- sensor 2, current measuring value at the time of recording
- sensor 2, min peak since the last recording

- sensor 2, max peak since the last recording
- difference sensor 1 - sensor 2, current measuring value at time of recording
- difference sensor 1 - sensor 2, min peak since the last recording
- difference sensor 1 - sensor 2, max peak since the last recording
- time and date of the recording

After each recording „St. XX“ will be displayed for a short time. XX represents the number of the recording.

If logger memory contains recordings already:

When „Store“ is pressed for 2 seconds, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording



Clear nothing (cancel menu)

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.

If the logger memory is full, the display will show:



Viewing Recorded Measurements

Within the „LoGG Stor“ function the measurements can be viewed directly in the display not only by means of a computer (like at „Func CYCL“): press 2 seconds „Set“ (key 4): The first menu displayed now is „rEAd LoGG“ (read logger data). After pressing ▶ (key 3) the measurement recorded last will be displayed, changing between the different values referring to the measurement also is done by pressing ▶.

Changing the measurement is done by pressing the keys ▲ or ▼.

7.8.2 „Func-CYCL“: Automatic Recording With Selectable Logger-Cycle-Time

The Logger-Cycle-Time is settable (p.r.t. 7.7 Configuration). For example „CYCL“ = 60: A measuring is recorded after each 60 seconds.

When the slow measurement "rAtE-Slo" is chosen, additionally a low power function is available: „Lo.Po“.

If „Lo.Po“ is on, the device only will take a measurement at the point of time of the recording. In between the recordings the measuring shut's down. This decreases the power consumption enormously and therefore is recommended e.g. for long time recordings where no mains adapter is available.

Max. number of measurements: 4000

Cycle time: 1...3600 seconds (=1h), selectable in the configuration

A measuring contains:

- slow measuring rate (rAtE Slo):
 - sensor 1, current measuring value at the time of recording
 - sensor 1, min peak, max peak since the last recording
 - sensor 2, current measuring value at the time of recording
 - sensor 2, min peak, max peak since the last recording
 - difference sensor 1 – sensor 2, current measuring value at time of recording
 - difference sensor 1 – sensor 2, min peak, max peak since the last recording

fast measuring rates (rAtE FASt,P.dEt):

- sensor 1, arithmetic mean value since the last recording
- sensor 1 min peak, max peak since the last recording
- sensor 2, arithmetic mean value since the last recording
- sensor 2 min peak, max peak since the last recording
- difference sensor 1 – sensor 2, arithmetic mean value since the last recording
- difference sensor 1 – sensor 2, min peak, max peak since the last recording

Starting a recording:

By pressing "Store" (key 6) for 2 seconds the recording will be initiated. After that the display shows 'St.XXXX' for a short time whenever a measuring is recorded. XXXX is the number of the measuring 1..4000.

If the logger memory is full, the display will show:



The recording automatically will be stopped.

If Low-Power-Logger-Function „Lo.Po = on“ the device switches itself off as soon as the memory gets filled.

Stopping the recording manually:

By pressing "Store" (key 6) the recording can be stopped manually. Then the following choice appears:



Stop the recording



Do not stop the recording

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.



Note: If you try to switch off the instrument in the cyclic recording operation you will be asked once again if the recording is to be stopped. The device can only be switched off after the recording has been stopped! The Auto-Power-Off-function is deactivated during recording!

Clear Recordings:

When „Store“ is pressed for 2 seconds, the logger operation will be called:

The display will show:  By pressing the keys ▲ (key 2) or

▼ (key 5) the display will change to



When „Store“ is pressed, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording sequence



Clear nothing (cancel menu)

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.

8. Output

The output can be used as serial interface (HND-Z031 or HND-Z032 interface adapters) or as analog output (0-1V).

If none of both is needed, we suggest to switch the output off, because battery life then is extended.

8.1 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031) the device can be connected to a computer for data transfer. To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

- **HND-Z034:** Operation and read out of logger function, data display in diagrams and tables
- **BUS-S20M:** 20-channel software to display the measuring values

HND-P215

The device has 9 channels:

- Channel 1: sensor 1 current measuring value (base address)
- Channel 2: sensor 1 min peak (p.r.t. 7.8 Operation Of Logger)
- Channel 3: sensor 1 max peak (p.r.t. 7.8 Operation Of Logger)
- Channel 4: sensor 2 current measuring value (base address)
- Channel 5: sensor 2 min peak (p.r.t. 7.8 Operation Of Logger)
- Channel 6: sensor 2 max peak (p.r.t. 7.8 Operation Of Logger)
- Channel 7: difference sensor 1 – sensor 2 current measuring value (base address)
- Channel 8: difference sensor 1 – sensor 2 min peak (p.r.t. chapter 7.8 Operation Of Logger)
- Channel 9: difference sensor 1 – sensor 2 sensor 1 max peak (p.r.t. chapter 7.8 Operation Of Logger)



Note: The measuring-/ alarm- and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Channel	Code	Name/Function	Channel	Code	Name/Function
1	4, 7	2,3,5 6,8,9	1	4, 7	2,3,5 6,8,9
x x x	0	Read measurement value	x	208	Read # of channels
x x x	3	Read system state	x	222	Read power off time (Conf-P.oFF)
x	12	Read ID number	x	223	Set power off time (Conf-P.oFF)
x	22	Read min alarm rail (AL. - AL.Lo)	x x x	224	Logger: Read data of CYCL- Logger
x	23	Read max alarm rail (AL. - AL.Hi)	x	225	Logger: Read cycle time (LoGG - CYCL)
x	32	Read configuration flag BitPeakDetection:33; BitFastFiltered:34; BitLoggerOn:50; BitCyclicLogger:51; BitLowPowerLogger:52	x	226	Logger: set cycle time (LoGG - CYCL)
			x	227	Logger: start recording
			x	228	Logger: Read # of recordings made
			x	229	Logger: Read state
			x	231	Logger: Read stop time
x	160	Set configuration flag (refer to 32)	x	233	Read real time clock (CLOC)
x x x	176	Read min measuring range	x	234	Set real time clock (CLOC)
x x x	177	Read max measuring range	x	236	Read logger memory size
x x x	178	Read measuring range unit	x	237	Read logger filecount
x x x	179	Read measuring range decimal point	x	238	Read logger filepointer
x x x	180	Read kind of measuring of sensor	x	239	Read logger file info
			x	240	Reset
x x x	199	Read kind of measuring of display	x	254	Program version
x x x	200	Read min display range	x	260	Logger: read data of STOR Logger
x x x	201	Read max display range	x x x	263	Read logger channel info
x x x	202	Read display range - unit			
x x x	204	Read display range – decimal point			

8.2 Analogue Output – Scaling with DAC.0 and DAC.1


Note: Analogue output cannot be used during logger recordings

With the DAC.0 and DAC.1 values the output can be rapidly scaled to your efforts. Keep in mind not to connect low-resistive loads to the output, otherwise the output value will be wrong and battery life is decreased. Loads above ca 10kOhm are uncritical.

If the display exceeds the value set by DAC.1, then the device will apply 1V to the output

If the display falls below the value set by DAC.0, then the device will apply 0V to the output

In case of an error (Err.1, Err.2, no sensor, etc.) the device will apply slightly above 1V to the output.



8.3 Instrument Adjustment

8.3.1 Zero Displacement Sensor 1 ('OFS.1') and Sensor 2 ('OFS.2')

A zero displacement can be carried out for the measured value:

value displayed = value measured - offset

Standard setting: 'off' = 0.0°, i.e. no zero displacement will be carried out. Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations. Input is in the display unit.

8.3.2 Scale Correction Sensor 1 ('SCL.1') and Sensor 2 ('SCL.2')

The scale of the measuring can be influenced by this setting (factor is in %):

displayed value = measured value * (1+Scal/100)

Standard setting: 'off' =0.000, i.e. value is not corrected. Together with the zero displacement (see above) this factor is mainly used to compensate for sensor deviations.

8.4 Pressure Connection to the Sensors

The device is designed to be connected to the sensors of the HND-PS...-series without a new calibration being necessary. Therefore a great variety of replaceable sensors of e.g. -1.999...2.500 mbar relative up to 0...1000 bar absolute pressure can be connected to the device.

8.5 Relative Pressure Sensors (Types: HND-PS01...-PS05, HND-PS09)

- **For measurements of over- or under pressure:**

Connect plastic tube with internal dia of 4 mm to pressure port "B". Port "A" is not used!

- **For measurements of under pressure:** (with higher negative measuring range)

Connect plastic tube with internal dia of 4 mm to pressure port "B". Port "A" will not be used!

Pressure sensors HND-PS01, HND-PS02 and HND-PS03 allow for measurements of under pressure up to the entire over pressure measuring range by re-plugging the tube to pressure port "A". Please note that all values are displayed as positive values. No minus sign will be shown. (Example for HND-PS02: For tube connection "B" the measuring range covers -19.99 to 25.00 mbar. If you replug to port "A" under pressure measurements down to -25.00 mbar could be carried out with the display showing the value 25.00 (no minus sign).

Note: All values are displayed now as positive values. No minus sign will be shown. Example: it is possible to measure under pressure down to -25.00 mbar, the display shows then the value 25.00 (no minus sign).

For measurements of differential pressure:

Connect both plastic tubes with an internal dia of 4 mm to pressure port "B" and "A"; make sure to apply higher pressure to port "B".




Stainless steel pressure sensors: (types: HND-PS01...-PS30)

For measurements of over-, under- or absolute pressure screw sensor to G1/4" pressure terminal or plug plastic tube to a suitable adapter.

Measurements of differential pressure with two sensors

By means of the calculation sensor 1 – sensor 2 (DIF) press. differences of any sensor combinations can be measured.

8.6 Error and System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty Mains operation without battery: wrong voltage	Replace battery Check power supply, replace it when necessary
	No sensor connected Connected sensor or device defective Value extremely out of measuring range	Switch off device and connect sensor If 2nd sensor available, check if device is ok. Return defective device/sensor to manufacturer for repair Check: pressure not within sensor range?
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
Err.1	Device defective	Return to manufacturer for repair
	Measured value above allowable range	Check: pressure not within sensor range? -> measuring value to high!
Err.2	Sensor defective	Return to manufacturer for repair
	Measured value below allowable range	Check: pressure not within sensor range? -> measuring value to low!
Err.3	Sensor defective	Return to manufacturer for repair
	Display range overflow	Check: value above 19999 -> to high to be displayed!
Err.4	Display range underflow	Check: value below 19999 (Tara?) -> to low!
Er.11	Value could not be calculated	Choose different unit
	Calculation overflow happened	Choose different unit
Err.7	System error	Return to manufacturer for repair
----	Sensor not present/recognized	Reconnect sensor, During logging: stop the logger and restart it
	Could not calculate value	Suitable sensor/unit combination necessary

8.7 Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certificated for its accuracy, it is the best solution to return it with the referring sensors to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

9. Maintenance


9.1 Battery Operation

If 'bAt' is shown in the lower display the battery has been used up and needs to be replaced. However, the device will operate correctly for a certain time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.



Please note: The battery has to be taken out, when storing device above 50 °C. We recommend taking out battery if device is not used for a longer period of time! After recommissioning the real time clock has to be set again.




10. Technical Information

Measurement input:	for pressure sensor HND-PS
Measuring range:	depending upon the pressure sensor
Accuracy:	± 0.1 % F.S. ± 1 Digit (at nominal temperature 25 °C)
Resolution:	depending upon the sensor
Display range:	-19999 ... +19999
Operating temperat.:	-25 to +50 °C
Storage temperat.:	-25 to +70 °C
Storage humidity:	0 to 95% r.H. (non-condensing)
Probe connection:	6-pin shielded Mini-DIN plug, autom. sensor recognition, and measuring range adjustment
Output:	3.5mm audio plug, stereo
Output function:	selectable as serial interface or analog output
Interface:	Serial interface (3.5mm jack) can be connected to USB or RS232 interface of a PC via electrically isolated interface adapter, HND-Z031 or HND-Z032 (see accessories)
Analog output:	0...1 Volt, freely scaleable (resolution 12 bit)
Power supply:	9V battery, type IEC 6F22 (included in scope of delivery) as well as additional d.c. connector (diameter of internal pin 1.9mm) for external 10.5-12 V direct voltage supply.  (suitable power supply: HND-Z002)
Power consumption:	Slow measuring rate: <1.8 mA Fast measuring rate: <7.0 mA Low-Power-Logger: <0.3 mA (for cycle time >30s, without interface communication active and no alarm horn sounding) up to 0.8 mA (at cycle time 1s)
Low battery warning:	'bat'
Working conditions:	-20...+50 °C, 0...95% RH (not condensing)
Storage temperature:	-20...+70 °C
Housing:	impact-resistance ABS, membrane keyboard, transparent panel, Front side IP65
Dimensions:	142x71x26 mm (LxWxD)
Weight:	approx. 170 g

11. Order Codes

Order-no.	Housing design
HND-P...	2 x pressure sensor inputs with additional functions (see techn. data)

11.1 Pressure sensors

Measuring range	Accuracy	Resolution	Overload	Working-Temperature	Connection	Order-no.		
1.999...2.500 mbar	$\pm 0.2\%$ EW / $\pm 1.0\%$ EW*	0.001 mbar	max. 200 mbar	0...+50 °C	Nylon spigot for hose 6 x1 mm 	HND-PS01**		
19.99...25 mbar	$\pm 0.2\%$ EW/ $\pm 0.5\%$ EW*	0.01 mbar	max. 300 mbar			HND-PS02**		
199.9...350.0 mbar	$\pm 0.2\%$ EW/ $\pm 0.4\%$ EW*	0.1 mbar	max. 1 bar			HND-PS03**		
1000...2000 mbar		1 mbar	max. 4 bar			HND-PS04**		
-1...10 bar		10 mbar	max. 10.34 bar			HND-PS05**		
0...1300 mbar abs.		1 mbar	max. 4 bar abs.			HND-PS06**		
0...2000 mbar abs.		10 mbar	max. 10 bar abs.			HND-PS07**		
0...7.00 bar abs.		0.1 mbar	max. 1.4 bar			HND-PS08**		
0...350.0 mbar rel.	$\pm 0.2\%$ EW/ $\pm 0.4\%$ EW*	1 mbar	max. 4 bar abs.	0...+70 °C	External threads G 1/4, stainless steel 	HND-PS09		
0...1000 mbar abs.			max. 14 bar abs.			HND-PS10		
0...3500 mbar abs.			max. 14 bar rel.			HND-PS11		
0...3500 mbar rel.			max. 28 bar abs.			HND-PS12		
0...7000 mbar abs.		10 mbar	max. 140 bar abs.			HND-PS13		
0...35.00 bar abs.			max. 280 bar abs.			HND-PS14		
0...70.00 bar abs.		0.1 bar	max. 600 bar abs			HND-PS15		
0...160.0 bar abs.						HND-PS16		
0...250.0 bar abs.						HND-PS17		
0...400.0 bar abs.						HND-PS18		
0...400 mbar rel.		0.1 mbar	max. 2 bar rel.			0...+70 °C	G 1/2 male thread 	HND-PS19
0...1000 mbar rel.		1 mbar	max. 5 bar rel.					HND-PS20
0...2500 mbar rel.			max. 10 bar rel.	HND-PS21				
0...4000 mbar rel.			max. 17 bar rel.	HND-PS22				
0...6000 mbar rel.		10 mbar	max. 35 bar rel.	HND-PS23				
0...10 bar rel.			max. 50 bar rel.	HND-PS24				
0...250 bar rel.			max. 80 bar rel.	HND-PS25				
0...40.0 bar rel.		0.1 bar	max. 120 bar rel.	HND-PS26				
0...60 bar rel.	max. 200 bar rel.		HND-PS27					
0...100 bar rel.	max. 320 bar rel.		HND-PS28					
0...160 bar rel.	10 mbar	max. 500 bar rel.	HND-PS29					
0...250 bar rel.		max. 800 bar rel.	HND-PS30					
0...400 bar rel.		max. 1200 bar rel.	HND-PS31					
0...600 bar rel.	0.1 bar	max. 500 bar rel.	HND-PS32					
0...1000 bar rel.	1 bar	max. 1500 bar rel.	HND-PS33					

* in the range from 0 to +50 °C

** Pressure sensors HND-PS01 up to HND-PS08 are only suitable for air and non corrosive/non ionizing gases and liquids, not for water.

11.2 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10,5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose $\frac{6}{4}$ on hose $\frac{6}{4}$
HND-Z082	Hose clamp for hose $\frac{6}{4}$
HND-Z083	Adapter made of brass for G $\frac{1}{4}$ internal threads on hose $\frac{6}{4}$
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

* observe instrument dimensions

Additional accessories on request

12. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Manual Pressure Measuring Devices with External and Integrated Pressure Sensors model: HND-P215

EN 61326-1:2006 Electrical equipment for measurement, control and laboratory use. EMC requirements

Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline


Hofheim, 29. July 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Hand-Held Pressure Measuring Devices
with Integrated Pressure Sensors

Model: HND-P231



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Electrical Connection	4
6.1 General.....	4
7. Operation	5
7.1 General	5
7.2 Configuration	7
7.3 Operation Of Logger	11
7.4 The Serial Interface	14
7.5 Pressure Connection To The Sensors	15
7.6 Error And System Messages	16
7.7 Calibration Services	16
8. Maintenance	17
8.1 Battery Operation.....	17
9. Technical Information.....	17
10. Order Codes	18
10.1 Accessories	19
11. Declaration of Conformance	20

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Hand-held Pressure Measuring Device with Integrated Pressure Sensors
model: HND-P231
- Operating Instructions

4. Regulation Use

Any use of the Hand-held Pressure Measuring Device with Integrated Pressure Sensors, model: HND-P231, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The highly precise KOBOLD manual pressure measuring devices HND-P231 are measuring devices with integrated pressure sensors. They have two pressure measurement inputs on the top of the housing, which are connected to the measuring points by means of stable metal connections and plastic hoses that are available as accessories. Numerous measuring ranges in the overpressure and underpressure range are available for various measurement tasks, such as differential pressure measurement. In addition to pressure display, these first-rate, compact, universally applicable measuring units offer additional functions such as minimum/maximum value memory, a hold function, tare function, automatic self-shut-off, or zero point offset. The devices with an expanded spectrum of functions also have a logger function, a peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

6. Electrical Connection

6.1 General

6.1.1 Mains Operation With Power Supply



Attention: When using a power supply please note that operating voltage has to be 10.5 to 12 V DC. Do not apply overvoltage!! Cheap 12V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply GNG10/3000. Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

7. Operation

7.1 General

7.1.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices.

However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under chapter 9 Technical Information.
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.




Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be a risk if:
 - there is visible damage to the device
 - the device is not working as specified
 - the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.

7.1.2 Connections



Connection for pressure tubes:

„+“ = higher pressure, „-“ = lower pressure

Interface: Connection for el. isolated interface adapter (p.r.t. chapter 7.4 The Serial Interface)

The mains adapter socket is located at the left side of the device.

7.1.3 Display

Einheiten: ein Pfeil zeigt auf die gewählte Messeinheit
SL: ohne Funktion

Tara: signalisiert, ob Tara-Funktion aktiviert ist.




Hauptanzeige: zeigt den aktuellen Messwert an
Nebenanzeige: zeigt u.a. Min-, Max- oder Holdwerte an.

Logg: erscheint falls Loggerfunktion ausgewählt wurde und blinkt bei laufendem Logger

7.1.4 Basic Operation

When switching on the device and the logger function is not off the time of the integrated clock will shortly be displayed. If a **zero point adjustment** was carried out the display shows shortly „nuLL Corr“.

After changing the battery the clock-setting menu is activated automatically („CLOC“). Check the clock and adjust, if necessary (p.r.t. chapter 7.2 Configuration).



Max Memory: Pressing 'max' (key 2) shows the maximum of the measured values. Pressing it again hides it. To clear the max memory press key 'max' for >2 seconds.

Min Memory: Pressing 'min' (key 5) shows the minimum of the measured values. Pressing it again hides it. To clear the min memory press key 'min' for >2 seconds.

Hold Function: By pressing 'Store/Quit' (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it. (only when logger = ,off').

Tare Function: By pressing 'Tara' (key 3) the display will be set to 0. All measurings from then on will be displayed relatively to the set tare value. When tara function is activated, the arrow "Tara" appears in the display. To deactivate tare function press 'Tara' for >2 seconds.



Please Note: Activating/deactivating tara clears the max- & min-memories.

Zero-Point Adjustment: If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press button 3 for approx. 5 seconds (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu).

Please note: A zero-point adjustment can only be carried out if the difference between the value on display is less than 500 digits!

To recall the manufacturer`s calibration press button 3 for approx. 15 seconds.

7.2 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu (main display: „SEt“).

Pressing key **Menu** changes between the menus, pressing **▶** (key 3) jumps to the referring parameters, which can be selected with key **▶** (key 3).

The parameters can be changed with **▲** (key 2) or **▼** (key 5).

Pressing **Menu** again jumps back to the main configuration menu and saves the settings.

Quit (key 6) finishes the configuration and returns to standard meas. operation.

Menu	PARAM.	Values	Meaning	C. lon	C. dat	Stor
„Menu“	▶	▲ or ▼				
SEt ConF	Set Configuration: Generic Configurations					
	Unit	mbar,bar..	Unit: Unit of display	*		*
	rAtE		Rate: Measuring rate (p.r.t. chapter 7.2.1 <i>Different Kinds Of Measuring: „rAtE-Slo, -P.dEt, -FASt“</i>)	*		*
		Slo	Slow measuring rate (4 Hz filtered, low power consumption)	*		*
		FASt	Fast measuring rate, filtered (>100 Hz)	*		*
		P.dEt	Peak detection: fast measuring rate, unfiltered (>100 Hz)	*		*
	t.AVG	1-120	Averaging period in seconds, used by the averaging function	*		*
		oFF	Averaging function deactivated	*		*
	P.oFF	1-120	Auto Power Off time in minutes			
		oFF	Auto Power Off deactivated			
	Out	oFF	Function off the output: No output function, lowest power consumption			
		SEr	Output is serial interface			
		dAC	Output is analogue output 0...1V			
	Adr.	01,11..91	Base address of interface			
	dAC.0	-1.00... 25.00 mbar	Enter desired value at which the analogue output potential should be 0V (if Out=dAC)			
dAC.1	-1.00... 25.00 mbar	Enter desired value at which the analogue output potential should be 1V (if Out=dAC)				
Set CAL	Set Calibration: Adjustment of Sensor			*		
	OFFS	-5.00... 5.00 mbar	The offset of sensor will be displaced by this value to compensate for deviations in the probe or in measuring device.	*		
		oFF	Zero displacement inactive (=0.00)	*		
	SCAL	-2.000... 2.000	The measuring scale of sensor will be changed by this factor [%] to compensate deviations of temperature probe or measuring device	*		
		oFF	Scale correction factor inactive (=0.000)	*		

HND-P231

Set AL.	Set Alarm: Settings Of Alarm Function					
	AL.	On	Alarm on, with horn-sound			
		no.So	Alarm on, without horn-sound			
		oFF	Alarm deactivated			
AL.Lo	-10 mbar ... AL.Hi	Min alarm rail (not when AL. oFF, Sensor-Min is the lower display range of connected sensor)				
AL.Hi	AL.Lo ... 350 mbar	Max alarm rail (not when AL. oFF, Sensor-Max is the upper display range of connected sensor)				
SEt LoGG	Set Logger: Configuration Of Logger Function			*		*
	Func	CYCL	Cyclic: logger function ,cyclic logger‘	*	*	*
		Stor	Store: logger function ,individual value logger‘	*	*	*
		oFF	no logger function	*	*	*
	CYCL	1..3600	Cycle time of cyclic logger [seconds]	*		*
Lo.Po	on/oFF	Low-power logger with very low power consumption (only for cyclic logger and slow measuring rate)	*		*	
SEt CLOC	Set Clock: Setting Of Real Time Clock					
	CLOC	HH:MM	Clock: Setting of time hours:minutes			
	dAtE	TT.MM	Date: day.month			
	YEAr	YYYY	Year			



Note: If the logger memory contains data already, the menus/parameters marked with (*) can not be invoked! If these should be altered the logger memory has to be cleared before! (key 6, p.r.t. chapter 7.3 Operation Of Logger)

7.2.1 Different Kinds Of Measuring: „rAtE-Slo, -P.dEt, -FASt“

Three different kinds of measuring pressure are supported. Two of them are working with high measuring frequency of more than 1000 measurings per second. If one of them was chosen in the configuration (see above), this will be displayed in the secondary display: „P.dEt“ or „FASt“.

7.2.1.1 rAtE-Slo: Standard Measuring

Measuring rate 4 Hz, averaging and filter functions are active.

Application: Measuring of slowly changing or static pressures, e.g. measuring of leakproofness, atmospheric pressure...

Highest accuracy, high noise immunity (EMI and unstable measuring signals), low power consumption.

7.2.1.2 rAtE-P.dEt: Peak detection

Measuring rate >1000 Hz, the value is displayed unfiltered.

Application with logger function: Measuring of short pressure peaks or fast changing pressures with a resolution of < 1 ms. The cyclic logger function records the arithmetic mean value, the highest and the lowest peak of the referring time interval.

Attention: higher power consumption, measuring is sensitive to noise (EMI,..).

7.2.1.3 rAtE-FAST: Fast filtered measuring

Measuring rate >1000 Hz, the value is filtered slightly (higher noise immunity than P.dEt, small peaks will be filtered out), apart from that identical behaviour like P.dEt.

7.2.2 Averaging Function

The averaging function concerns the display values (LCD and interface). It is completely independent from the averaging of the logger function, please don't mix them up!

The averaging integrates the measuring values during a selectable period of time and then calculates the average display value. It is independent from the selected kind of measuring (slow, fast, peak detect) .

As long as not enough values are collected (selected averaging time) to calculate a average value, the upper display shows "----", the lower display a 'countdown'.

During an active low-power-logging procedure the averaging is always deactivated
Function of min-/max-value memory during averaging:

- If averaging is activated and slow measuring is selected (rAtE-Slo), the min-/max-value memory refers to the average display value.
- If averaging is activated and fast measuring is selected (rAtE-FAST or P.dEt) , the min-/max-value memory refers to the internal measured values (fast peaks can be detected).

7.2.3 Zero Displacement Sensor (`OFFS`)

A zero displacement can be carried out for the measured value:

$$\text{value displayed} = \text{value measured} - \text{offset}$$

Standard setting: `off` = 0.0, i.e. no zero displacement will be carried out.

Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations. Input is in the display unit.

7.2.4 Scale Correction Sensor (`SCAL`)

The scale of the measuring can be influenced by this setting (factor is in %):

$$\text{value displayed} = \text{measured value} * (1 + \text{Scal}/100)$$

Standard setting: `off` = 0.000, i.e. value is not corrected. Together with the zero displacement (see above) this factor is mainly used to compensate for sensor deviations.

7.2.5 Power Off Time

If there won't be pressed any key and no interface communication takes place for the time of the power off time setting (P.Off), the device will be switched off automatically to save battery power.

If P.oFF = oFF then the automatic switch off is deactivated.

7.2.6 Output

The output can be used as serial interface (for HND-Z032, HND-Z031 interface adapters) or as analogue output.

7.2.6.1 Interface-Base Address

Up to 10 devices of the HND-P...-handheld-family can be connected to a serial interface at once. To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on.

7.2.6.2 Analogue Output-Scaling with DAC.0 and DAC.1

Note: Analogue output can not be used during logger recordings


With the DAC.0 and DAC.1 values the output can be rapidly scaled to Your efforts. Keep in mind not to connect low-resistive loads to the output, otherwise the output value will be wrong and battery life is decreased. Loads above ca 10kOhm are uncritical.

If the display exceeds the value set by DAC.1, then the device will apply 1V to the output.

If the display falls below the value set by DAC.0, then the device will apply 0V to the output.

In case of an error (Err.1, Err.2, no sensor, etc.) the device will apply slightly above 1V to the output.

plug wiring:



GND

+Uout

Attention!

The 3rd contact has to be left floating!
Only stereo plugs are allowed!

7.2.7 Address

Up to 10 devices of the HND-handheld-family can be connected to a serial interface at once (depending on interface converter, e.g. HND-Z032: 5 devices). To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on. See also chapter 7.4 The Serial Interface.

7.2.8 Alarm

There are three possible settings: Alarm off (AL. oFF), on with horn sound (AL. on), on without horn sound (AL. no.So).

Following conditions will display an alarm, when the function is activated (on or no.So):

- Value is below lower (AL. Lo) or above upper alarm rail (AL.Hi).
- Sensor error (Sens Erro)
- Low battery (bAt)
- Fe 7: System error (always with sound)

In case of an alarm and when polling the interface the prio-flag is set in the returned interface message.

7.2.9 Real Time Clock

The real time clock is used for the logger function: Recorded values are also containing the point of time, when they were measured. Please check the settings when necessary.

If the battery was replaced the referring menu ‚CLOC‘ will automatically be started.

7.3 Operation Of Logger

The device supports two different logger functions:

„Func-Stor“: each time when „store“ (key 6) is pressed a measurement will be recorded.

„Func-CYCL“: measurements will automatically be recorded each interval, which was set in the logger menu ‚CYCL‘ until the logger will be stopped or the logger memory is full. The recording is started by pressing „Store“ 2 seconds.

The logger records 3 measurement results each time:

current or mean value (depending on logger setting, see below), min peak and max peak.

Min and max peak are the minimum resp. the maximum of the measured values since the last recording.

Using them allows f.e. analysis of fluctuating pressures.

For the evaluation of the data the software HND-Z034 has to be used. The software also allows easy configuration and starting of the logger.

When the logger is activated (Func Stor or Func CYCL) the hold function is no more available, the key 6 is solely used for the operation of the logger functions.

7.3.1 Func-Stor“: Storing Single Measurements

Each time when „store“ (key 6) is pressed a measurement and its time stamp will be recorded.

The recorded data can be viewed either in the display (when calling the configuration an additional menu „REAd LoGG“ is displayed, see below) or by means of the interface and a PC with HND-Z034-software.

Max. number of measurings 99

A measuring contains:

- current measuring value at the time of recording
- min peak, max peak since the last recording
- time and date of the recording

After each recording „St. XX“ will be displayed for a short time. XX represents the number of the recording.

If logger memory contains recordings already:


When „Store“ is pressed for 2 seconds, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording



Clear nothing (cancel menu)

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.

If the logger memory is full, the display will show:



Viewing Recorded Measurements

Within the „LoGG Stor“ function the measurements can be viewed directly in the display not only by means of a computer (like at „Func CYCL“): press 2 seconds „Set“ (key 4): The first menu displayed now is „rEAd LoGG“ (read logger data). After pressing ▶ (key 3) the measurement recorded last will be displayed, changing between the different values referring to the measurement also is done by pressing ▶.

Changing the measurement is done by pressing the keys ▲ or ▼.

7.3.2 „Func-CYCL“: Automatic Recording With Selectable Logger-Cycle-Time

The Logger-Cycle-Time is setable (p.r.t. 7.2 *Configuration*). For example „CYCL“ = 60: A measuring is recorded after each 60 seconds.

When the slow measurement "rAtE-Slo" is chosen, additionally a low power function is available: „Lo.Po“.

If „Lo.Po“ is on, the device only will take a measurement at the point of time of the recording. In between the recordings the measuring shut's down. This decreases the power consumption enormously and therefore is recommended e.g. for long time recordings where no mains adapter is available.

Max. number of measurements: 10000

Cycle time: 1...3600 seconds (=1 h), selectable in the configuration

A measuring contains:

- | | |
|-----------------|---|
| rAtE SLo: | - current measuring value at the time of recording
- min peak, max peak since the last recording |
| rAtE FASt,P.dEt | - arithmetic mean value since the last recording
- min peak, max peak since the last recording |

Starting a recording:

By pressing "Store" (key 6) for 2 seconds the recording will be initiated. After that the display shows 'St.XXXX' for a short time whenever a measuring is recorded. XXXX is the number of the measuring 1..10000.

If the logger memory is full, the display will show:  The recording

If Low-Power-Logger-Function „Lo.Po = on“ the device switches itself off as soon as the memory gets filled.

Stopping the recording manually:

By pressing "Store" (key 6) the recording can be stopped manually. Then the following choice appears:



Stop the recording



Do not stop the recording

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.



Note: If you try to switch off the instrument in the cyclic recording operation You will be asked once again if the recording is to be stopped.

The device can only be switched off after the recording has been stopped!

The Auto-Power-Off-function is deactivated during recording!

Clear Recordings:

By pressing "Store" (key 6) for 2 seconds the logger operation will be called:



The display will show: By pressing the keys ▲ (key 2) or ▼ (key 5) the



display will change to .

When "Store" is pressed, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording sequence



Clear nothing (cancel menu)

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.

7.4 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031) the device can be connected to a computer for data transfer. To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

- **HND-Z034:** Operation and read out of logger function, data display in diagrams and tables
- **BUS-SW9M:** 9-channel software to display the measuring values

The device has 3 channels:

- Channel 1: current measuring value (base address)
- Channel 2: min peak (p.r.t. chapter 7.3 Operation Of Logger)
- Channel 3: max peak (p.r.t. chapter 7.3 Operation Of Logger)



Note: The measuring-/ alarm- and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Channel				Code	Name/Function	Channel				Code	Name/Function		
1	2	3				1	2	3					
x	x	x		0	Read measurement value	x	x	x		200	Read min display range		
x	x	x		3	Read system state	x	x	x		201	Read max display range		
x				6	Read min memory	x	x	x		202	Read display range - unit		
x				7	Read max memory	x	x	x		204	Read display range – decimal point		
x	x	x		12	Read ID number	x				208	Read # of channels		
x				22	Read min alarm rail (AL. - AL.Lo)	x				214	Read scale adjustment [%]		
x				23	Read max alarm rail (AL. - AL.Hi)	x				216	Read offset adjustment		
x				32	Read configuration flag BitAlarmOn:1; BitAlarmSound:3; BitPeakDetection:33; BitFastFiltered:34; BitLoggerOn:50; BitCyclicLogger:51; BitLowPowerLogger:52	x				222	Read power off time (Conf-P.oFF)		
							x					223	Set power off time (Conf-P.oFF)
							x	x	x			224	Logger: Read data of CYCL-Logger
							x					225	Logger: Read cycle time (LoGG - CYCL)
							x					226	Logger: set cycle time (LoGG - CYCL)
x				102	Set min alarm rail (AL. - AL.Lo)	x				227	Logger: start recording		
x				103	Set max alarm rail (AL. - AL.Hi)	x				228	Logger: Read # of recordings made		
x				160	Set configuration flag (refer to 32)	x				229	Logger: Read state		
x				174	Clear min memory	x				231	Logger: Read stop time		
x				175	Clear max memory	x				233	Read real time clock (CLOC)		
x	x	x		176	Read min measuring range	x				234	Set real time clock (CLOC)		
x	x	x		177	Read max measuring range	x				236	Read logger memory size		
x	x	x		178	Read measuring range – measuring unit	x				240	Reset		
x	x	x		179	Read measuring range – decimal point	x				254	Program version		
x	x	x		180	Read kind of measuring of sensor	x				260	Logger: read data of STOR Logger		
x	x	x		199	Read kind of measuring of display								

7.5 Pressure Connection To The Sensors

- **For measurements of over pressure (-1.00 mbar...25.00 mbar):**
Connect plastic tube with internal dia of 4 mm to pressure port "+". Port "-" will not be used!
- **For measurements of under pressure (-25.00 mbar...0.00 mbar):**
Plug the tube to pressure port "-". The measuring range covers then -350.0 to 0.0 mbar.






Note: All values are displayed now as positive values. No minus sign will be shown.

Example: it is possible to measure under pressure down to -25.0 mbar, the display shows then the value 25.00 (no minus sign).

- **For measurements of pressure differences:**
Connect both plastic tubes with an internal dia of 4 mm to pressure port "+" and "-"; make sure to apply higher pressure to port "+".

7.6 Error And System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
	Logger data are read by the interface	When transfer completed the device will automatically return to normal measuring display, no remedy necessary
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
Err.1	Measured value above allowable range	Check: pressure above 350 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.2	Measured value below allowable range	Check: pressure below -10 mbar? -> measuring value to low
Err.4	Sensor defective	Return to manufacturer for repair
Err.9	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
Err.7	System error	Return to manufacturer for repair

7.7 Calibration Services


Calibration certificates – DKD-certificates – other certificates:

If device should be certificated for its accuracy, it is the best solution to return it to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

8. Maintenance

8.1 Battery Operation

If  and 'bAt' are shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up. The battery has to be taken out, when storing device above 50 °C.



Please note: We recommend to take out battery if device is not used for a longer period of time!

9. Technical Information

Measuring range:	-1,00 to 25,00 mbar
Overload:	Under pressure down to -25 mbar max. 100 mbar rel. (without destruction or recalibration of sensor being necessary)
Resolution:	0.01 mbar (1 Pa)
Pressure units:	mbar, bar, Pa, kPa, mmHg, PSI, mH ₂ O (display `m`), selectable
Accuracy: (typ.):	±0.3 % FS. (hysteresis and linearity) ±0.4 % FS (temperature dependency 0-50 °C)
Measuring rate:	slow: 4 meas./sec (ConF-Rate=Slow) fast: >1000 meas./sec (ConF-Rate=FASt and P.dEt)
Nominal temperature:	25°C
Sensor:	Piezo-resistive relative pressure sensor, for air and non-corrosive and non-ionising gases and liquids, not for water!
Connection:	2 metal pressure ports for connection to 6x1 mm tubes at the top of device (4 mm inner tube ø)
Logger:	2 Functions: individual value logger ("Func-Stor") and cyclic logger ("Func-CYCL")
Memory:	Stor: 99 data sets CYCL: 10000 data sets (in max. 64 recording sequences)
Cycle time CYCL:	1...3600 seconds
Display:	2 four digit LCDs (12.4 mm high and 7 mm high) for measuring values, and for min/max memories, hold function, etc. As well as additional functional arrows.
Pushbuttons:	6 membrane keys
Output:	3.5 mm audio plug, stereo

HND-P231

Output function:	selectable as serial interface or analog output
Interface:	Serial interface (3.5 mm jack) can be connected to RS 232 or USB interface of a PC via electrically isolated interface adapter.
Analog output:	0...1 Volt, freely scalable (resolution 12 bit)
Power supply:	9 V battery. Type: IEC 6F22 (included in the scope of supply) as well as additional d.c. connector for external 10.5-12 V _{DC} .
Power consumption:	Slow measuring rate: ~0.6 mA Fast measuring rate: <2.5 mA Low-Power-Logger: <0.1 mA (for cycle time >30 s, without interface communication active and no alarm horn sounding) up to 0.4 mA (at cycle time 1 s)
Low battery warning:	`bAt`
Material:	housing made of impact-resistant ABS plastic
Degree of protect.:	IP65, front side
Dimensions:	142 x 71 x 26 mm (LxWxD)
Weight:	approx. 165 g
Power-Off-Function:	Device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power-off delay. The power-off delay can be set to values between 1 and 120 min.; it can be completely deactivated.
Min/Max-Alarm:	The measuring value is constantly monitored for the min and max rails set. Alarming is done by integrated horn, display and interface.
Real time clock:	Integrated clock with date and year

10. Order Codes

Order-no.	Housing design
HND-P 231	2 measuring inputs with additional functions (see techn. data)

10.1 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10.5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose 6.4 on hose 6.4
HND-Z082	Hose clamp for hose 6.4
HND-Z088	Adapter made of brass for G ½ internal threads on hose 6.4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

* Pay attention to instrument dimensions

Further accessories on request

11. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

**Hand-Held Pressure Measuring Devices with Integrated Pressure Sensors
Model: HND-P231**

to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and laboratory use. EMC requirements


Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline


Hofheim, 8. May 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Manual Pressure Measuring Devices
with External and Integrated Pressure
Sensors

Model:

HND-P231

HND-P233

HND-P236

HND-P239



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Electrical Connection	4
6.1 Mains Operation with Power Supply	4
7. Operation	5
7.1 General.....	5
7.2 Connections.....	6
7.3 Display.....	6
7.4 Basic Operation	6
7.5 Operation.....	7
7.6 Pop-up clip.....	8
7.7 Configuration	9
8. Remarks to special features.....	11
8.1 Different Kinds of Measuring: „rAtE-Slo, -P.dEt, -FASt“	11
8.2 Sea Level Correction (only for HND-P239)	11
8.3 Averaging Function	12
8.4 Operation of Logger.....	13
8.5 The Serial Interface	16
8.6 Pressure Connection	18
8.7 Error and System Messages.....	19
8.8 Calibration Services.....	19
9. Maintenance	20
9.1 Battery Operation.....	20
10. Technical Information.....	20
11. Order Codes	22
11.1 Accessories	23
12. Declaration of Conformance	24

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EC-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Manual Pressure Measuring Devices with External and Integrated Pressure Sensors model: HND-P231/HND-P233/HND-P236/HND-P239
- Operating Instructions

4. Regulation Use

Any use of the Manual Pressure Measuring Devices with External and Integrated Pressure Sensors, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The highly precise KOBOLD hand-held pressure measuring devices HND-P231/-P233/-P236 are measuring devices with integrated pressure sensors. They have two pressure measurement inputs on the top of the housing, which are connected to the measuring points by means of stable metal connections and plastic hoses that are available as accessories. Numerous measuring ranges in the overpressure and under pressure range are available for various measurement tasks, such as differential pressure measurement. In addition to pressure display, these first-rate, compact, universally applicable measuring units offer additional functions such as minimum/maximum value memory, a hold function, tare function, automatic self-shut-off, or zero point offset. The devices with an expanded spectrum of functions also have a logger function, a peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

The KOBOLD hand-held pressure measuring devices HND-P239 have an integrated pressure sensor for absolute pressure measurement. The measuring device is connected to the measuring point by means of a stable, metal connection on the top of the housing and an optional plastic hose. This device design offers the possibility of also displaying the barometric air pressure in relation to sea level »zero«. In this case, air pressure is corrected by entering the height above »zero« in meters. Naturally, these devices also have the minimum/maximum value memory, a hold function, a tare function, automatic self-shut-off function, and zero point adjustment. The KOBOLD HND-P239 devices also offer additional functions like the logger function, peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

6. Electrical Connection

6.1 Mains Operation with Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002. Prior to connecting the power supply to the mains, make sure that the operating voltage stated at the power supply is identical to the mains voltage.

7. Operation

7.1 General

7.1.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices. However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under *Technical Information*.

If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.

If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting.

Operator safety may be a risk if:

- there is visible damage to the device
- the device is not working as specified
- the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.


2. When connecting the device to other devices the connection has to be designed most thoroughly as internal connections in third-party devices (e.g. connection GND with protective earth) may lead to undesired voltage potentials that can lead to malfunctions or destroying of the device and the connected devices.
3. Do not use these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury or material damage. Failure to comply with these instructions could result in death or serious injury and material damage.



Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

HND-P231/-233/-236/-239

7.2 Connections




Connection for pressure tubes:

„+“ = higher pressure, „-“ = lower pressure

Interface: Connection for el. isolated interface adapter (p.r.t. chapter 8.5 Serial Interface)

The mains adapter socket is located at the left side of the device.

7.3 Display



- | | |
|---|--|
| 1 | Main display: shows actual value |
| 2 | Arrow points to the chosen measuring unit |
| 3 | Secondary display: shows min./max. or hold value |
| 4 | SL: appears if sea-level-correction is activated (only HND-P239) |
| 5 | Tara: appears if tara-function is activated |
| 6 | Logg: appears if logger function is chosen, flashes while logger is running |

7.4 Basic Operation



On / Off



min/max bei Messung:

press short: shows the min./max. value

press again: hides min./max. value



press 2 sec.: clears particular value

Tara, zero-point adjustment:

press short: display will be set to 0

The following measuring will be relatively displayed to the set tara value



press 2 sec.: deactivates tara-function

press 5 sec.: Zero-Point Adjustment¹⁾



Set/Menu:

press short: invokes configuration menu

Store/Quit:

press short: hold-function, the last measuring value will be held in the secondary display.



press again: hides the value

at active logger: invokes logger functions



Please Note: Activating/deactivating tara clears the max- & min-memories.

- 1) **Zero-Point Adjustment:** If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press button 3 for approx. 5 seconds (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu). To recall the manufacturer's calibration press button 3 for approx. 15 seconds.



Please Note: A zero-point adjustment can only be carried out if the difference between the value on display is less than 500 digits!

If a zero point adjustment was carried out the display shows "Corr" after a restart .

7.5 Operation


After turning on, if the logger function is not off, the time of the integrated clock will shortly be displayed. If a zero point adjustment was carried out the display shows shortly „nuLL Corr“.

After changing the battery the clock-setting menu is activated automatically (,CLOC'). Check the clock and adjust, if necessary (p.r.t. chapter 7.7).

7.6 Pop-up clip


Handling:

- Pull at label “open” in order to swing open the pop-up clip.
- Pull at label “open” again to swing open the pop-up clip further.



Function:

- The device with a closed pop-up clip can be plainly laid onto a table or attached to a belt, etc.
- The device with pop-up clip at position 90° can be set up on a table, etc.
- The device with pop-up clip at position 180° can be suspended from a screw or the magnetic holder.



7.7 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu (main display: „SEt“).

Pressing key **Menu** changes between the menus, pressing **▶** (key 3) jumps to the referring parameters, which can be selected with key **▶** (key 3).

The parameters can be changed with **▲** (key 2) or **▼** (key 5).

Pressing **Menu** again jumps back to the main configuration menu and saves the settings.

Quit (key 6) finishes the configuration and returns to standard measuring operation.

Menu	PARAM.	Values	Meaning	c_log	C_dat	Stor
„Menu“	▶	▲ or ▼				
SEt ConF	Set Configuration: Generic Configurations					
	Unit	mbar,bar..	Unit: Unit of display	*		*
	SL	oFF/on	Sea-Level: Sea level correction on/off (only HND-P239)	*		*
	Alti	-2000...9999	Altitude: Input of altitude above sea level [m] (only if SL=on) (only for HND-P239)	*		*
	rAtE		Rate: Measuring rate (p.r.t. chapter 8.1)	*		*
		Slo	Slow measuring rate (4 Hz filtered, low power consumption)	*		*
		FASt	Fast measuring rate, filtered (>1000 Hz)	*		*
		P.dEt	Peak detection: fast measuring rate, unfiltered (>1000 Hz)	*		*
	t.AVG	1-120	Averaging period in seconds, used by the averaging function	*		*
		oFF	Averaging function deactivated	*		*
	P.oFF	1-120	Auto Power Off time in minutes			
		oFF	Auto Power Off deactivated			
	Out	oFF	Function of the outout: No outout function, lowest power consumption			
		SEr	Output is serial interface			
		dAC	Outout is analogue output 0...1 V			
Adr.	01,11...91	Base address of interface				
dAC.0	p.r.t. chart	Enter desired value at which the analogue output potential should be 0 V (if Out=dAC)				
dAC.1	p.r.t. chart	Enter desired value at which the analogue output potential should be 1 V (if Out=dAC)				
Set CAL	Set Calibration: Adjustment of Sensor			*		
	OFFS	p.r.t. chart	The offset of sensor will be displaced by this value to compensate for deviations in the probe or in the measuring device.	*		
		oFF	Zero displacement inactive (=0.00)	*		
	SCAL	-2.000... 2.000	The measuring scale of sensor will be changed by this factor [%] to compensate deviations of temperature probe or measuring devices	*		
oFF		Scale correction factor inactive (=0.000)	*			

HND-P231/-233/-236/-239

Menu	PARAM.	Values	Meaning	C_log	C_dat	Stor
,Menu'	▶	▲ or ▼				
Set AL.	Set Alarm: Settings Of Alarm Function					
	AL.	On	Alarm on, with horn-sound			
		no.So	Alarm on, without horn-sound			
		oFF	Alarm deactivated			
	AL.Lo	p.r.t. chart	Min alarm rail (not when AL. oFF, Sensor-Min is the lower display range of connected sensor)			
	AL.Hi	p.r.t. chart	Max alarm rail (not when AL. oFF, Sensor-Max is the upper display range of connected sensor)			
Set LOGG	Set Logger: Configuration Of Logger Function			*		*
	Func	CYCL	Cyclic: logger function ,cyclic logger'	*	*	*
		Stor	Store: logger function ,individual value logger'	*	*	*
		oFF	no logger function	*	*	*
	CYCL	1..3600	Cycle time of cyclic logger [seconds]	*		*
	Lo.Po	on/oFF	Low-power logger with very low power consumption (only for cyclic logger and slow measuring rate)	*		*
Set CLOC	Set Clock: Setting Of Real Time Clock					
	CLOC	HH:MM	Clock: Setting of time hours:minutes			
	dAtE	TT.MM	Date: Setting of date day.month			
	YEAr	YYYY	Year: Setting of year			

C_log: cyclic Logger (active) C_dat: cyclic logger with data (no active logging) C_stor: individual value logger with data



Please Note: When using the logger function some settings in the menu may not be accessible (*). If these settings should be changed, the logger has to be stopped before, eventually the logger data has to be cleared. (key 6, p.r.t. chapter 8.4)

device type	analog output	adjustment of sensor	alarm function	
	dAC.0/dAC.1	OFFS	Al.Lo	Al.Hi
HND-P231	-1.00...25.00 mbar	-5.00..5.00 mbar	-1 mbar...AL.Hi	AL-Lo...25 mbar
HND-P233	-10.0...350.0 mbar	-50.0...50.0 mbar	-10 mbar...AL.Hi	AL.Lo...350 mbar
HND-P236	-100...2000 mbar	-500...500 mbar	-100 mbar...AL.Hi	AL.Lo...2000 mbar
HND-P239	0...13000 mbar abs.	-500...500 mbar	0 bar...AL.Hi	AL.LO...1300 mbar

8. Remarks to special features

8.1 Different Kinds of Measuring: „rAtE-Slo, -P.dEt, -FASt“

Three different kinds of measuring pressure are supported. Two of them are working with high measuring frequency of more than 100 measurings per second. If one of them was chosen in the configuration (see above), this will be displayed in the secondary display: „P.dEt“ or „FASt“.

8.1.1 rAtE-Slo: Standard Measuring

Measuring rate 4 Hz, averaging and filter functions are active.

Application: Measuring of slowly changing or static pressures, e.g. measuring of leakproofness, atmospheric pressure...

Highest accuracy, high noise immunity (EMI and unstable measuring signals), low power consumption.

8.1.2 rAtE-P.dEt: Peak detection

Measuring rate >1000 Hz, the value is displayed unfiltered.

Application with logger function: Measuring of short pressure peaks or fast changing pressures with a resolution of < 1 ms. The cyclic logger function records the arithmetic mean value, the highest and the lowest peak of the referring time interval.

Attention: higher power consumption, measuring is sensitive to noise (EMI,...).

8.1.3 rAtE-FASt: Fast filtered measuring

Measuring rate >1000 Hz, the value is filtered slightly (higher noise immunity than P.dEt, small peaks will be filtered out), apart from that identical behavior like P.dEt.

8.2 Sea Level Correction (only for HND-P239)

The device displays the absolute pressure measured at the sensor. This is not necessarily the same like the values given by weather stations! The weather stations' values are giving the pressure at sea level. Usually the sensor is placed above sea level and therefore, if the value at sea level (zero) is to be measured, the pressure loss resulting from the actual level above sea level has to be considered! To correct the measuring display, activate the „Sea-Level-Function“. Then enter the altitude above sea level of the sensor's location in meters (Alti, p.r.t. chapter 7.7). When activated, the display shows the SL-arrow and the device displays the pressure value at sea level.

8.3 Averaging Function

The averaging function concerns the display values (LCD and interface). It is completely independent from the averaging of the logger function, please don't mix them up!

The averaging integrates the measuring values during a selectable period of time and then calculates the average display value. It is independent from the selected kind of measuring (slow, fast, peak detect).

As long as not enough values are collected (selected averaging time) to calculate a average value, the upper display shows "----", the lower display a 'countdown'.

During an active low-power-logging procedure the avering is always deactivated
Function of min-/max-value memory during averaging:

- If averaging is activated and slow measuring is selected (rAtE-Slo), the min-/max-value memory refers to the average display value.
- If averaging is activated and fast measuring is selected (rAtE-FASt or P.dEt) , the min-/max-value memory refers to the internal measured values (fast peaks can be detected).

8.3.1 Power off Time

If there won't be pressed any key and no interface communication takes place for the time of the power off time setting (P.Off), the device will be switched off automatically to save battery power.

If P.oFF = oFF then the automatic switch off is deactivated.

8.3.2 Address

Up to 10 devices of the HND-handheld-family can be connected to a serial interface at once (depending on interface converter). To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on. See also chapter 8.5 Serial Interface.

8.3.3 Alarm

There are three possible settings: Alarm off (AL. oFF), on with horn sound (AL. on), on without horn sound (AL. no.So).

Following conditions will display an alarm, when the function is activated (on or no.So):

- Value is below lower (AL. Lo) or above upper alarm rail (AL.Hi).
- Sensor error (Sens Erro)
- Low battery (bAt)
- Fe 7: System error (always with sound)

In case of an alarm and when polling the interface, the prio-flag is set in the returned interface message.

8.3.4 Real Time Clock

The real time clock is used for the logger function: Recorded values are also containing the point of time, when they were measured. Please check the settings when necessary.

If the battery was replaced the referring menu ‚CLOC‘ will automatically be started.

8.4 Operation of Logger

The device supports two different logger functions:

„Func-Stor“: each time when „store“ (key 6) is pressed a measurement will be recorded.

„Func-CYCL“: measurements will automatically be recorded each interval, which was set in the logger menu ‚CYCL‘ until the logger will be stopped or the logger memory is full. The recording is started by pressing „Store“ 2 seconds.

The logger records 3 measurement results each time:

current or mean value (depending on logger setting, see below), min peak and max peak.

Min and max peak are the minimum resp. the maximum of the measured values since the last recording.

Using them allows f.e. analysis of fluctuating pressures.

For the evaluation of the data the software HND-Z034 has to be used. The software also allows easy configuration and starting of the logger.

When the logger is activated (Func Stor or Func CYCL) the hold function is no more available, the key 6 is solely used for the operation of the logger functions.

8.4.1 Func-Stor“: Storing Single Measurements

Each time when „store“ (key 6) is pressed a measurement and its time stamp will be recorded.

The recorded data can be viewed either in the display (when calling the configuration an additional menu ‚REAd LoGG“ is displayed, see below) or by means of the interface and a PC.

Max. number of measurings 99

A measuring contains:

- current measuring value at the time of recording
- min peak, max peak since the last recording
- time and date of the recording

After each recording „St. XX“ will be displayed for a short time. XX represents the number of the recording.

If logger memory contains recordings already:

When „Store“ is pressed for 2 seconds, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording



Clear nothing (cancel menu)



If the logger memory is full, the display will show:

Viewing Recorded Measurements

Within the „LoGG Stor“ function the measurements can be viewed directly in the display not only by means of a computer (like at „Func CYCL“): press 2 seconds „Set“ (key 4): The first menu displayed now is „rEAd LoGG“ (read logger data). After pressing \blacktriangleright (key 3) the measurement recorded last will be displayed, changing between the different values referring to the measurement also is done by pressing \blacktriangleright .

Changing the measurement is done by pressing the keys \blacktriangle or \blacktriangledown .

8.4.2 „Func-CYCL“: Automatic Recording with Selectable Logger-Cycle-Time

The Logger-Cycle-Time is setable (p.r.t. configuration).

For example „CYCL“ = 60: A measuring is recorded after each 60 seconds.

When the slow measurement "rAtE-Slo" is chosen, additionally a low power function is available: „Lo.Po“.

If „Lo.Po“ is on, the device only will take a measurement at the point of time of the recording. In between the recordings the measuring shut's down. This decreases the power consumption enormously and therefore is recommended e.g. for long time recordings where no mains adapter is available.

Max. number of measurements: 10000

Cycle time: 1...3600 seconds (=1 h), selectable in the configuration

A measuring contains:

- rAtE SLo: - current measuring value at the time of recording
- min peak, max peak since the last recording
- rAtE FASt,P.dEt - arithmetic mean value since the last recording
- min peak, max peak since the last recording

Starting a recording:

By pressing "Store" (key 6) for 2 seconds the recording will be initiated. After that the display shows 'St.XXXX' for a short time whenever a measuring is recorded. XXXX is the number of the measuring 1..10000.

If the logger memory is full, the display will show:  The recording

If Low-Power-Logger-Function „Lo.Po = on“ the device switches itself off as soon as the memory gets filled.

Stopping the recording manually:

By pressing "Store" (key 6) the recording can be stopped manually. Then the following choice appears:



Stop the recording



Do not stop the recording

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.




Note: If you try to switch off the instrument in the cyclic recording operation you will be asked once again if the recording is to be stopped. The device can only be switched off after the recording has been stopped! The Auto-Power-Off-function is deactivated during recording!

Clear Recordings:

When „Store“ is pressed for 2 seconds, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear nothing (cancel menu)

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.

8.5 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031) the device can be connected to a computer for data transfer. To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

- **HND-Z034**: Operation and read out of logger function, data display in diagrams and tables
- **BUS-S20M**: 20-channel software to display the measuring values

The device has 3 channels:

- 1: current measuring value (base address)
- 2: min peak (p.r.t. chapter 8.4)
- 3: max peak (p.r.t. chapter 8.4)



Note: The measuring-/ alarm- and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Channel			Code	Name/Function	Channel			Code	Name/Function
1	2	3			1	2	3		
x	x	x	0	Read measurement value	x	x	x	201	Read max display range
x	x	x	3	Read system state	x	x	x	202	Read display range - unit
x			6	Read min memory	x	x	x	204	Read display range – decimal point
x			7	Read max memory	x			208	Read # of channels
x	x	x	12	Read ID number	X			214	Read scale adjustment
x			22	Read min alarm rail (AL. - AL.Lo)	X			216	Read offset adjustment
x			23	Read max alarm rail (AL. - AL.Hi)	X			220	Read offset adjustment
x			32	Read configuration flag	X			221	Read altitude *
				BitAlarmOn:1; BitAlarmSound:3;	x			222	Set altitude *
				BitPeakDetection:33; BitFastFiltered:34;	x			223	Set power off time (Conf-P.off)
				BitLoggerOn:50; BitCyclicLogger:51;	x	x	x	224	Logger: Read data of CYCL-Logger
			52	BitLowPowerLogger:52					
x			102	Set min alarm rail (AL. - AL.Lo)	x			225	Logger: Read cycle time (LoGG - CYCL)
x			103	Set max alarm rail (AL. - AL.Hi)	x			226	Logger: set cycle time (LoGG - CYCL)
x			160	Set configuration flag (refer to 32)	x			227	Logger: start recording
x			174	Clear min memory	x			228	Logger: Read # of recordings made
x			175	Clear max memory	x			229	Logger: Read state
x	x	x	176	Read min measuring range	x			231	Logger: Read stop time
x	x	x	177	Read max measuring range	x			233	Read real time clock (CLOC)
x	x	x	178	Read measuring range – measuring unit	x			234	Set real time clock (CLOC)
x	x	x	179	Read measuring range – decimal point	X			236	Read logger memory size
x	x	x	180	Read kind of measuring of sensor	X			240	Reset
x	x	x	199	Read kind of measuring of display	X			254	Program version
x	x	x	200	Read min display range	x			260	Logger: read data of STOR logger

* only available at HND-P239

8.6 Pressure Connection

8.6.1 Device type with absolute pressure (HND-P239)

Connect plastic tube to pressure port.

8.6.2 Device type with relative pressure

- **For measurements of over pressure** (refer to summary):
Connect plastic tube with internal dia of 4 mm to pressure port "+". Port "-" will not be used!
- **For measurements of under pressure** (refer to summary):
Plug the tube to pressure port "-". The measuring range covers then up to max. overpressure range.



Note: All values are displayed now as positive values. No minus sign will be shown.




Example: it is possible to measure under pressure down to -25.00 mbar, the display shows then the value 25.00 (no minus sign).

- **For measurements of pressure differences:**
Connect both plastic tubes with an internal dia of 4 mm to pressure port "+" and "-"; make sure to apply higher pressure to port "+".

Measure ranges:

device type	over- or underpressure	underpressure
HND-P231	-1.00...25.00 mbar	-25.00...0.00 mbar
HND-P233	-10.00...350.0 mbar	-350.0...0.0 mbar
HND-P236	-100...2000 mbar	-2000...0 mbar

8.7 Error and System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
	Logger data are read by the interface	When transfer completed the device will automatically return to normal measuring display, no remedy necessary
No display or confused characters device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
Err.1	Measured value above allowable range	Check: pressure above 350 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.2	Measured value below allowable range	Check: pressure below -10 mbar? -> measuring value to low
Err.4	Sensor defective	Return to manufacturer for repair
Err.9	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
Err.7	System error	Return to manufacturer for repair

8.8 Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certificated for its accuracy, it is the best solution to return it to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

9. Maintenance

9.1 Battery Operation

If 'bAt' is shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up. The battery has to be taken out, when storing device above 50 °C.



Please note: We recommend taking out battery if device is not used for a longer period of time!

10. Technical Information

HND-P231:

Measuring range¹⁾: -1.0 to 25.0 mbar
Overload²⁾: max. 100 mbar
Resolution: 1 Pa (0.01 mbar)
Accuracy: ±0.3 % F.S.
(Hysteresis and linearity)
±0.4 % F.S.
(in the range of 0-50 °C)
Units: mbar, bar, Pa, kPa, PSI, m H₂O
(display "m")

HND-P233:

Measuring range¹⁾: -10.0 to 350.0 mbar
Overload²⁾: max. 1 bar
Resolution: 0.1 mbar
Accuracy: ±0.2 % F.S.
(Hysteresis and linearity)
±0.4 % F.S.
(in the range of 0-50 °C)
Units: mbar, bar, kPa, MPa, mmHg, PSI, m H₂O
(display "m")

HND-P236:

Measuring range¹⁾: -100.0 to 2000.0 mbar
Overload²⁾: max. 4 bar
Resolution: 1 mbar
Accuracy: ±0.2 % F.S.
(Hysteresis and linearity)
±0.4 % F.S.
(in the range of 0-50 °C)
Units: mbar, bar, kPa, MPa, mmHg, PSI, m H₂O
(display "m")

HND-P239:

Measuring range ¹⁾ :	0 to 1300.0 mbar absolute
Overload ²⁾ :	max. 4 bar absolute
Resolution:	1 mbar
Accuracy:	±0.2 % F.S. (Hysteresis and linearity) ±0.4 % F.S. (in the range of 0-50 °C)
Units:	mbar, bar, kPa, MPa, mmHg, PSI, m H ₂ O (display "m")

¹⁾ *underpressure measurement up to the overpressure measuring range suitable (refer to chapter 8.6.2)*

²⁾ *without destruction or recalibration of sensor being necessary*

Measurement input: by means of two (HND-P239: one) metal hose stems

Sensor: **piezo-resistive relative pressure sensor, for air or non-corrosive and non-ionising gases and liquids, not for water!**

Display: 2 x 4½ - digit LC-displays
Operating temp.: -20 to +50 °C
Storage temp.: -20 to +70 °C
Storage humidity: 0 to 95 % r.H. (non-condensing)
Output: serial interface
(via 3-pin jack, transformer on RS232 or USB optional)

Power supply: 9 V-monobloc battery
(included in the scope of delivery),
extern 10.5-12 V_{DC} via jack

Current consumpt.: < 1 mA (HND-P121...),
max. 3 mA (HND-P231...)

Material: housing made of impact-resistant
ABS plastic

Degree of protect.: IP65, front
Dimensions: 142 x 71 x 26 mm (HxWxD)
Weight: approx. 170 g

Scope of functions:

Minimum/maximum value memory

Hold function: »freezing« of the current value

Automatic-off function: 1...120 min (can be deactivated)

Zero point adjustment via keyboard possible

Tare function:

display, minimum/maximum values are set to zero

Battery change notification

HND-P231/-233/-236/-239

Minimum/maximum alarm can be deactivated

Alarm (3 alarm settings)

Off: Alarm function inactive
On: Alarm notification via display, internal horn and serial interface
No Sound: Alarm notification only via display and interface

Averaging

Peak value memory unfiltered pressure peaks ≥ 1 msec

Adjustable measuring cycle:

»slow« 4 measurements/sec
»fast« ≥ 1000 measurements/ sec (filtered)
»peak-detect« ≥ 1000 measurements/sec

Power saving mode for measuring cycle »slow«

Real-time clock: current time

Logger functions:

Manual: 99 datasets
Cyclic: 10000 datasets
Adjustable cycle time: 1 sec...1 h

11. Order Codes

Order-no.	Housing design
HND-P231	2 measuring inputs with additional functions (see techn. data)
HND-P233	2 measuring inputs with additional functions (see techn. data)
HND-P236	2 measuring inputs with additional functions (see techn. data)
HND-P239	1 pressure sensor input with additional functions (see techn. data)

11.1 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10,5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
BUS-S20M	Software for recording measuring data on a PC for 20 modules, for devices of the HND-series without logger function
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose $\frac{6}{4}$ on hose $\frac{6}{4}$
HND-Z082	Hose clamp for hose $\frac{6}{4}$
HND-Z083	Adapter made of brass for G $\frac{1}{4}$ internal threads on hose $\frac{6}{4}$
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

* observe instrument dimensions
Additional accessories on request

12. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Manual Pressure Measuring Devices with External and Integrated Pressure Sensors Model: HND-P231/-P233/-P236/-P239

to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and laboratory use. EMC requirements


Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline


Hofheim, 27. Mai 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Handheld Pressure Measuring Devices
with Integrated Pressure Sensors

Model: HND-P236



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Electrical Connection	4
6.1 Mains Operation With Power Supply	4
7. Operation / Configuration / Adjustments	5
7.1 General	5
7.2 Configuration	7
7.3 Operation Of Logger	10
7.4 The Serial Interface	14
7.5 Pressure Connection To The Sensors	15
7.6 Error And System Messages	15
7.7 Calibration Services	16
8. Maintenance	16
8.1 Battery Operation.....	16
9. Technical Information.....	16
10. Order Codes	18
10.1 Accessories	18
11. Declaration of Conformance	19

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Handheld Pressure Measuring Devices with Integrated Pressure Sensors
model: HND-P236
- Operating Instructions

4. Regulation Use

Any use of the Manual Pressure Measuring Devices with External and Integrated Pressure Sensors, model: HND-P236, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The highly precise KOBOLD handheld pressure measuring devices HND-P236 are measuring devices with integrated pressure sensors. They have two pressure measurement inputs on the top of the housing, which are connected to the measuring points by means of stable metal connections and plastic hoses that are available as accessories. Numerous measuring ranges in the overpressure and underpressure range are available for various measurement tasks, such as differential pressure measurement. In addition to pressure display, these first-rate, compact, universally applicable measuring units offer additional functions such as minimum/maximum value memory, a hold function, tare function, automatic self-shut-off, or zero point offset. The devices with an expanded spectrum of functions also have a logger function, a peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

6. Electrical Connection

6.1 Mains Operation With Power Supply



Warning: When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!! Cheap 12 V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002. Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

7. Operation / Configuration / Adjustments

7.1 General

7.1.1 Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices.

However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under "Specification".
2. Device and sensors have to be handled with care (don't throw, hit, etc.). Protect plugs and sockets from soiling.
3. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
4. If device is to be connected to other devices (e.g. via serial interface) the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.




Warning: If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

5. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be a risk if:
 - there is visible damage to the device
 - the device is not working as specified
 - the device has been stored under unsuitable conditions for a longer period of time.

In case of doubt, please return device to manufacturer for repair or maintenance.

7.1.2 Connections



The mains adapter socket is located at the left side of the device.

7.1.3 Display

Units: an arrow points to the chosen measuring unit
SL: no function

Tara: appears if tara-function is activated




main display: shows measuring value
secondary display: shows min-, max- or hold value

Logg: appears, if logger function is chosen, flashes when logger is running

7.1.4 Basic Operation

When switching on the device and the logger function is not off the time of the integrated clock will shortly be displayed. If a **zero point adjustment** was carried out the display shows shortly „nuLL Corr“.

After changing the battery the clock-setting menu is activated automatically („CLOC“). Check the clock and adjust, if necessary (p.r.t. chapter 7.2 Configuration).



On-/Off-Switch

Tara: Calling of tara function, zero point adjustment

min/max: Showing the min- resp. max-memory in sec. display

Store/Quit: Calling of hold function resp. calling of logger functions (p.r.t. ch. 7.3 Operation Of Logger)

Set/Menu: Calling of configuration

Max Memory: Pressing 'max' (key 2) shows the maximum of the measured values. Pressing it again hides it. To clear the max memory press key 'max' for >2 seconds.

Min Memory: Pressing 'min' (key 5) shows the minimum of the measured values. Pressing it again hides it. To clear the min memory press key 'min' for >2 seconds.

Hold Function: By pressing 'Store/Quit' (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it. (only when logger = ,off').

Tare Function: By pressing 'Tara' (key 3) the display will be set to 0. All measurements from then on will be displayed relatively to the set tare value. When tara function is activated, the arrow "Tara" appears in the display. To deactivate tare function press 'Tara' for >2 seconds.

Please Note: Activating/deactivating tara clears the max- & min-memories.

Zero-Point Adjustment: If there is no pressure or zero-pressure (absolute) applied to the pressure ports the device will display 0. If there is a permanent deviation (and device is operated under steady conditions), a permanent zero point adjustment can be carried out. To carry out the adjustment press button 3 for approx. 5 seconds (Auto Null will be displayed shortly). The adjustment is done via the OFFSET-value of the sensor (referring configuration menu).

Please note: A zero-point adjustment can only be carried out if the difference between the value on display is less than 500 digits.

To recall the manufacturer's calibration press button 3 for approx. 15 seconds.

7.2 Configuration

To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu (main display: „SEt“).

Pressing key **Menu** changes between the menus, pressing **▶** (key 3) jumps to the referring parameters, which can be selected with key **▶** (key 3).

The parameters can be changed with **▲** (key 2) or **▼** (key 5).

Pressing **Menu** again jumps back to the main configuration menu and saves the settings.

Quit (key 6) finishes the configuration and returns to standard measuring operation.

	PARAM.	Values	Meaning	C log	C dat	Stor
„Menu“	▶	▲ or ▼				
SEt ConF	Set Configuration: Generic Configurations					
	Unit	mbar, bar..	Unit: Unit of display	*		*
	rAtE		Rate: Measuring rate (p.r.t. chapter 7.2.1 <i>Different Kinds Of Measuring: „rAtE-Slo, -P.dEt, -FASt“</i>)	*		*
		Slo	Slow measuring rate (4 Hz filtered, low power consumption)	*		*
		FASt	Fast measuring rate, filtered (>100 Hz)	*		*
		P.dEt	Peak detection: fast measuring rate, unfiltered (>100 Hz)	*		*
	t.AVG	1-120	Averaging period in seconds, used by the averaging function	*		*
		oFF	Averaging function deactivated	*		*
	P.oFF	1-120	Auto Power Off time in minutes			
		oFF	Auto Power Off deactivated			
	Out	oFF	Function of the output			
		Ser	Output is serial interface			
		dAC	Output is analogue output 0...1 V			
	Adr.	01, 11..91	Base address of interface			
dAC.0	-100... 2000 mbar	Enter desired value which the analogue output potential should be 0V (if Out=dAC)				
dAC.1	-100... 2000 mbar	Enter desired value at which the analogue output potential should be 1V (if Out=dAC)				
Set CAL	Set Calibration: Adjustment of Sensor			*		
	OFFS	-500... 500 mbar	The offset of sensor will be displaced by this value to compensate for deviations in the probe or in the measuring device.	*		
		oFF	Zero displacement inactive (=0.00)	*		
	SCAL	-2.000... 2.000	The measuring scale of sensor will be changed by this factor [%] to compensate deviations of temperature probe or measuring device	*		
oFF		Scale correction factor inactive (=0.000)	*			
Set AL.	Set Alarm: Settings Of Alarm Function					
	AL.	On	Alarm on , with horn-sound			
		no.So	Alarm on, without horn-sound			
		oFF	Alarm deactivated			
	AL.Lo	-100 mbar ... AL.Hi	Min alarm rail (not when AL. oFF, Sensor-Min is the lower display range of connected sensor)			
AL.Hi	AL.Lo ... 2000 mbar	Max alarm rail (not when AL. oFF, Sensor-Max is the upper display range of connected sensor)				

SEt	Set Logger: Configuration Of Logger Function		*		*
LoGG	Func	CYCL	Cyclic: logger function ,cyclic logger‘		
		Stor	Store: logger function ,individual value logger‘		
		oFF	no logger function		
	CYCL	1..3600	Cycle time of cyclic logger [seconds]		
	Lo.Po	on/oFF	Low-power logger with very low power consumption (only for cyclic logger and slow measuring rate)		
SEt	Set Clock: Setting Of Real Time Clock				
CLOC	CLOC	HH:MM	Clock: Setting of time hours:minutes		
	dAtE	TT.MM	Date day.month		
	YEAr	YYYY	Year		



Note: If the logger memory contains data already, the menus/parameters marked with (*) can not be invoked! If these should be altered the logger memory has to be cleared before! (key 6, p.r.t. chapter 7.3 Operation Of Logger)

7.2.1 Different Kinds Of Measuring: „rAtE-Slo, -P.dEt, -FASt“

Three different kinds of measuring pressure are supported. Two of them are working with high measuring frequency of more than 1000 measurings per second. If one of them was chosen in the configuration (see above), this will be displayed in the secondary display: „P.dEt“ or „FASt“.

7.2.1.1 rAtE-Slo: Standard Measuring

Measuring rate 4 Hz, averaging and filter functions are active.

Application: Measuring of slowly changing or static pressures, e.g. measuring of leakproofness, atmospheric pressure...

Highest accuracy, high noise immunity (EMI and unstable measuring signals), low power consumption.

7.2.1.2 rAtE-P.dEt: Peak detection

Measuring rate >1000 Hz, the value is displayed unfiltered.

Application with logger function: Measuring of short pressure peaks or fast changing pressures with a resolution of < 1 ms. The cyclic logger function records the arithmetic mean value, the highest and the lowest peak of the referring time interval.

Attention: higher power consumption, measuring is sensitive to noise (EMI,...).

7.2.1.3 rAtE-FASt: Fast filtered measuring

Measuring rate >1000 Hz, the value is filtered slightly (higher noise immunity than P.dEt, small peaks will be filtered out), apart from that identical behaviour like P.dEt.

7.2.2 Averaging Function

The averaging function concerns the display values (LCD and interface). It is completely independent from the averaging of the logger function, please don't mix them up!

The averaging integrates the measuring values during a selectable period of time and then calculates the average display value. It is independent from the selected kind of measuring (slow, fast, peak detect).

As long as not enough values are collected (selected averaging time) to calculate a average value, the upper display shows "----", the lower display a 'countdown'.

During an active low-power-logging procedure the averaging is always deactivated
Function of min-/max-value memory during averaging:

- If averaging is activated and slow measuring is selected (rAtE-Slo), the min-/max-value memory refers to the average display value.
- If averaging is activated and fast measuring is selected (rAtE-FAST or P.dEt) , the min-/max-value memory refers to the internal measured values (fast peaks can be detected).

7.2.3 Zero Displacement Sensor

A zero displacement can be carried out for the measured value:

$$\text{value displayed} = \text{value measured} - \text{offset}$$

Standard setting: `off` = 0.0, i.e. no zero displacement will be carried out.

Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations. Input is in the display unit.

7.2.4 Scale Correction Sensor (`SCAL`)

The scale of the measuring can be influenced by this setting (factor is in %):

$$\text{displayed value} = \text{measured value} * (1 + \text{SCAL} / 100)$$

Standard setting: `off` = 0.000, i.e. value is not corrected. Together with the zero displacement (see above) this factor is mainly used to compensate for sensor deviations.

7.2.5 Power Off Time

If there won't be pressed any key and no interface communication takes place for the time of the power off time setting (P.Off), the device will be switched off automatically to save battery power.

If P.oFF = oFF then the automatic switch off is deactivated.

7.2.6 Output

The output can be used as a serial interface (for HND-Z031, HND-Z034 interface adapters) or as analogue output (0-1V).

7.2.6.1 Interface – Base Address (`Adr.`)

Up to 10 devices of the HND-P-handheld-family can be connected to a serial interface at once (depending on interface converter). To get access to each

device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on.

7.2.7 Address

Up to 10 devices of the HND-Pxxx- handheld-family can be connected to a serial interface at once (depending on interface converter). To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on. See also chapter 7.4 *The Serial Interface*.

7.2.8 Alarm

There are three possible settings: Alarm off (AL. oFF), on with horn sound (AL. on), on without horn sound (AL. no.So).

Following conditions will display an alarm, when the function is activated (on or no.So):

- Value is below lower (AL. Lo) or above upper alarm rail (AL.Hi).
- Sensor error (Sens Erro)
- Low battery (bAt)
- Fe 7: System error (always with sound)

In case of an alarm and when polling the interface the prio-flag is set in the returned interface message.

7.2.9 Real Time Clock

The real time clock is used for the logger function: Recorded values are also containing the point of time, when they were measured. Please check the settings when necessary.

If the battery was replaced the referring menu ‚CLOC‘ will automatically be started.

7.3 Operation Of Logger

The device supports two different logger functions:

„Func-Stor“: each time when „store“ (key 6) is pressed a measurement will be recorded.

„Func-CYCL“: measurements will automatically be recorded each interval, which was set in the logger menu ‚CYCL‘ until the logger will be stopped or the logger memory is full. The recording is started by pressing „Store“ 2 seconds.

The logger records 3 measurement results each time:

current or mean value (depending on logger setting, see below), min peak and max peak.

Min and max peak are the minimum resp. the maximum of the measured values since the last recording.

Using them allows f.e. analysis of fluctuating pressures.

For the evaluation of the data the software HND-Z034 has to be used. The software also allows easy configuration and starting of the logger. When the logger is activated (Func Stor or Func CYCL) the hold function is no more available, the key 6 is solely used for the operation of the logger functions.

7.3.1 „Func-Stor“: Storing Single Measurements

Each time when „store“ (key 6) is pressed a measurement and its time stamp will be recorded.

The recorded data can be viewed either in the display (when calling the configuration an additional menu „REAd LoGG“ is displayed, see below) or by means of the interface and a PC with HND-Z034-software.

Max. number of measurements: 99

A measuring contains:

- current measuring value at the time of recording
- min peak, max peak since the last recording
- time and date of the recording

After each recording „St. XX“ will be displayed for a short time. XX represents the number of the recording.

If logger memory contains recordings already:

When „Store“ is pressed for 2 seconds, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording



Clear nothing (cancel menu)

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.

If the logger memory is full, the display will show:



Viewing Recorded Measurements

Within the „LoGG Stor“ function the measurings can be viewed directly in the display not only by means of a computer (like at „Func CYCL“): press 2 seconds „Set“ (key 4): The first menu displayed now is „rEAd LoGG“ (read logger data). After pressing ▶ (key 3) the measurement recorded last will be displayed, changing between the different values referring to the measurement also is done by pressing ▶. Changing the measurement is done by pressing the keys ▲ or ▼.

7.3.2 „Func-CYCL“: Automatic Recording With Selectable Logger-Cycle-Time

The Logger-Cycle-Time is setable (p.r.t. Configuration). For example „CYCL“ = 60: A measuring is recorded after each 60 seconds.

When the slow measurement "rAtE-Slo" is chosen, additionally a low power function is available: „Lo.Po“.

If „Lo.Po“ is on, the device only will take a measurement at the point of time of the recording. In between the recordings the measuring shut's down. This decreases the power consumption enormously and therefore is recommended e.g. for long time recordings where no mains adapter is available.

Max. number of measurings: 10000

Cycle time: 1...3600 seconds (=1h), selectable in the configuration

A data set contains:

- rAtE SLo: - current measuring value at the time of recording
- min peak, max peak since the last recording
- rAtE FASt,P.dEt - arithmetic mean value since the last recording
- min peak, max peak since the last recording

7.3.2.1 Starting a recording:

By pressing "Store" (key 6) for 2 seconds the recording will be called. The display



will show:

By pressing "Store" again the recording will be initiated. After that the display shows 'St.XXXX' for a short time whenever a measuring is recorded. XXXX is the number of the measuring 1..10000.



If the logger memory is full, the display will show: The recording automatically will be stopped.

If Low-Power-Logger-Function „Lo.Po = on“ the device switches itself off as soon as the memory gets filled.

7.3.3 Stopping the recording manually:

By pressing "Store" (key 6) the recording can be stopped manually. Then the following choice appears:



Stop the recording



Do not stop the recording

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.



Note: If you try to switch off the instrument in the cyclic recording operation You will be asked once again if the recording is to be stopped. The device can only be switched off after the recording has been stopped! The Auto-Power-Off-function is deactivated during recording!

7.3.4 Clear Recordings:

By pressing „Store“ (key 6) for 2 seconds the logger memory will be called.



The display will show: By pressing the keys ▲ (key 2) or ▼ (key 5) the



display will change to . When "Store" is pressed, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear nothing (cancel menu)

The selection can be made by ▲ (key 2) and ▼ (key 5). "Quit" (key 6) enters the choice.

7.4 The Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (HND-Z031 or HND-Z032) the device can be connected to a computer for data transfer.

To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available:

HND-Z034: Operation and read out of logger function, data display in diagrams and tables

BUS-SW9M: 9-channel software to display the measuring values

The device has 3 channels:

1. 1: current measuring value (base address)
2. 2: min peak (p.r.t. chapter 7.3 Operation Of Logger)
3. 3: max peak (p.r.t. chapter 7.3 Operation Of Logger)



Note: The measuring-/ alarm- and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Channel				Code	Name/Function	Channel				Code	Name/Function	
1	2	3				1	2	3				
x	x	x		0	Read measurement value	x	x	x	200	Read min display range		
x	x	x		3	Read system state	x	x	x	201	Read max display range		
x				6	Read min memory	x	x	x	202	Read display range - unit		
x				7	Read max memory	x	x	x	204	Read display range – decimal point		
x	x	x		12	Read ID number	x			208	Read # of channels		
x				22	Read min alarm rail (AL. - AL.Lo)	x			214	Read scale adjustment [%]		
x				23	Read max alarm rail (AL. - AL.Hi)	x			216	Read offset adjustment		
x				32	Read configuration flag BitAlarmOn:1; BitAlarmSound:3; BitPeakDetection:33; BitFastFiltered:34; BitLoggerOn:50; BitCyclicLogger:51; BitLowPowerLogger:52	x			222	Read power off time (Conf-P.oFF)		
						x				223	Set power off time (Conf-P.oFF)	
						x	x	x	224	Logger: Read data of CYCL- Logger		
						x			225	Logger: Read cycle time (LoGG - CYCL)		
						x			226	Logger: set cycle time (LoGG - CYCL)		
x				102	Set min alarm rail (AL. - AL.Lo)	x			227	Logger: start recording		
x				103	Set max alarm rail (AL. - AL.Hi)	x			228	Logger: Read # of recordings made		
x				160	Set configuration flag (refer to 32)	x			229	Logger: Read state		
x				174	Clear min memory	x			231	Logger: Read stop time		
x				175	Clear max memory	x			233	Read real time clock (CLOC)		
x	x	x		176	Read min measuring range	x			234	Set real time clock (CLOC)		
x	x	x		177	Read max measuring range	x			236	Read logger memory size		
x	x	x		178	Read measuring range – measuring unit	x			240	Reset		
x	x	x		179	Read measuring range – decimal point	x			254	Program version		
x	x	x		180	Read kind of measuring of sensor	x			260	Logger: read data of STOR Logger		
x				194	Set display unit							
x	x	x		199	Read kind of measuring of display							

7.5 Pressure Connection To The Sensors

For measurements of over pressure (-100 mbar...2000 mbar):

Connect plastic tube with internal dia of 4 mm to pressure port "+". Port "-" will not be used!

For measurements of under pressure (-2000 mbar...0 mbar):

Plug the tube to pressure port "-". The measuring range covers then -2000 to 0 mbar.




Note: All values are displayed now as positive values. No minus sign will be shown.

Example: it is possible to measure under pressure down to -2000 mbar, the display shows then the value 2000 (no minus sign).

For measurements of pressure differences:

Connect both plastic tubes with an internal dia of 4 mm to pressure port "+" and "-"; make sure to apply higher pressure to port "+".

7.6 Error and System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
	Logger data are read by the interface	When transfer completed the device will automatically return to normal measuring display, no remedy necessary
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
Err.1	Measured value above allowable range	Check: pressure above 2000 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.2	Measured value below allowable range	Check: pressure below -100 mbar? -> measuring value to low
	Sensor defective	Return to manufacturer for repair
Err.4	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
Err.9	Measured value far out of allowable range	Check: pressure not within sensor range?
Err.7	System error	Return to manufacturer for repair

7.7 Calibration Services


Calibration certificates – DKD-certificates – other certificates:

If device should be certificated for its accuracy, it is the best solution to return it to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

8. Maintenance

8.1 Battery Operation

If  and 'bAt' are shown in the secondary display the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up. The battery has to be taken out, when storing device above 50 °C.



Please note: We recommend to take out battery if device is not used for a longer period of time!

9. Technical Information

Measuring range:	-100 to 2000 mbar relative (under pressure down to -2000 mbar, p.r.t.)
-option: MB: -1...2 bar	-1000 to 2000 mbar relative (under pressure down to -2000 mbar, p.r.t.)
Overload:	max. 4000 mbar rel. (without destruction or recalibration of sensor being necessary)
Resolution:	1 mbar
Pressure units:	mbar, bar, kPa, MPa, mmHg, PSI, mH ₂ O (display `m`), selectable
Accuracy: (typ.)	±0.2 % F.S. (hysteresis and linearity) ±0.4 % F.S. (temperature dependency 0-50 °C)
-option: higher accuracy:	±0.1 % F.S. (hysteresis and linearity) ±0.4 % F.S. (temperature dependency 0-50 °C)
Measuring rate:	slow: 4 meas./sec(ConF-Rate = Slow) fast: >1000 meas./sec (ConF-Rate=FASt and P.dEt)
Nominal temperature:	25 °C
Sensor:	piezo-resistive relative pressure sensor integrated in device.

		Suitable for air and non-corrosive and non-ionising gases and liquids. Not suitable for water-use air buffering)
Connexion:		2 metal pressures ports for connection to 6x1 mm tubes at the top of device (4 mm inner tube \varnothing)
Logger:		2 Functions: individual value logger ("Func-Stor") and cyclic logger ("Func-CYCL")
Memory:	Stor:	99 data sets
	CYCL:	10000 data sets (in max. 64 recording sequences)
Cycle time CYCL:		1...3600 seconds
Display:		2 four digit LCDs (12.4 mm high and 7 mm high) for measuring values, and for min/max memories, hold function, etc. As well as additional functional arrows.
Pushbuttons:		6 membrane keys
Output:		3.5 mm audio plug, stereo
Output function:		selectable as serial interface or analogue output
Interface:		Serial interface (3.5 mm jack) can be connected to RS232 or USB interface of a PC via electrically isolated interface adapter.
Analogue output:		0...1 Volt, freely scalable (resolution 12 bit)
Power supply:		9 V battery, type: IEC 6F22 (included in the scope of supply) As well as additional d.c. connector (diameter of internal pin 1.9 mm) for external 10.5-12 V direct voltage supply.
Power consumption:		Slow measuring rate: ~0.6 mA Fast measuring rate: <2.5 mA Low-Power-Logger: <0,1 mA (for cycle time >30s, without interface communication active and no alarm horn sounding) up to 0.4 mA (at cycle-time 1s)
Low battery warning:		`bAt`
Additional functions:		
Power-Off-Function:		Device will be automatically switched off if no key is pressed/no interface communication takes place for the time of the power-off delay. The power-off delay can be set to values between 1 and 120 min.; it can be completely deactivated.
Min/Max Alarm:		The measuring value is constantly monitored for the min and max rails set. Alarming is done by integrated horn, display and interface
Real-time clock:		Integrated clock with date and year
Housing:		impact-resistant ABS, membrane keyboard, transparent panel, Front side IP65
Dimensions:		142x71x26 mm (LxWxD)
Weight:		approx. 165 g
Working temperature:		-20...+50 °C
Allowable rel. humidity:		0...95 % RH (not condensing)
Storage temperature:		-20...+70 °C

10. Order Codes

Order-no.	Housing design
HND-P236	2 measuring inputs with additional functions (see techn. data)

10.1 Accessories

Order-no.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/60 Hz), 10.5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection
HND-Z021*	Case with recess (275 x 229 x 83 mm)
HND-Z022*	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023*	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Interface converter on USB, galvanically isolated
HND-Z033	Adapter RS232 converter on USB- interface
HND-Z034	Windows software for setting and data read- and print-out of instruments of the HND- series with logger function
HND-Z081	Double nozzle for hose 6.4 on hose 6.4
HND-Z082	Hose clamp for hose 6.4
HND-Z088	Adapter made of brass for G ½ internal threads on hose 6.4
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

* Pay attention to instrument dimensions

Further Accessories on request

11. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

**Handheld Pressure Measuring Devices with Integrated Pressure Sensors
Model: HND-P236**

to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and laboratory use. EMC requirements

Also the following EC guidelines are fulfilled:

2004/108/EC Electromagnetic compatibility
2006/95/EC Low voltage guideline

Hofheim, 8. May 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder



Operating Instructions
for
Handheld Digital Pressure Meter
with internal pressure sensor

Model: HND-P239



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	4
6. Safety Requirements.....	4
7. Electrical Connection	5
8. Operation	6
9. Configuration.....	7
9.1 Different Kinds Of Measuring: „rAtE-Slo, -P.dEt, -FASt“	8
9.2 Sea Level Correction	8
9.3 Averaging Function	9
9.4 Power Off Time.....	9
9.5 Address.....	9
9.6 Alarm	9
9.7 Real Time Clock	10
10. Operation Of Logger	10
10.1 „Func-Stor“: Storing Single Measurements.....	10
10.2 „Func-CYCL“: Automatic Recording With Selectable Logger-Cycle-Time	
11	
11. The Serial Interface.....	13
12. Error And System Messages	14
13. Calibration Services	14
14. Maintenance	15
14.1 Battery Operation.....	15
15. Technical Information.....	15
16. Order Codes	17
16.1 Accessories for HND-P	17
17. Declaration of Conformance	18

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Handheld Digital Pressure Meter with internal pressure sensor
model: HND-P239
- Operating Instructions

4. Regulation Use

Any use of the Handheld Digital Pressure Meter, model: HND-P239, which exceeds the manufacturer's specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The KOBOLD Handheld Digital Pressure Meters HND-P239 have an integrated pressure sensor for absolute pressure measurement. The measuring device is connected to the measuring point by means of a stable, metal connection on the top of the housing and an optional plastic hose. This device design offers the possibility of also displaying the barometric air pressure in relation to sea level »zero«. In this case, air pressure is corrected by entering the height above »zero« in meters. Naturally, these devices also have the minimum/maximum value memory, a hold function, a tare function, automatic self-shut-off function, and zero point adjustment. The HND-P239 devices also offer additional functions like the logger function, peak value memory, minimum/maximum alarm, an adjustable measuring cycle, and averaging.

6. Safety Requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices.

However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under "Technical Information".
2. If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
3. If device is to be connected to other devices the circuitry has to be designed most carefully. Internal connection in third party devices (e.g. connection GND and earth) may result in not-permissible voltages impairing or destroying the device or another device connected.



Warning! If device is operated with a defective mains power supply (e.g. short circuit from mains voltage to output voltage) this may result in hazardous voltages at the device (e.g. at sensor socket or interface).

4. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be a risk if:
- there is visible damage to the device
 - the device is not working as specified
 - the device has been stored under unsuitable conditions for a longer period of time.
- In case of doubt, please return device to manufacturer for repair or maintenance.

7. Electrical Connection


By operation with external power supply:

When using a power supply please note that operating voltage has to be 10.5 to 12 V_{DC}. Do not apply overvoltage!!! Cheap 12V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies. Trouble-free operation is guaranteed by our power supply HND-Z002. Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

8. Operation

When switching on the device and the logger function is not off the time of the integrated clock will shortly be displayed.

After changing the battery the clock-setting menu is activated automatically (,CLOC'). Check the clock and adjust, if necessary (see chapter 9. Configuration).



Max Memory: Pressing "max" (key 2) shows the maximum of the measured values. Pressing it again hides it. To clear the max memory press key „max“ for >2 seconds.

Min Memory: Pressing "min" (key 5) shows the minimum of the measured values. Pressing it again hides it. To clear the min memory press key „min“ for >2 seconds.

Hold Function: By pressing "Store/Quit" (key 6) the last measuring value will be held in the secondary display. Pressing it again hides it. (only when logger = ,off').

Tare Function: By pressing "Tara" (key 3) the display will be set to 0. All measurements from then on will be displayed relatively to the set tare value. When tara function is activated, the arrow "Tara" appears in the display. To deactivate tare function press "Tara" for >2 seconds.



Note: Activating/deactivating tara clears the max- & min-memories.

9. Configuration

To change device settings, press **“Menu”** (key 4) for 2 seconds. This will call the configuration menu (main display: „SEt“).

Pressing key **“Menu”** changes between the menu, pressing **“▶”** (key 3) jumps to the referring parameters, which can be selected with key **“▶”** (key 3).

The parameters can be changed with **“▲”** (key 2) or **“▼”** (key 5).

Pressing **“Menu”** again jumps back to the main configuration menu and saves the settings.

“Quit” (key 6) finishes the configuration and returns to standard measuring operation.

Menu	Param.	Values	Meaning	
,Menu'	▶	▲ or ▼		
SEt	Set Configuration: Generic Configuration			
ConF	Unit	mbar, bar..	Unit: Unit of display	*
	SL	oFF/on	Sea-Level: on or off	*
	Alti	-2000..9999	Altitude: Input of altitude above sea level [m] (only if SL on)	*
	rAtE		Rate: Measuring rate (see chapter 9.1 Different Kinds Of Measuring: „rAtE-Slo, -P.dEt, -FASt“)	*
		Slo	Slow: measuring rate (4 Hz filtered, low power consumption)	*
		FASt	Fast: measuring rate, filtered (>100 Hz)	*
		P.dEt	Peak detection: fast measuring rate, unfiltered (>100 Hz)	*
	t.AVG	1-120	Averaging period in seconds, used by the averaging function	
		oFF	Averaging function deactivated	
	P.oFF	1-120	Auto Power-Off time in minutes	
		oFF	Auto Power-Off deactivated	
	Adr.	01,11..91	Base address of interface	
SEt	Set Alarm: Settings Of Alarm Function			
AL.	AL.	On	Alarm on, with horn-sound	
		no.So	Alarm on, without horn-sound	
		oFF	Alarm deactivated	
	AL.Lo	0 bar ... AL.Hi	Min alarm rail (not when AL. oFF. Sensor-Min is the lower display range of connected sensor)	
	AL.Hi	AL.Lo ...1.3 bar	Max alarm rail (not when AL. oFF. Sensor-Max is the upper display range of connected sensor)	
SEt	Set Logger: Configuration Of Logger Function			
LoGG	Func	CYCL	Store: logger function, 'cyclic logger'	*
		Stor	Cyclic: logger function, 'individual value logger'	*
		oFF	no logger function	*
	CYCL	1..3600	Cycle time of cyclic logger [seconds]	*
	Lo.Po	on/oFF	Low-power logger with very low power consumption (only for cyclic logger and slow measuring rate)	*
SEt	Set Clock: Setting Of Real Time Clock			
CLOC	CLOC	HH:MM	Clock: Setting of time hours: minutes	
	dAtE	TT.MM	Date: day. month	
	YEAr	YYYY	Year:	



Note! If the logger memory contains data already, the menus/parameters marked with (*) can not be invoked! If these should be altered the logger memory has to be cleared before! (key 6, please refer to. chapter 10. “Operation Of Logger”)

9.1 Different Kinds Of Measuring: „rAtE-Slo, -P.dEt, -FASt“

Three different kinds of measuring pressure are supported. Two of them are working with high measuring frequency of more than 100 measurings per second. If one of them was chosen in the configuration (see above), this will be displayed in the secondary display: „P.dEt“ or „FASt“.

9.1.1 rAtE-Slo: Standard Measuring

Measuring rate 4Hz, averaging and filter functions are active.

Application: Measuring of slowly changing or static pressures, e.g. measuring of leak proofness, atmospheric pressure...

Highest accuracy, high noise immunity (EMI and unstable measuring signals), low power consumption.

9.1.2 rAtE-P.dEt: Peak detection

Measuring rate >100Hz, the value is displayed **unfiltered**.

Application with logger function: Measuring of short pressure peaks or fast changing pressures with a resolution of <10ms. The cyclic logger function records the arithmetic mean value, the highest and the lowest peak of the referring time interval.

Attention: higher power consumption, measuring is sensitive to noise (EMI,...).

9.1.3 rAtE-FASt: Fast filtered measuring

Measuring rate >100Hz, the value is **filtered** slightly (higher noise immunity than P.dEt, small peaks will be filtered out), apart from that identical behaviour like P.dEt.

9.2 Sea Level Correction

The device displays the absolute pressure measured at the sensor. This is not necessarily the same like the values given by weather stations! The weather stations' values are giving the pressure at sea level. Usually the sensor is placed above sea level and therefore, if the value at sea level(zero) is to be measured, the pressure loss resulting from the actual level above sea level has to be considered! To correct the measuring display activate the „Sea-Level-Function“ (SL, please refer to chapter 9. “Configuration”). Then enter the altitude above sea level of the sensor's location in meters (Alti, please refer to chapter 9. Configuration). When activated, the display shows the SL-arrow and the device displays the pressure value at sea level.

9.3 Averaging Function

The averaging function concerns the display values (LCD and interface). It is completely independent from the averaging of the logger function, please don't mix them up!

The averaging integrates the measuring values during a selectable period of time and then calculates the average display value. It is independent from the selected kind of measuring (slow, fast, peak detect)

As long as not enough values are collected (selected averaging time) to calculate a average value, the upper display shows "----", the lower display a 'countdown'.

During an active low-power-logging procedure the averaging is always deactivated.

Function of min-/max-value memory during averaging:

- If averaging is activated and slow measuring is selected (rAtE-Slo), the min-/max-value memory refers to the average display value.
- If averaging is activated and fast measuring is selected (rAtE-FASt or P.dEt) , the min-/max-value memory refers to the internal measured values (fast peaks can be detected).

9.4 Power Off Time

If there won't be pressed any key and no interface communication takes place for the time of the power off time setting (P.Off), the device will be switched off automatically to save battery power.

If P.oFF = oFF then the automatic switch off is deactivated.

9.5 Address

Up to 10 devices of the GMH3xxx- handheld-family can be connected to a serial interface at once (depending on interface converter, e.g. GRS3105: 5 devices). To get access to each device the base addresses of the devices have to be different. For example choose 01 for the first, 11 for the second device and so on. See also chapter 11. "The Serial Interface".

9.6 Alarm

There are three possible settings: Alarm off (AL. oFF), on with horn sound (AL. on), on without horn sound (AL. no.So).

Following conditions will display an alarm, when the function is activated (on or no.So):

- Value is below lower (AL. Lo) or above upper alarm rail (AL.Hi).
- Sensor error (Sens Erro)
- Low battery (bAt)
- Fe 7: System error (always with sound)

In case of an alarm and when polling the interface the prio-flag is set in the returned interface message.

9.7 Real Time Clock

The real time clock is used for the logger function: Recorded values are also containing the point of time, when they were measured. Please check the settings when necessary.

If the battery was replaced the referring menu ‚CLOC‘ will automatically be started.

10. Operation Of Logger

The device supports two different logger functions:

„Func-Stor“:

each time when „store“ (key 6) is pressed a measurement will be recorded.

„Func-CYCL“:

measurements will automatically be recorded each interval, which was set in the logger menu ‚CYCL‘ until the logger will be stopped or the logger memory is full. The recording is started by pressing „Store“ 2 seconds.

The logger records 3 measurement results each time:

Current or mean value (depending on logger setting, see below), min peak and max peak.

Min and max peak are the minimum resp. the maximum of the measured values since the last recording.

Using them allows f.e. analysis of fluctuating pressures.

For the evaluation of the data the software HND-Z034 has to be used. The software also allows easy configuration and starting of the logger.

When the logger is activated (Func Stor or Func CYCL) the hold function is no more available, the key 6 is solely used for the operation of the logger functions.

10.1 „Func-Stor“: Storing Single Measurements

Each time when „store“ (key 6) is pressed a measurement and its time stamp will be recorded.

The recorded data can be viewed either in the display (when calling the configuration an additional menu „REAd LoGG“ is displayed, see below) or by means of the interface and a PC with GSOFT3050-software.

Max. number of measurings: 99

A measuring contains:

- current measuring value at the time of recording
- min peak, max peak since the last recording
- - time and date of the recording

After each recording „St. XX“ will be displayed for a short time. XX represents the number of the recording.

If logger memory contains recordings already:

When „Store“ is pressed for 2 seconds, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear the last recording



Clear nothing (Cancel menu)

The selection can be made by “▲” (key 2) and “▼” (key 5). "Quit" (key 6) enters the choice.



If the logger memory is full, the display will show:

Viewing Recorded Measurements

Within the „LoGG Stor“ function the measurements can be viewed directly in the display not only by means of a computer (like at „Func CYCL“): press 2 seconds „Set“ (key 4): The first menu displayed now is „rEAd LoGG“ (read logger data). After pressing “▶” (key 3) the measurement recorded last will be displayed, changing between the different values referring to the measurement also is done by pressing “▶”.

Changing the measurement is done by pressing the keys “▲” or “▼”.

10.2. „Func-CYCL“: Automatic Recording With Selectable Logger-Cycle-Time

The Logger-Cycle-Time is settable (please refer to Configuration). For example „CYCL“ = 60: A measuring is recorded after each 60 seconds.

When the slow measurement "rAtE-Slo" is chosen, additionally a low power function is available: „Lo.Po“.

If „Lo.Po“ is on, the device only will take a measurement at the point of time of the recording. In between the recordings the measuring shuts down. This decreases the power consumption enormously and therefore is recommended e.g. for long time recordings where no mains adapter is available.

Max. number of measurings: 9999

Cycle time: 1...3600 seconds (=1h), selectable in the configuration

A measurement comprises of:

by slow measurements (rAtE Slo):

- current measuring value at the time of recording
- min peak, max peak since the last recording

by fast measurements (rAtE FASt,P.dEt)

- arithmetic mean value since the last recording
- min peak, max peak since the last recording

Starting a recording:

By pressing "Store" (key 6) for 2 seconds the recording will be initiated. After that the display shows 'St.XXXX' for a short time whenever a measuring is recorded. XXXX is the number of the measuring 1..9999.

If the logger memory is full, the display will show:



The recording automatically will be stopped.

If Low-Power-Logger-Function „Lo.Po = on“ the device switches itself off as soon as the memory gets filled.

Stopping the recording manually:

By pressing "Store" (key 6) the recording can be stopped manually. Then the following choice appears:



Stop the recording



Do not stop the recording

The selection can be made by "▲" (key 2) and "▼" (key 5). "Quit" (key 6) enters the choice.



Note: If you try to switch off the instrument in the cyclic recording operation You will be asked once again if the recording is to be stopped. The device can only be switched off after the recording has been stopped!

The Auto-Power-Off-function is deactivated during recording!

Clear Recordings:

When „Store“ is pressed for 2 seconds, the choice for clearing the logger memory will be displayed:



Clear all recordings



Clear nothing (cancel menu)

The selection can be made by "▲" (key 2) and "▼" (key 5). "Quit" (key 6) enters the choice.

11. The Serial Interface

With an electrically isolated interface converter HND-Z031 (accessories) the device can be directly connected a RS232 interface of a computer (HND-Z032 complies with USB-interface). To avoid transmission errors, there are several security checks implemented (CRC).

The following standard software packages are available:

HND-Z034: Operation and read out of logger function, data display in diagrams and tables

The device has 3 channels:

Channel 1: current measuring value (base address)

Channel 2: min peak (please refer to chapter 10. Operation Of Logger)

Channel 3: max peak (please refer to chapter 10. Operation Of Logger)






Note! The measuring-/ alarm- and display range values read back from the interface are always in the selected measurement unit (mbar, bar...)!

Supported functions:

Channel				Code	Name/Function	Channel				Code	Name/Function	
1	2	3				1	2	3				
x	x	x	0		Read measurement value	x	x	x	199		Read kind of measuring of display	
x	x	x	3		Read system state	x	x	x	200		Read min display range	
x			6		Read min memory	x	x	x	201		Read max display range	
x			7		Read max memory	x	x	x	202		Read display range - unit	
x	x	x	12		Read ID number	x	x	x	204		Read display range – decimal point	
x			22		Read min alarm rail (AL. - AL.Lo)	x			208		Read # of channels	
x			23		Read max alarm rail (AL. - AL.Hi)	x			220		Read altitude (only abs. press sensors)	
x			32		Read configuration flag	x			221		Set altitude (only abs. press sensors)	
					BitAlarmOn:1; BitAlarmSound:3;	x			222		Read power off time (Conf-P.oFF)	
					BitCorrectToSealevel:32 (only abs. press. Sensors);	x			223		Set power off time (Conf-P.oFF)	
					BitPeakDetection:33; BitFastFiltered:34;	x	x	x	224		Logger: Read data of CYCL- Logger	
					BitLoggerOn:50; BitCyclicLogger:51;	x			225		Logger: Read cycle time (LoGG - CYCL)	
			52		BitLowPowerLogger:52	x			226		Logger: set cycle time (LoGG - CYCL)	
x			102		Set min alarm rail (AL. - AL.Lo)	x			227		Logger: start recording	
x			103		Set max alarm rail (AL. - AL.Hi)	x			228		Logger: Read # of recordings made	
x			160		Set configuration flag (refer to 32)	x			229		Logger: Read state	
x			174		Clear min memory	x			231		Logger: Read stop time	
x			175		Clear max memory	x			233		Read real time clock (CLOC)	
x	x	x	176		Read min measuring range	x			234		Set real time clock (CLOC)	
x	x	x	177		Read max measuring range	x			236		Read logger memory size	
x	x	x	178		Read measuring range – measuring unit	x			240		Reset	
x	x	x	179		Read measuring range – decimal point	x			254		Program version	
x	x	x	180		Read kind of measuring of sensor	x			260		Logger: read data of STOR Logger	
x			194		Set display unit	x						

12. Error And System Messages

Display	Meaning	What to do?
	Low battery power, device will only continue operation for a short period of time	Replace battery
	Battery empty	Replace battery
	Mains operation without battery: wrong voltage	Check power supply, replace it when necessary
	Logger data are read by the interface	When transfer completed the device will automatically return to normal measuring display, no remedy necessary
No display or confused characters, device does not react on keypress	Battery empty	Replace battery
	Mains operation without battery: wrong voltage or polarity	Check power supply, replace it when necessary
	System error	Disconnect battery and power supplies, wait shortly, then reconnect
	Device defective	Return to manufacturer for repair
Err.1	Measured value above allowable range	Check: pressure above 1300 mbar? -> measuring value to high
	Sensor defective	Return to manufacturer for repair
Err.2	Measured value below allowable range	-> measuring value to low
	Sensor defective	Return to manufacturer for repair
Err.4	Value is too low to be displayed, tara is set	Check: display below -2000 (tara?)?
Err.9	Measured value far out of allowable range	Check: pressure not within sensor range?
Err.7	System error	Return to manufacturer for repair

13. Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certificated for its accuracy, it is the best solution to return it to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results with highest accuracy!

14. Maintenance

14.1 Battery Operation

If Δ and 'bAt' are shown in the secondary display, the battery has been used up and needs to be replaced. The device will, however, operate correctly for a certain amount of time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.

The battery has to be taken out, when, the device is stored above 50°C.



We recommend to take out battery if device is not used for a longer period of time!

15. Technical Information

Measuring range:	0 to 1300 mbar
Accuracy:	±0,2 % F.S. (hysteresis and linearity) ±0.4 % F.S. (temperature dependency 0-50 °C)
Resolution:	1 mbar
Pressure units:	mbar, bar, kPa, MPa, mmHg, PSI, m (switchable)
Overload:	max. 4 bar absolute
Measuring input:	by means of a metal-hose stem
Sensor:	piezo-resistive absolute pressure sensor, for air or non-corrosive and non-ionising gases and liquids, not for water!
Display:	2 x 4-digit LC-displays
Operating temperature:	0...50 °C
Storage temperature:	-20...+70 °C
Relative humidity:	0...95 % r.H. (non-condensing)
Output:	serial interface (via 3-pin jack, transformer on RS232 or USB optional)
Power supply:	9V-monobloc battery (included in scope of delivery), external 10.5 - 12VDC via jack
Current consumption:	max. 3 mA (HND-P239)
Materials:	housing made of impact-resistant ABS plastic
Protection:	IP65, front side
Dimensions:	142 x 71 x 26 mm (L x W x D)
Weight:	approx. 160g

Scope of functions:

- Min-/Max-value memory
- Hold function: »freezing« of the current value
- Automatic-off function: 1...120 min (can be deactivated)
- Zero point adjustment via keyboard possible
- Tare function: Display, minimum/maximum values are set to zero
- Battery change notification

Additional functions for the HND-P239:

- Minimum/maximum alarm can be deactivated
- Alarm (3 alarm settings)
 - Off: Alarm function inactive
 - On: Alarm notification via display, internal horn and serial interface
 - No Sound: Alarm notification only via display and interface
- Averaging
- Peak value memory unfiltered pressure peaks ≥ 10 msec
- Adjustable measuring cycle:
 - »slow« 4 measurements/sec
 - »fast« ≥ 100 measurements/sec (filtered)
 - »peak-detect« ≤ 100 measurements/sec
- Power saving mode in the measuring cycle »slow«
- Real-time clock: current time
- Logger functions:
 - Manual: 99 datasets
 - Cyclic: 9999 datasets
 - Adjustable cycle time: 1sec...1h

16. Order Codes

Order-No.	Design
HND-P 239	1x pressure sensor input, with additional functions (see Technical Information)

16.1 Accessories for HND-P

Order-No.	Description
HND-Z002	Plug power supply unit (220/240 V, 50/ 60 Hz), 10,5 V/10 mA
HND-Z011	Equipment protective housing bag, nappa leather, with 1 cut-out for round sensor connection
HND-Z012	Equipment protective housing bag, nappa leather, with 2 cut-outs for round sensor connection of the HND- series with logger function
HND-Z021	Case with recess (275 x 229 x 83 mm)
HND-Z022	Universal case with egg crate foam (275 x 229 x 83 mm)
HND-Z023	Large case with recess (394 x 294 x 106 mm)
HND-Z031	Interface converter on RS232, galvanically isolated
HND-Z032	Adapter RS232 converter on USB- interface
HND-Z033	Interface converter on USB, galvanically isolated
HND-Z034	Windows software for setting, data read-out, and printing of the data of housings of the HND- series with logger function
HND-Z081	Double nozzle for hose $\frac{6}{4}$ on hose $\frac{6}{4}$
HND-Z082	Hose clamp for hose $\frac{6}{4}$
HND-Z083	Adapter made of brass for G $\frac{1}{4}$ internal threads on hose $\frac{6}{4}$
HND-Z084	PVC-hose (5 bar), 6 mm external / 4 mm internal
HND-Z085	PE-hose (10 bar), 6 mm external / 4 mm internal
HND-Z086	PU-hose (9 bar), 6 mm external / 4 mm internal
HND-Z087	PA-hose (25 bar), 6 mm external / 4 mm internal

Additional accessories on request.

17. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

**Handheld Digital Pressure Meter
with external pressure sensor**

Model: HND-P239

to which this declaration relates is in conformity with the standards noted below:

Also the following EEC guidelines are fulfilled:


**93/38/EEC, 2004/108/EC
73/23/EEC, 93/68 EEC**

Electromagnetic compatibility
Low voltage guideline (for usage of the external
power supply HND-Z002)


Hofheim, 28. Jul. 2005




H. Peters
General Manager



M. Wenzel
Proxy Holder



Digital Pressure Sensors
Model HND-PS19...PS33, HND-PS20...PS23
for
HND-P105, HND-P210 and HND-P215



Content

1	INTENDED USE	2
2	GENERAL	2
3	OPERATING AND MAINTENANCE ADVICE	3
4	GENERAL SAFETY REQUIREMENTS	3
5	SPECIFICATION	4
5.1	SPECIFICATION (HND-PA...):	4
5.2	SPECIFICATION (HND-PS...):	4
5.3	COMMON SPECIFICATIONS (HND-PA., HND-PS.):	4

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

1 Intended use

The pressure sensors are designed for the connection to an hand-held instrument of the following types:

HND-P105, HND-P210, HND-P215

The sensors have following application areas:

- air, aggressive gases
- water, aggressive media, etc.

2 General

Read through this document attentively and make yourself familiar to the of the device before you use it. Keep this document in a ready-to-hand way in order to be able to look up in the case of doubt.

3 Operating and Maintenance Advice

- a.) You must only use the sensor with suitable devices!
Usage of other devices may result in destruction of sensor and device.
- b) Treat sensor and device carefully. Use only in accordance with above specification. (do not throw, hit against etc.).
Protect plug from soiling.
- c) To disconnect pressure sensor adapter cable from the device do not pull at the cable but at the plug (to open lock).
When connecting the sensor make sure that arrows are pointing upwards and that plug is entered into device socket centrally. Do not twist plug when entering socket.
If plug is entered correctly, it will slide in smoothly
If plug is twisted or entered incorrectly the connecting pins of the plug can be spoiled by bending or broken
=> Plug can no longer be used and connecting cable needs to be replaced.
- d) **HND-PS...** (= relative pressure sensor):
Caution: The pressure compensation hole has to be kept clean! It is placed at the back part of the housing.
Do not cover with stickers or similar things!

4 General Safety requirements

This device has been designed and tested in accordance with the safety regulations for electronic devices. However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under "Specification".
2. If the device is transported from a cold to a warm environment condensation may result in a failure of the device. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
3. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting.
Operator safety may be at risk if:
 - there is visible damage to the device.
 - the device is not working as specified.
 - the device has been stored under unsuitable conditions for a longer time.In case of doubt, please return device to manufacturer for repair or maintenance.
4. **Warning:** Do not use this product as safety or emergency stop device or in any other application where failure of the product could result in personal injury or material damage.
Failure to comply with these instructions could result in death or serious injury and material damage.
5. **Any changes or repair of the device is not allowed.**
Please return device to manufacturer for repair or maintenance.

5 Specification

5.1 Specification (HND-PA...):

	HND-PA20	HND-PA21	HND-PA22	HND-PA23	HND-PA... (special range)
Measuring range:	0 ... 1000 mbar abs.	0 ... 2500 mbar abs.	0 ... 4000 mbar abs.	0 ... 6000 mbar abs.	refer to type plate
Overload: (max.)	5 bar abs.	10 bar abs.	17 bar abs.	35 bar abs.	refer to type plate
Resolution:	1 mbar	1 mbar	1 mbar	1 mbar	refer to type plate

Sensortyp: stainless steel absolute pressure sensor.
Suitable for aggressive media, water, etc.

5.2 Specification (HND-PS...):


	HND-PS19	HND-PS20	HND-PS21	HND-PS22	HND-PS23	HND-PS24	HND-PS25	HND-PS26
Measuring range:	0,0 ... 400,0 mbar rel.	0 ... 1000 mbar rel.	0 ... 2500 mbar rel.	0 ... 4000 mbar rel.	0 ... 6000 mbar rel.	0,00 ... 10,00 bar rel.	0,00 ... 25,00 bar rel.	0,00 ... 40,00 bar rel.
Overload: (max.)	2 bar	5 bar	10 bar	17 bar	35 bar	35 bar	50 bar	80 bar
Resolution:	0,1 mbar	1 mbar	1 mbar	1 mbar	1 mbar	0,01 bar	0,01 bar	0,01 bar


	HND-PS27	HND-PS28	HND-PS29	HND-PS30	HND-PS31	HND-PS32	HND-PS33	HND-PS... (Sonderbereich)
Measuring range:	0,00 ... 60,00 bar rel.	0,0 ... 100,0 bar rel.	0,0 ... 160,0 bar rel.	0,0 ... 250,0 bar rel.	0,0 ... 400,0 bar rel.	0,0 ... 600,0 bar rel.	0 ... 1000 bar rel.	refer to type plate
Overload: (max.)	120 bar	200 bar	320 bar	500 bar	800 bar	1200 bar	1500 bar	refer to type plate
Resolution:	0,01 bar	0,1 bar	0,1 bar	0,1 bar	0,1 bar	0,1 bar	1 bar	refer to type plate

Sensortyp: stainless steel relative pressure sensor for overpressure measuring.
Suitable for aggressive media, water, etc.
Caution: The pressure compensation hole at the back part of the housing has to be kept clean!

5.3 Common specifications (HND-PA..., HND-PS...):

- Accuracy:** (typ. values) ±0,2%FS (hysteresis and linearity)
±0,4%FS (temperature influence from 0-50°C)
- Pressure connection:** connections thread G1/4. Key width: 27 mm
- Device Connection:** M12-plug, for connection cable HND-K31
- Electronics:** PC-board with amplifier and data memory for sensor data (measuring data, calibration etc.) integrated in sensor housing.
- Nominal temperature:** 25 °C
- Operating conditions:** -20 to +70 °C (compensated range: 0 to 70 °C)
- Storage temperature:** -40 to +80 °C
- Housing:** made of stainless steel (CrNi steel or Elgiloy®)
- Weight:** 220 g
- IP rating:** IP 67 (sensor), IP 54 (plug)
- EMC:** The HND... corresponds to the essential protection ratings established in the Regulations of the Council for the Approximation of Legislation for the member countries regarding electromagnetic compatibility (2004/108/EG). Additional fault: <1%





**Operating Instructions
for
Digital Pressure Sensor**

Model: HND-PS04



1. Contents

1. Contents.....	2
2. Note	3
3. Instrument Inspection.....	3
4. Regulation Use.....	3
5. Operating Principle.....	3
6. Mechanical Connection.....	4
7. Operation	5
8. Technical Information.....	5
9. Declaration of Conformance	6

Manufactured and sold by:

Kobold Messring GmbH
Nordring 22-24
D-65719 Hofheim
Tel.: +49(0)6192-2990
Fax: +49(0)6192-23398
E-Mail: info.de@kobold.com
Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EC-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

- Digital Pressure Sensor model: HND-PS04
- Operating Instructions

4. Regulation Use

Any use of the Digital Pressure Sensor, model: HND-PS04, which exceeds the manufacturers specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

With the appropriate external pressure sensors, precise measurement results over the entire measuring range can be achieved. Various pressure sensors are available for a multitude of measuring tasks and special applications.

6. Mechanical Connection

This device has been designed and tested in accordance with the safety regulations for electronic devices. However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under "Specification".
2. If the device is transported from a cold to a warm environment condensation may result in a failure of the device. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.
3. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting. Operator safety may be at risk if:
 - there is visible damage to the device.
 - the device is not working as specified.
 - the device has been stored under unsuitable conditions for a longer time.In case of doubt, please return device to manufacturer for repair or maintenance.



Warning: Do not use this product as safety or emergency stop device or in any other application where failure of the product could result in personal injury or material damage.

Failure to comply with these instructions could result in death or serious injury and material damage.

4. Any changes or repair of the device is not allowed.
Please return device to manufacturer for repair or maintenance.

7. Operation

- a) You must only use the sensor with HND-P-devices (see Datasheet)! Usage of other devices may result in destruction of sensor and device.
- b) Treat sensor and device carefully. Use only in accordance with above specification. (Do not throw, hit against etc.). Protect plug from soiling.
- c) To disconnect pressure sensor do not pull at the cable but at the plug (to open lock).

When connecting the sensor make sure that arrows are pointing upwards and that plug is entered into device socket centrally. Do not twist plug when entering socket.

If plug is entered correctly, it will slide in smoothly.

If plug is twisted or entered incorrectly the connecting pins of the plug can be spoilt by bending or broken => Plug can no longer be used and connecting cable needs to be replaced.

- d) HND-PS01...HND-PS08 (= standard (plastic) pressure sensors): Connection diagram for sensor tube connection:

For measurements of over pressure (relative pressure sensor):

- Connect plastic tube with internal dia of 4 mm to cable gland "B". Connection "A" will not be used!

For measurements of pressure differences (relative pressure sensor):

- Connect both plastic tubes with an internal dia of 4 mm to cable gland "B" and "A"; make sure to apply higher pressure to connection "B"

For measurements of absolute pressure (absolute pressure sensor):

- Connect plastic tube with an internal dia of 4 mm to cable gland "A".(Cable gland "B" is not used.)

8. Technical Information

Measuring range	Linearity/temperature dependency 0...50 °C	Resolution	Overload	Operating temperature	Connection	Order-no.
-1000... 2000 mbar rel.	±0,2% of full scale/ ±0,4% of full scale*	1 mbar	max. 4 bar	0...+50 °C	Nylon spigot for hose 6x1 mm	HND- PS04

* in the range from 0 to 50 °C

9. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Digital Pressure Sensor Model: HND-PS04


to which this declaration relates is in conformity with the standards noted below:

EN 61326-1:2006 Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements


Also the following EC guidelines are fulfilled:

2004/108/EC EMC Directive
2006/95/EC Low Voltage Directive

Hofheim, 23. Sept. 2014



H. Peters
General Manager



M. Wenzel
Proxy Holder