

Operating Instructions for Pressure Sensor with Ceramic Sensor Element

Model: SEN-9601



SEN-9601

Subject to change without prior notice

1. Contents

1.	Contents	2
2.	Note	.3
3.	Instrument Inspection	.3
4.	Regulation Use	.3
5.	General	.4
6.	Installation	. 4
7.	Electrical Connection	. 5
8.	Maintenance	. 6
9.	Product Label	.6
10	Technical Information	.6
11.	Dimensions	. 8
12.	Declaration of Conformance	.9

Manufactured and sold by:

Kobold Instruments Inc. 1801 Parkway View Drive Pittsburgh, PA 15205 Tel: 412-788-2830 Fax: 412-788-4890 E-Mail: info@koboldusa.com Internet:www.koboldusa.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfill the EWG-machine guidelines.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition. Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, as they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

• Pressure Sensor

model: SEN-9601

• Operating Instructions

4. Regulation Use

Any use of the "Description Instrument", which exceeds the manufacturers specification may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.



Caution!

The manufacturer disclaims all responsibility in case of damages caused by the improper use of the product and by the non-respect of the instructions reported in this manual.

- Follow carefully the specific safety rules in case of measuring oxygen pressure, acetylene, inflammable or toxic gas or liquids.

- Disconnect the instruments only after depressurization of the system.

- The process fluids residuals in the disassembled instruments could affect people, the environment and the system. It is highly recommended to take proper precautions.



Before installation, ensure that the right instrument has been selected following the working conditions and in particular the range, the working temperature and the compatibility between the material used and the process fluid.

This manual does not conform to standard 94/9/CE (ATEX).
The product warranty is no longer valid in case of non-authorized modifications and of incorrect use of the product.

- The user is totally responsible for the instrument installation and maintenance.

- Handle and carefully stock the instrument used for toxic or inflammable liquids measurement

The pressure transmitter turns the input pressure into an output electrical signal. The electrical signal changes in proportion to the input pressure level.

5. General

The KOBOLD SEN-96 Standard model is an electronic transmitter with ceramic sensor for air, industrial, technical gases, water, and oils. They are designed to be installed in gaseous distribution plants, storage tanks, refrigeration, compressors, vacuum pumps, and general hydraulic/pneumatic pressure systems.

6. Installation

Before installing electrical instrument safely and securely into a plant or a system the user should verify the instrument suitability to the plant characteristics and the correct installation. After installation the user should verify that the instrument is not exposed to any source of heat exceeding the established ambient limits. Secure the instrument thread through a special key/wrench on the process connection hexagon (20...30 Nm). The correct torque depends on the type of process connection and the type of seal used (form and material). As for those process connections with a cylindrical thread (Gas-Metric), a head gasket compatible with the measurement gas or fluid should be used. If the connection thread is conical the instrument is tightened through a simple

screwing on the plug. In order to improve the thread tightness it is recommended to place a PTFE layer on the male thread.

If the instrument is equipped with a fluid diaphragm seal the connection should be clamped on the diaphragm otherwise the calibration could be compromised.

7. Electrical Connection

Output signal:	420 mA		
N° of wires:	2		
Charge (Ohm):	$R_L - (UB-9)/0,02$	2	
Input UB:	830		
	EN 175301-803 Fo	rm A	
Output signal:	05 Vdc	010 Vdc	0,54,5 Vdc
Nº of wires.	3	3	3

3 Kohm min.	3 10Kohm min. 5Ko	hm
Kohm min.	10Kohm min. 5Ko	hm
14		
14	30 5	
803 Form A		
) <u>s+</u> V		
	803 Form A	803 Form A

The transmitter metal case should always be connected to ground through the process connection thread in order to protect it from disturbances due to electromagnetic fields or electrostatic charges.

If it is not possible to do so, connect the transmitter to ground through the connector and the cable gland.

8. Maintenance

The SEN-9601 transmitter is *"maintenance free"*. If a fault occurs, contact Kobold. Using transmitters that have been subjected to repair not authorized by Kobold relieves the Company of any and all responsibility and causes the contractual guarantee to become null and void.

9. Product Label

SEN -96010B075A0	- 830 VDC	77
010 bar 420 mA	A _{CC} ≤0,5 10/13	
1: + UB 2: - 0V	S# 9-80248	N O
Kobold Messring GmbH Werk 2	D-71065 Sindelfingen ()	

10. Technical Information

Ranges:	-14.50PSIG to 0 – 6000PSIG
Accuracy:	\leq ± 1.0% of the range*
Non-linearity (BFSL):	\leq ± 0.5 % of the range, according to EN 61298-2
Non-repeatability:	\leq 0.1 % of the range, according to EN 61298-2
Output signal	
deviation of zero:	\leq ± 0.5 % of span, typical; iÜ ± 0.8 % of span, max.
Thermal drift:	Between 0 and 80 °C, 1 % of span;
	2.5 % of span, max.
Long term drift:	\leq 0.2 % of span, according to EN 61298-2
Process fluid temperature,	
ambient and stocking	
temperature:	-10+185 °F
Output signals:	4 20 mA, 05 VDC, 010 VDC,
	1 5 VDC, 0.5 4.5 ratiometric VDC
Response time:	<4 ms
Emission and immunity:	According to EN 61326, (group 1 - class B; industrial
	applications)
Process connection:	316L, hole ø 2.5 mm
Sensor:	Ceramic in Al2O3
Case:	316L, vented up to 200PSIG

Gasket (Sensor): Electric connection: Protection degree: 0.27lb FKM DIN 43650A IP 65 according to IEC 529 / EN 60529** Weight:

* Including non-linearity, hysteresis, non-repeatability and output signal deviation of zero at the reference conditions described in standard EN 61298-1

** with properly assembled electric connection .

Output signal code	420 mA 0	05 V _{DC} 1	010 V _{DC} 2	0.54.5 V _{DC} ratiometric – 3	15 V _{DC} 4
No. of wires	2	3	3	3	3
Load max. (Ω)	R _L ≤ (Vin- 8)/0.02	R _L ≥ 5 KΩ	R _L ≥ 10 KΩ	R _L ≥ 4.5 KΩ	R _L ≥5 KΩ
Supply: + Vin (V _{DC})	830	830	1430	5 ± 10 %	830
Absorbed current (mA)	< 25	< 10	< 10	< 10	< 10

All output signals are provided of protection against short circuit and polarity inversion. Insulation tension 500 V_{DC}

11. Dimensions



F ¹⁾	L (mm)
A -G½, male EN 837	20
B -G¼, male EN 837	13
E-G1/4, male DIN 3852-E ²⁾	13
F -1/2 - 14 NPT	20
G -1/4 - 18 NPT	13

1) Torque 20...30 Nm

2) For pressures up to 400 bar

12. Declaration of Conformance

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

Pressure Sensor with Ceramic Sensor Elements Model: SEN-9601

to which this declaration relates is in conformity with the standards noted below:

DIN EN 61326

Electrical equipment for measurement, control and laboratory use. EMC requirements-Industrial environment.

Also the following EWG guidelines are fulfilled:

89/336/CE

EMC - Electromagnetic compatibility

Hofheim, 14. March. 2013

poa. Willing

H. Peters General Manager

M. Wenzel Proxy Holder