

User manual for

Resistance Thermometers for Harsh Operational and Ambient Conditions

Version:TNK



Order from: C A Briggs Company 622 Mary Street; Suite 101; Warminster, PA 18974

Phone: 267-673-8117 - Fax: 267-673-8118
Sales@cabriggs.com - www.cabriggs.com

1. Contents

1.	Contents	2
2.	Note	3
3.	Unit inspection	3
	Intended use	
5.	Operation	4
6.	Mechanical connection	4
7.	Electrical connection	5
8.	Maintenance	6
9.	Technical data	6
10.	Order data	7
11.	Dimensions	8

Produced and distributed by:

Kobold Messring GmbH Nordring 22-24 D-65719 Hofheim Tel.: +49 (0)6192-2990

Fax: +49(0)6192-23398 Email: info.de@kobold.com Internet: www.kobold.com

Page 2 TNK K01/1112

2. Note

Please read and observe the guidelines in this user manual before unpacking and initially operating the unit.

The units are to be used, maintained and serviced solely by persons familiar with this user manual and the current regulations applying to occupational health & safety and accident prevention.

In line with the EU machine directive 2006/42/EU

When installed in machines, the measuring unit TNK should only be used, if the machine fulfils the EU machine directive.

3. Unit inspection

The units are inspected before distribution and dispatched in perfect condition. Should there be visible damage to a unit, we recommend a thorough inspection of the delivery packaging. In the event of damage, please inform the parcel or dispatch service, as the transport company assumes liability for damage during transport.

Scope of services:

The standard scope of services includes:

- Resistance thermometer Version: TNK
- User manual

4. Intended use

Faultless operation of the unit can only be guaranteed, if all points in the user manual are observed. We offer no guarantee against damage that arises due to non-compliance with this manual.

TNK K01/1112 Page 3

5. Operation

Resistance thermometers are electric temperature measuring transducers which, when used in conjunction with the corresponding evaluation devices, display and regulate temperatures. They contain temperature-dependent measurement resistors that are housed in one of the valves adapted for this purpose.

TNK resistance thermometers are specially designed for use in shipbuilding and mechanical engineering and meet the high demands for robustness, reliability, impact resistance, shock and vibration resistance in accordance with the specifications set by Germanische Lloyd and Deutsche Bahn. Particularly suitable for temperature measurements on diesel engines.

The resistance thermometer sensor is made of brass, saltwater-resistant bronze or stainless steel. The connecting head is made of saltwater resistant aluminium and is available with various cable inlets. The sensor can be built onto the machine or into the pipeline using different threaded nipples or clamp screws.

The measurement resistors can be replaced without having to remove the valve. For more critical applications, the sensor can also be used as a dual precision resistor.

6. Mechanical connection

Before installation:

- Remove all transportation locks and ensure that there are no packaging materials left in the unit.
- Ensure that the permissible max. operating pressure and operating temperature for the unit are not being exceeded (see technical data).

During installation:

- Install the resistance thermometer in the system at zero potential.
- Protect the measurement sensor from mechanical damage during the process
- Seal the mounting thread or the mounting flange with appropriate sealant.
- If possible at this point, a check should be carried out after the mechanical installation, to determine if the connecting fittings are completely sealed.
- If the resistance thermometer is mounted in an exposed location, the connecting head should be protected from exterior damage.

Page 4 TNK K01/1112

7. Electrical connection



Warning!Ensure that the voltage values in your system correspond to the voltage values for the measurement unit.



The electrical connection should only be carried out by competent staff with the relevant expertise.

Choose a suitable cable for the electrical connection:

Version TNK-...P: Cable diameter 5-10 mm

Version TNK-...M: according to DIN 89280 with internal thread M18x1.5

for cables with a cap, diameter: 8-10.5 mm

(For shipping use)

Version TNK-...M: according to VG 88812 with internal thread M18x1.5


for cables with a cap, diameter: 11.5-12.5 mm

(For military use)

Circuit diagram for plug-in socket


2 conductor (TNK-1xxx xx x2x) x3x)

The conductor resistance is read as a measurement error approx. 30 m and longer



3 conductor (TNK-1xxx xx


Measurement deviations can arise from a cable length of




4 conductor (TNK-1xxx xx x4x)

The internal conductor resistance of the connecting wires $\mathbf{B}(\mathbf{D})\mathbf{2x}$

can be ignored



2x 2 conductor (TNK-1xxx xx 2(6)2x) 2x 2 conductor (TNK-1xxx xx



We recommend connection to suitable transmitter/evaluation devices (see brochure Z2)

TNK K01/1112 Page 5

8. Maintenance

The resistance thermometers do not require maintenance.

The measurement inserts are interchangeable with the resistance sensors.

9. Technical data

Measurement sensors: Pt100, Ni100, Pt1000,

NTC (5 k Ω at 25 °C)

Measurement range: -80...+150 °C

Accuracy (Pt): class A or B according to DIN EN 60751

Accuracy (Ni): Class B

Accuracy (NTC) class B₁(± 0.2°C in range 0 -70 °C)

Basic values: PT100/Pt1000

specified in DIN EN 60751

The nominal value is 100 Ω (or 1000 for

PT1000 at 20°C

Ni100:

specified in DIN 43 760 **NTC**: $(5 k\Omega \text{ at } 25 ^{\circ}\text{C})$

It can be calculated using the following

formula.

RT = R25 * $e^{B(\frac{1}{T} - \frac{1}{TN})}$

RT = Resistance in Ω at a falling temperature R25 = Resistance in Ω at 25°C (5 k Ω) e=Fuler's number (approx. 2.71828)

e=Euler's number (approx. 2.71828)
B = coefficient Beta (25/85°C): 3976 K
T = Operating temperature in Kelvin

TN = Nominal temp. in Kelvin (298.16 K = 25°C)

Max. Temperature: 150 °C Max. Pressure: 16 bar

(Connection code: D5, G4, M5, N4)

(Clamping screws) 50 bar

Sensor material: Nickel plated brass,

saltwater resistant bronze or stainless steel 1.4571

Connection housing: saltwater resistant aluminium
Clamping screws: Galvanised steel, stainless steel
Double nipple: Nickel plated brass, stainless steel,

saltwater resistant bronze

Mechanical Connection: M18 x1.5, G 1/2, 1/2 NPT

Electrical Connection: Screw terminals in connecting head

Thread cable inlet: PG11
Protection class: IP65

Weight: approx. 350 g (50 mm sensor)

Approval: GL approval

Page 6 TNK K01/1112

10. Order data


Sensor length	Nickel plated	Version Stainless steel	Bronze saltwater	Mechanical connection	Sensor type/ class	Sensor version	Cable screw connection s	
50 mm	brass TNK-1105	TNK-1405	resistant TNK-1705	Thread, pivoting D5= M18x1.5 Double nipple M5= M18x1.5 G4= G 1/2 N4= ½ NPT Clamping screws, galvanised brass S5*= M18x1.5 S4*= G ½ P4*= ½ NPT Clamping screws stainless steel 1.4571 V5*= M18x1.5 V4*= G 1/2 Q4*= ½ NPT	class B		P= for Cable-Ø 5-10mm	
75 mm	TNK-1107	TNK-1407	TNK-1707		Double nipple M5= M18x1.5 1: G4= G 1/2 2: N4= ½ NPT 5: 6: 6:	1= 1xPt 100 2= 2xPt 100 5= 1xPt 1000 6= 1xPt 1000	2 = 2 conductor	2***= 2 m Rubber cable
100 mm	TNK-1110	TNK-1410	TNK-1710		rews, alvanised brass 5*= M18x1.5 4*= G ½	N= 1xNTC 3**=3 conductor M =	M = according to DIN	
150 mm	TNK-1115	TNK-1415	TNK-1715		A= 1xPt 100 B= 2xPt 100 C= 1xPt 1000 D= 2xPt 1000	4**=4 conductor	89280 V=	
Custom length (max. 300 mm)	-	TNK-14xx	-		D - ZAI (1000		according to VG 88812	

^{*}Clamping screws not in sensor materials, bronze **3- or 4 conductor only for single sensor *** 2 m rubber cable only for 1x 2 conductor version


TNK K01/1112 Page 7

11. Dimensions






TNK with double nipple



TNK with compression fitting



Page 8 TNK K01/1112

Type Approval Certificate This is to cert fy that the undemoted production has these been tested.



This is to certify that the undernoted product(s) has/have been tested in accordance with the relevant requirements of the GL Type Approval System.

Cortificate No.

58 793 - 08 HH

Company

KOBOLO Messring GmbH Nordring 22-24

85719 Hofheim, GERMANY

Product Description

Resistance Thermometer

Type

TNK-XXXXXXXXXX

Environmenta Category

ry D

Technica Data / Range of Application

Sensor: Pt 100, Pt 1000, Class A or B, Ni 100, NTC

Mossuring range: -80...+ 150 °C Max. temperature: 150 °C

Max. pressure: 16 bar, 50 bar with clamp connection

Thread for cable entry points: PG 11, 1118 x 1.5 DIN 8980-1:2008-96 +

VG 88812:2003-09

Degree of protection: IP 65

Test Standard

Guidelines for the Performance of Type Approvals. Chapter 2, Edition 2003

Documents

Test report : Kobold Massring No. P80803 da. 26.35.2008; Mectronic No. P082775 dd. 30.04.2008;

paconsult No. 09-2016 dd. 17.06.2088.

Drawing Nos.: 214.006 dd. 24.08.2006, 214.007 dd. 05.09.2006

Remarks

None

Valid uctil

2013-07-03

Page

1 01 1

File No. 1.0.02

Hamburg, 2008-07-04

Type Approval Symbol

GL

Germanischer Lloyd

Margo Rinkel

Contar Demnig

This certificate is issued on the post-int Grido has for the Performance of Type Approvals Part 1. Procedure.

TNK K01/1112 Page 9